



to enable "power save mode" on both outs
 replace R10 R11 to NT1 NT2