


# Andon light wireless solutions for machine monitoring & workstation call-for-action systems




## Easy steps to head-of-line monitoring

1



184-5126



184-5128



184-5127



455-3407



314-7332

Select your signal tower modules & add a transmitter to your system



184-5124

2

Install ethernet master & software on your network



184-5126



184-5128



184-5127



455-3407



314-7332

+



185-3038



3

Install another signal tower in head of line location but add WIN slave control

4

Monitor from your PC



184-5123