

LCD controller

	EXP1				EXP2		
Not used	1	2	PA1	MISO	1	2	SCK
PA7	3	4	PA5	PH1	3	4	PA3
PC0	5	6	PC2	PH0	5	6	MOSI
PC4	7	8	PC6	Not used	7	8	RST
GND	9	10	5V	Not used	9	10	Not used

1	X	7	2
3	9	1	4
5	10	12	6
7	17	8	8
9	18	14	10

1		3	2
3	15	5	4
5	13	6	6
7	X	2	8
9	X	X	10

