

Item Spec/RS Number	Item Spec/Global Description	Europe Regional/English Description/Description	Item Spec/Purchasing/Vendor Part no
7362740	Torque ESD TORX interchange.blades T7	Torque ESD TORX interchange.blades T7	26868
7362702	Torque slot. ESD interchange.blades 1.5	Torque slot. ESD interchange.blades 1.5	26869
7362706	Torque slot. ESD interchange.blades 2.0	Torque slot. ESD interchange.blades 2.0	26870
7362715	Torque slot. ESD interchange.blades 3.0	Torque slot. ESD interchange.blades 3.0	26871
7362718	Torque slot. ESD interchange.blades 3.5	Torque slot. ESD interchange.blades 3.5	26872
7362712	Torque slot. ESD interchange.blades 4.0	Torque slot. ESD interchange.blades 4.0	26873
7362728	Torque ESD PH interchange.blades PH0	Torque ESD PH interchange.blades PH0	26875
7362724	Torque ESD PH interchange.blades PH00	Torque ESD PH interchange.blades PH00	26876
7362721	Torque ESD PH interchange.blades PH000	Torque ESD PH interchange.blades PH000	26877
7362737	Torque ESD PH interchange.blades PH1	Torque ESD PH interchange.blades PH1	26878
7362730	Torque ESD PZ interchange.blades PZ0	Torque ESD PZ interchange.blades PZ0	26879
7362734	Torque ESD PZ interchange.blades PZ1	Torque ESD PZ interchange.blades PZ1	26880
7362743	Torque ESD TORX interchange.blades T5	Torque ESD TORX interchange.blades T5	26881
7362746	Torque ESD TORX interchange.blades T6	Torque ESD TORX interchange.blades T6	26882
7362759	Torque ESD TORX interchange.blades T8	Torque ESD TORX interchange.blades T8	26883
7362752	Torque ESD TORX interchange.blades T9	Torque ESD TORX interchange.blades T9	26884
7362756	Torque ESD TORX interchange.blades T10	Torque ESD TORX interchange.blades T10	26885
7362765	Torque ESD bit universal holder	Torque ESD bit universal holder	27711
7362709	Diagonal cutters Inomic 160mm	Diagonal cutters Inomic 160mm	33254
7362699	Needle nose pliers Inomic 160mm	Needle nose pliers Inomic 160mm	33256
7362695	Combination pliers Inomic 180mm	Combination pliers Inomic 180mm	33260