

Пульт дистанционного управления универсальный

ДУ-25 Р

TYPE: **D001B001**


 **SONY**



Описание:

Перечень заменяемых моделей:

RM-640, RM-656A, RM-677, RM-677C, RM-687, RM-687C, RM-689, RM-821, RM-827T, RM-827S, RM-834, RM-836, RM-839, RM-841, RM-845P, RM-845S, RM-849S, RM-849T, RM-857, RM-857A, RM-858, RM-861, RM-869, RM-870, RM-873, RM-878, RM-880, RM-883, RM-886, RM-887, RM-889, RM-934, RM-952, RM-953, RM-969, RM-980, RM-993, RM-W100, RM-W101, RM-Y116, RM-Y133, RM-Y145, RM-Y145A, RM-Y145C, RM-Y145P, RM-Y155, RM-Y171, RM-Y173, RM-Y183, RM-GA002, RM-GA005, RM-YA005, RM-191A, RM-2092, RM-2910, 33S-001, 33S-002, RM-008, RM-009, RM-010, RM-021, RC670-1, RM-827B, RM-768, RM-791, RM-816, RM-817, RM-826, RM-827B, RM-830, RM-831, RM-832, RM-833, RM-837, RM-838, RM-842, RM-827C, RM-859, RM-862, RM-871, RM-881, RM-890, RM-891, RM-892, RM-893, RM-916, RM-921, RM-933, RM-936, RM-938, RM-940, RM-943, RM-945, RM-946, RM-954, RM-955, RM-956, RM-961, RM-963, RM-972, RM-991, RM-992, RM-W103, RM-W104, RM-Y101, RM-Y146A, RM-Y172, RM-2918



Сеть магазинов

КВАРЦ

Радиодетали и электронные компоненты

107023, Москва, ул. Буженинова, д. 16

телефон: (495) 963-6120

факс: (495) 963-4994

e-mail: quartz1@quartz1.ru

111123, Москва, шоссе Энтузиастов, д31

телефон/факс: (495) 788-8899 *многоканальный*

e-mail: mqz@quartz1.ru