# JUUSUL

## **Digital Timer** H5CX-D-N

## Ultra-compact Timer Provides Advanced Functions and Security Settings.

#### **Basic Features**

- Short body with depth of only 59 mm (for 24-VAC / 12 to 24-VDC Models with Screw Terminals). \*
- Character height of 12 mm for better readability (on models with 4 digits).
- The present value display characters can be switched between red, green, and orange. \*2

#### Safety and Reliability

- Power supply circuit and input circuits are isolated for safety and reliability. \*3
- New set value limit and output counter functions have been added.

#### Other Features

- Front Panel can be changed to white or light gray. \*4
- · Models with instantaneous contact output added to the series.
- For 100 to 240 VAC Models with Screw Terminals 78 mm, Models with Sockets: 63.7 mm \*1. (case dimension). The H5CX-A11, H5CX-L8 and H5CX-B Timers have only red characters.
- Specifications: 100 to 240 VAC Replacement Front Panels sold separately

### Features

### **Basic Features**

### **Ultra Short Body**

The body depth has been greatly reduced. Helps in making thinner control panels. (Models with Screw Terminals)

24-VAC / 12 to 24-VDC Models with Screw Terminals: 59 mm 100 to 240-VAC / VDC Models with Screw Terminals: 78 mm \* Models with Sockets: 63.7 mm (case dimension)

- \* The shortest body for a timer with isolated power supply and input circuits and a maximum ambient temperature of 55°C (according to OMRON investigation in June 2009).



New models models

### Easier to Read

For better readability, the character height for the present value display is 12 mm (on models with 4 digits), the largest class in the industry. The wide viewing angle and brightness provide excellent visibility. The number of display segments has also been increased to make settings easier to understand, and the present value display can be switched between red, green and orange so that output status can be seen from a distance.

Model with 4 Digits Model with 6 Digits





(Display example)

Note: The H5CX-A11 and H5CX-L8 Timers have only red characters.

### The Easiest Operation

Operation is simplified by the Up/Down Keys for each digit on 4-digit models and Up Keys for each digit on 6-digit models.





Safety and Reliability

### Isolated Power Supply and Input Circuits <sup>\*1</sup>

Power supply circuit and input circuits are isolated for safety and reliability.

Previous non-isolated timers had wiring restrictions and could be damaged if wired incorrectly. The New H5CX removes these worries.



\*1. New Models (H5CX--N) with 100 to 240-VAC specifications.

### Set Value Limit

You can set an upper limit for the set value to prevent unexpected operation of output devices caused by setting mistakes.



### **Output Counter**

The output counter counts the number of times the output turns ON (alarm display, count monitoring, count in increments of 1,000). This counter is useful in managing the service life of the Timer or the load.

### Other Features

### **Change the Front Panel Color**

The Front Panel can be replaced with an optional Front Panel (order separately) with a different color to match the installation site. Select from black, white, and light gray.



#### Models with Instantaneous Contact Output

Models with instantaneous contact outputs have been added to the lineup for use with self-holding circuits and as auxiliary relays. These models are also convenient when replacing analog timers.

### Model Number Structure

#### **Universal NPN/PNP Input**

DC 2-wire sensors can be connected for a wide range of input devices.

## Waterproof, Dust-proof Structure (UL508 Type 4X and IP66)

Worry-free application is possible in locations subject to water. **Note:** When the Y92S-29 Waterproof Packing is used.

#### **Key Protection**

Select from any of seven protection patterns. Use the best one for the application.

#### **New Modes**

Modes, such as a stopwatch mode (Mode S), have been added. Select any of 15 modes.



### Model Number Legend (Not all possible combinations of functions are available.) H5CX-

### $\frac{1}{1}$ $\frac{2}{2}$ $\frac{3}{3}$ $\frac{4}{4}$ $\frac{5}{5}$

#### 1. Type Classifier

Symbol	Meaning
А	Standard type
В	6-digit type
L	Economy type

### 4. Output type

Symbol	Meaning
None	Contact output (time-limit SPDT)
E	Contact output (time-limit SPDT + instantaneous SPDT) *
S	Transistor output

\* Can be used as a time-limit DPDT output.

## **Ordering Information**

### List of Models

#### 2. External Connections

Symbol	Meaning
None	Screw terminals
8	8-pin socket
11	11-pin socket

#### 3. Settings

Symbol	Meaning
None	One stage
W	Two stages

### 5. Supply voltage

Symbol	Meaning	
None	100 to 240 VAC 50/60 Hz	
D	12 to 24 VDC/24 VAC 50/60 Hz *	
The HECK RIMED N is sucilable only for 12 to 24 VDC		

The H5CX-BWSD-N is available only for 12 to 24 VDC.

Туре	Time specifications	Operating modes	External connections	Inputs	Outputs	Supply voltage	Models
					Contact output	100 to 240 VAC	H5CX-A-N
		Timer Mode A: Signal ON Delay I			(time-limit SPDT)	12 to 24 VDC/ 24 VAC	H5CX-AD-N
			Screw terminals		Transistar	100 to 240 VAC	H5CX-AS-N
		A-1: Signal ON Delay I A-2: Power ON Delay I A-3: Power ON Delay II		Signal, Reset,	output (SPST)	12 to 24 VDC/ 24 VAC	H5CX-ASD-N
		b: Repeat cycle 1		PNP inputs)	Contact output	100 to 240 VAC	H5CX-A11-N
	0.001 to 0.000 o	b-1: Repeat cycle 2 d: Signal OFF Delay E: Interval F: Cumulative Z: ON/OFF-duty-adjustable flicker S: Stopwatch	11 nin ooskat		(time-limit SPDT)	12 to 24 VDC/ 24 VAC	H5CX-A11D-N
	0.001 to 99.99 s		TT-pill Socket		Transistor output (SPST)	100 to 240 VAC	H5CX-A11S-N
	0.1 to 999.9 s 1 to 9999 s					12 to 24 VDC/ 24 VAC	H5CX-A11SD-N
	1 to 999.9 min 1 to 999.9 min 1 to 9999 min 1 min to 99 h 59 min 0.1 to 999.9 h 1 to 9999 h	Twin Timer Mode         0.1 to 999.9 min         1 to 999.9 min         1 min to 99 h 59 min         1 to 999.9 h         1 to 999.9 h         1 to 999.9 h         Timer Mode         A-2: Power ON Delay I         b: Repeat cycle 1         E: Interval         Z: ON/OFF-duty-adjustable flicker         Twin Timer Mode         to 999.9 h	Signal, Reset (NPN inputs) 8-pin socket None	Contact output	100 to 240 VAC	H5CX-L8-N	
				Signal, Reset (NPN inputs)	(time-limit SPDT)	12 to 24 VDC/ 24 VAC	H5CX-L8D-N
					Transistor output (SPST)	100 to 240 VAC	H5CX-L8S-N
						12 to 24 VDC/ 24 VAC	H5CX-L8SD-N
H5CX-L				None	Contact output (time-limit SPDT + instantaneous SPDT) Models with instantaneous contact outputs	100 to 240 VAC	H5CX-L8E-N
						12 to 24 VDC/ 24 VAC	H5CX-L8ED-N
H5CX-B	0.01 to 9999.99 s 1 s to 99 h 59 min 59 s 0.1 to 99999.9 min 0.1 to 99999.9 h	A: Signal ON Delay I F-1: Cumulative	Screw terminals	Signal, Reset, Gate (NPN/ PNP inputs)	Transistor output (DPST)	12 to 24 VDC	H5CX-BWSD-N

Note: 1. The functions that are provided depend on the model. Check detailed specifications before ordering.
2. Refer to page 33 and later for information on H5CX-B Timers (6-digit display).

### **Accessories (Order Separately)**

### **Front Panels (Replacement Parts)**

Models	Color	Applicable Timers	Page
Y92P-CXT4G	Light gray (5Y7/1)		
Y92P-CXT4S	White (5Y9.2 / 0.5)	Four-digit models	12
Y92P-CXT4B	Black (N1.5)		

Note: 1. You can change the color of the front panel when mounting the Timer. The Timer is shipped with a black (N1.5) Front Panel. 2. "TIMER" is printed on the front of Replacement Front Panels.

#### Soft Cover

Page	Remarks	Models
12		Y92A-48F1
		Y92A-48F1

### **Hard Cover**

Models	Remarks	Page
Y92A-48		12

#### **Flush Mounting Adapter**

Models	Remarks	Page
Y92F-30	Included with models with terminal blocks.	
Y92F-45	Use this Adapter to install the Timer in a cutout previously made for a DIN 72 x 72 mm device (panel cutout: 68 x 68 mm).	12

### Waterproof Packing

Models	Remarks	Page
Y92S-29	Included with models with terminal blocks.	12

### **Connection Sockets**

Models	Туре	Connectable Timers	Remarks	Page
P2CF-08	Front Connecting Socket			
P2CF-08-E	Front Connecting Socket (Finger-safe Type)	H5CX-L8□	Round crimp terminals cannot be used on Finger-safe Sockets. Use forked crimp terminals.	
P2CF-11	Front Connecting Socket			13
P2CF-11-E	Front Connecting Socket (Finger-safe Type)	H5CX-A11	Round crimp terminals cannot be used on Finger-safe Sockets. Use forked crimp terminals.	
P3G-08	Pools Connecting Cooket	H5CX-L8	A Y92A-48G Terminal Cover can be used with the	
P3GA-11	Back Connecting Socket	H5CX-A11	Socket to create a finger-safe construction.	

### Terminal Covers for P3G-08 and P3GA-11 Back-connecting Sockets

Models	Remarks	Page	
Y92A-48G		14	

### H5CX-A -N/-L -N

### H5CX-A -N/-L -N Digital Timers

- Switch the display color\* between red, green, and orange to see the output status from a distance.
- Up/Down Keys for each digit enable easy operation.
- Cyclic control is easy with the Twin Timer and Variable ON/OFF Duty modes.
- \* Not supported by the H5CX-A11 or H5CX-L8 .

### Specifications

### Ratings



Inrush current will flow for a short time when the power supply is turned ON Inrush Current (Reference Values)

Voltage		Applied voltage	Inrush current (peak value)	Time	
	100 to 240 VAC	264 VAC	5.3 A	0.4 ms	
		26.4 VAC	6.4 A	1.4 ms	
	12 10 24 VDC/24 VAC	26.4 VDC	4.4 A	1.7 ms	

\*3. The display is lit only when the power is ON. Nothing is displayed when power is OFF.



### H5CX-A -N/-L -N

### Characteristics

Accuracy of operating time and setting error (including temperature and voltage influences)		Power-ON start: ±0.01% ±50 ms max. (See note 1.) Signal start: ±0.005%±0.03 ms max. (See note 1.) Signal start for transistor output model: ±0.005%±3 ms max. (See note 1 and 2.) If the set value is within the sensor waiting time at startup the control output of the H5CX will not turn ON until the sensor waiting time passes. <b>Note: 1.</b> The values are based on the set value. <b>2.</b> The value is applied for a minimum pulse width of 1 ms.
Insulation resis	tance	$100\ M\Omega$ min. (at 500 VDC) between current-carrying terminal and exposed non-current-carrying metal parts, and between non-continuous contacts
Dielectric strength		2,000 VAC, 50/60 Hz for 1 min between current-carrying metal parts and non-current-carrying metal parts 2,000 VAC, 50/60 Hz for 1 min between power supply and input circuits for H5CX-A11-N/-A11S-N 1,000 VAC, 50/60 Hz for 1 min between control output, power supply, and input circuits for H5CX-□SD-N 2,000 VAC, 50/60 Hz for 1 min between control output, power supply, and input circuits for other models 1,000 VAC, 50/60 Hz for 1 min between non-continuous contacts
Impulse withstand voltage		3 kV (between power terminals) for 100 to 240 VAC, 1 kV for 24 VAC/12 to 24 VDC 4.5 kV (between current-carrying terminal and exposed non-current- carrying metal parts) for 100 to 240 VAC 1.5 kV for 24 VAC/12 to 24 VDC
Noise immunity	,	$\pm 1.5$ kV (between power terminals) and $\pm 600$ V (between input terminals), square-wave noise by noise simulator (pulse width: 100 ns/ 1 $\mu s,$ 1-ns rise)
Static immunity	,	Malfunction: 8 kV Destruction: 15 kV
Vibration	Destruction	10 to 55 Hz with 0.75-mm single amplitude each in three directions for 2 h each
resistance Malfunction		10 to 55 Hz with 0.35-mm single amplitude each in three directions for 10 min each
Shock Destruction		300 m/s <sup>2</sup> in three directions, three cycles
resistance	Malfunction	100 m/s <sup>2</sup> in three directions, three cycles
Life Mechanical		10,000,000 operations min. (under no load at 18,000 operations/h and ambient temperature of 23°C)
expectancy	Electrical	100,000 operations min. (5 A at 250 VAC, resistive load at 1,800 operations/h and ambient temperature of 23°C) *
Weight		Approx. 115 g (Timer only)

\* Refer to Life-test Curve.

## Life-test Curve (Reference Values)



A maximum current of 0.15 A can be switched at 125 VDC ( $\cos\phi = 1$ ) and a maximum current of 0.1 A can be switched if L/R is 7 ms. In both cases, <u>a</u> life of 100,000 operations can be expected.

6

### **Applicable Standards**

Approved safety standards	UL508/Listing, UL50 Type 4X for indoor use (enclosure rating), CSA C22.2 No. 14 <sup>*1</sup> , conforms to EN61812-1 (Pollution degree 2/overvoltage category III) B300 PILOT DUTY 1/4 HP 120 VAC, 1/3 HP, 240 VAC, 5 A resistive load VDE0106/P100 CCC: Pollution degree 2, Overvoltage category II <sup>*2</sup>		
EMC	(EMI) Emission Enclosure: Emission AC mains: (EMS) Immunity ESD: Immunity RF-interference: Immunity Conducted Disturbance: Immunity Burst: Immunity Surge: Immunity Voltage Dip/Interruption:	EN61812-1 EN55011 Group 1 class A EN55011 Group 1 class A EN65011 Group 1 class A EN61812-1 EN61000-4-2: 6 kV contact discharge (level 2) 8 kV air discharge (level 3) EN61000-4-3: 10 V/m (Amplitude-modulated, 80 MHz to 1 GHz) (level 3); 10 V/m (Pulse-modulated, 900 MHz 5 MHz) (level 3) EN61000-4-6: 10 V (0.15 to 80 MHz) (level 3) EN61000-4-6: 10 V (0.15 to 80 MHz) (level 3) EN61000-4-4: 2 kV power-line (level 3); 1 kV I/O signal-line (level 4) EN61000-4-5: 1 kV line to lines (power and output lines) (level 3); 2 kV line to ground (power and output lines) (level 3) EN61000-4-11: 0.5 cycle, 100% (rated voltage)	

 The following safety standards apply to models with sockets (H5CX-A1 cUL (Listing): Applicable when an OMRON P2CF (-E) Socket is used. cUR (Recognition): Applicable when any other socket is used.
 Excluding the H5CX-ASD-N/-A11SD-N/-L8SD-N. ts (H5CX-A11□ or H5CX-L8□).

### **I/O Functions**

For details, refer to the timing charts on page 20 and page 29.

	Start signal	Normally functions to start timing. In modes A-2 and A-3, disable timing. In mode S, starts and stops timing.
Inputs *1	Reset	<ul> <li>Resets present value. (In elapsed time mode, the present value returns to 0; in remaining time mode, the present value returns to the set value.)</li> <li>Count inputs are not accepted and control output turns OFF while reset input is ON.</li> <li>Reset indicator is lit while reset input is ON.</li> </ul>
	Gate *2	Disables timing. (If a reset occurs while the gate input is ON, a reset will be performed.)
Outputs	Control output (OUT)	Outputs take place according to designated operating mode when timer reaches corresponding set value.

\*1. The H5CX-L8E<sup>O</sup> does not have an input.
\*2. The H5CX-L<sup>O</sup> does not have a gate input.

### **Response Delay Time When Resetting (Transistor Output)**

The following table shows the delay from when the reset signal is input until the output is turned OFF.

(Reference	va	lue)	)
------------	----	------	---

Minimum reset signal width	Output delay time
1 ms	0.8 to 1.2 ms
20 ms	15 to 25 ms

### H5CX-A -N/-L -N

### Connections

### **Block Diagram**



Note: Basic insulation is provided between the power supply circuit and the input circuits. However, basic insulation is not provided in the H5CX-D-N.

### **Terminal Arrangement**

Confirm that the power supply meets specifications before use.



### Input Circuits Signal, Reset, and Gate Input

No-voltage Inputs (NPN Inputs)

Voltage Inputs (PNP Inputs)





### **Input Connections**

The inputs are no-voltage (closed or open) inputs or voltage inputs except for the H5CX-L8. (The inputs of the H5CX-L8 are no-voltage inputs only. The H5CX-L8E does not have an input.)

### **No-voltage Inputs (NPN Inputs)**



Note: The DC voltage must be 30 VDC max.

#### Voltage Inputs (PNP Inputs) The inputs of the H5CX-L8 are no-voltage inputs only.

#### **No-contact Input (NPN Transistor)**



#### Note: Operate with transistor OF

### Voltage Input Signal Levels

High level (Input ON): 4.5 to 30 VDC	
Low level (Input OFF): 0 to 2 VDC	

Note: 1. The DC voltage must be 30 VDC max. 2. Input resistance: Approx. 4.7  $k\Omega$ 





**Contact Input** 

### H5CX-A -N/-L -N

### Nomenclature



80000

**80 0 0 0** 

### **Dimensions with Flush Mounting Adapter**

#### H5CX-A-N/-AS-N (Provided with Adapter and Waterproof Packing)



#### H5CX-AD-N/-ASD-N (Provided with Adapter and Waterproof Packing)





#### H5CX-A11 -N (Adapter and Waterproof Packing Ordered Separately)



7.5

84.8

Panel Cutouts Panel cutouts areas shown below. (according to DIN43700). -60 min.-45+0.6 45<sup>+</sup>0 15 min. 60 min. 1 ŧ Note: 1. The mounting panel thickness should be 1 to 5 mm. 2. To allow easier operation, it is recommended that Adapters be mounted so that the gap between sides with hooks is at least 15 mm (i.e., with the panel cutouts separated by at . least 60 mm). 3. It is possible to mount Timers side by side, but only in the direction without the hooks. (However, if Timers are mounted side by side, water resistance will be lost.) n Units mounted side-by-side A A=(48n-2.5) +1 With Y92A-48F1 attached. A={48n-2.5+(n-1)×4}-1 With Y92A-48 attached.  $A = (51n - 5.5)^{+1}_{-0}$ 

#### Dimensions with Front Connecting Socket



### Accessories (Order Separately)

#### Note:

Depending on the operating environment, the condition of resin products may deteriorate, and may shrink or become harder. Therefore, it is recommended that resin products are replaced regularly.

### Front Panel (Replacement Part)

You can change the color of the front panel when mounting the Timer. The Timer is shipped with a black (N1.5) Front Panel.

#### Y92P-CXT4S

Cover for Timer with 4 Digits White (5Y9.2/0.5)

#### Y92P-CXT4G

Cover for Timer with 4 Digits Light gray (5Y7/1)

#### Y92P-CXT4B

Cover for Timer with 4 Digits Black (N1.5)

#### **Replacement Method**



The Front Panel is attached to the Terminal with tabs in four locations. To remove the Front Panel, open the tabs and pull the Front Panel forward. To attach the Front Panel, press it onto the Timer so that all four tabs lodge into the groves on the

body of the Timer.

Soft Cover Y92A-48F1

### Hard Cover Y92A-48





#### Protecting the Timer in Environments Subject to Oil

The H5CX's panel surface is water-resistive (IP $\square$ 6, UL Type 4X) and so even if drops of water penetrate the gaps between the keys, there will be no adverse effect on internal circuits. If, however, there is a possibility of oil being present on the operator's hands, use the Soft Cover. The Soft Cover ensures protection equivalent to IP54 against oil. Do not, however, use the H5CX in locations where it would come in direct contact with oil.

### Flush Mounting Adapter Y92F-30 Y92F-45

Order the Flush Mounting Adapter separately if it is lost or damaged. Note: A Flush Mounting Adapter is included with screw terminals.



Use this Adapter to install the Timer in a cutout previously made for a DIN 72 x 72 mm device (panel cutout: 68 x 68 mm).



### Waterproof Packing



Order the Waterproof Packing separately if it is lost or damaged. The Waterproof Packing can be used to achieve IP66 protection.

The Waterproof Packing will deteriorate, harden, and shrink depending on the application environment. To ensure maintaining the IP $\Box$ 6, UL Type 4X waterproof level, periodically replace the Waterproof Packing. The periodic replacement period will depend on the application environment. You must confirm the proper replacement period. Use 1 year or less as a guideline. If the Waterproof Packing is not replaced periodically, the waterproof level will not be maintained.

It is not necessary to mount the Waterproof Packing if waterproof construction is not required.

### Connection Sockets Front-connecting Sockets



Note: Round crimp terminals cannot be used on Finger-safe Sockets. Use forked crimp terminals.

#### **Back-connecting Sockets**

Model	Dimensions	Terminal arrangement and internal connections
P3G-08	45 45 45 45 45 45 45 45 45 45	(Bottom View)
P3GA-11	+27 dia + 45 + 25.6 4.5 + 6.2	(Bottom View)

Note: A Y92A-48G Terminal Cover can be used with the Socket to create a finger-safe construction.

### H5CX-A -N/-L -N

#### Terminal Covers for P3G-08 and P3GA-11 Back-connecting Sockets



Note: The Terminal Cover can be used with a Back-mounting Socket (P3G-08 or P3GA-11) to create a finger-safe construction.

### **Optional Products for Track Mounting**



Note: Order Spacers in increments of 10.

### **Operating Procedures**

### Setting Procedure Guide

Settings for Timer Operation \*

Use the following settings.

### Settings for Twin Timer Operation \*

Refer to page 25.

\* It is not necessary to mount the Waterproof Packing if waterproof construction is not required.

### **Operating Procedures for Timer Function**



After making DIP switch settings for basic operation, advanced functions can be added using the operation keys on the front panel. Refer to Step2 on page 16 for details.

### H5CX-A□-N/-L□-N Timer

Ste	ep2 Settings	that cannot	t be performed with the DIP switch are performed with the operation	on keys.	
• Cha	nge to Function S	Setting Mode			
Г	Power ON		For details on operations in run mode, refer to page 19.		
Ľ		MODE 3 s min. *1			
ſ	Run mode	Functio	on setting mode		
_	(	MODE 3 s min. *2			
**	<ol> <li>If the mode is switc</li> <li>Changes made to s Also, when settings</li> </ol>	hed to the funct settings in functi are changed, t	tion setting mode during operation, operation will continue. on setting mode are enabled for the first time when the mode is changed to run mode. he timer is reset (time initialized and output turned OFF).		
			The characters displayed in reverse video are the default settings. When performing settings with operation keys only, set pin1 of the DIP switch to OFF (factory If pin 1 of the DIP switch is set to ON, the setting items indicated in will not be displayed	setting).	
	Elme	Time range	■ Set the time range using the 🚖 📚 keys.		
			(	Time Range L Display	Set Value
	MODE		➡ For details, refer to the Time Range List.	• • • • • • • • • • • • • • • • • • •	0.01 s to 99.99 s (default setting)
	Limm	Timer mode	■ Set the timer mode using the 🚖 😒 keys.	• • • • • • • • •	0.1 s to 999.9 s
			(UP) ↔ down ↔ (UP) (DOWN)	• • • • • • • • • • • • • • • • • • •	1 s to 9999 s
		1	<ul> <li>Set the output mode using the  keys.</li> </ul>	• •:• • • • • • • • • • • • • • • • • •	0 min 01 s to 99 min 59 s
	oüt m	Output modes	$\bigcirc \blacksquare \leftrightarrow \exists \cdot   \leftrightarrow \exists \cdot 2 \leftrightarrow \exists \cdot 3 \leftrightarrow b \leftrightarrow b \cdot   \leftrightarrow d \leftrightarrow \exists \leftrightarrow \exists \leftrightarrow z \leftrightarrow 5 \leftrightarrow 2 \leftrightarrow 5 \leftrightarrow 2 \to 5 \leftrightarrow 2 \to 5 \leftrightarrow 2 \to 5 \to$	• • • • • • •	0.1 min to 999.9 min
	MODE	I	<ul> <li>(A) (A-1) (A-2) (A-3) (b) (b-1) (d) (E) (F) (Z) (S)</li> <li>Note: Only modes A-2 b, E, and Z can be selected for models with instantaneous contact outputs.</li> </ul>	• • • • m	1 min to 9999 min
			• Set each digit for the output time using the corresponding 🙁 keys.	: h	0 h 01 min to 99 h 59 min
mode	OCLM Hald	Output time	→ <u>₩ăL d</u> / <u>D.D</u> /~ <u>99.99</u> → (Output hold) (0.01s) (99.99s)	• • • • <sup>h</sup>	0.1 h to 999.9 h
i setting	MODE		(If the output time is set to 0.00, <b>Hall d</b> is displayed.) <b>Note:</b> Displayed for modes A, A-1, A-2, A-3, b, b-1 and S only.	<b></b> h	1 h to 9999 h
<sup>-</sup> unctior	IFLE	Input signal	<ul> <li>Set the input signal width using the  keys.</li> </ul>	• • • • • • • • • • • • • • • • • • •	0.001 s to 9.999 s
	20~S		(20ms) (1ms)		
	MODE		Note: Not displayed for models with instantaneous contact outputs.		
	imod	NPN/PNP input	■ Set the NPN/PNP mode using the 😒 keys.		
			(NPN input) (PNP input)		
	MODE		Note: Only displayed for the H5CX-A□ and H5CX-A11□.		
	[lolr	Display color	■ Set the display color using the 🔿 😒 keys.		
			(Red) (Green) (Orange) (Red-green) (Green-red) (Red-orange) (Orange-red) (Green-orange) Note: Displayed only for models with terminal screws (H5CX-A□).	→ ǎ-Ĺ ← (Orange-green)	
	- δt md	Instantaneous/ time-limit	<ul> <li>Set the function (instantaneous or time-limit operation) for the instantaneous output ( using the</li></ul>	(output 1)	
<b></b>			(Instantaneous) (Time-limit) Note: Displayed only for models with instantaneous contact outputs.		
From n	ext page To next page				

16



### Explanation of Functions Operating Procedures for Timer Function

Items marked with stars ( $\star$ ) can be set using the DIP switch.

#### Time Range (とこって)★

Set the range to be timed in the range 0.001 s to 9,999 h. Settings of type ---- h (9,999 h) and ---- min (9,999 min) cannot be made with the DIP switch. Use the operation keys if these settings are required.

#### Timer Mode (とこゐゐ)★

Set either the elapsed time (UP) or remaining time (DOWN) mode. In UP mode, the elapsed time is displayed, and in DOWN mode, the remaining time is displayed.

#### Output Mode (るじとっ)★

Set the output mode.

The possible settings are A, A-1, A-2, A-3, b, b-1, d, E, F, Z and S. Only output modes A, A-2, E, and F can be set using the DIP switch. Use the operation keys if a different setting is required.

(For details on output mode operation, refer to "Timing Charts" on page 20.)

#### Output Time (atim)

When using one-shot output, set the output time for one-shot output (0.01 to 99.99 s).

One-shot output can be used only if the selected output mode is A, A-1, A-2, A-3, b, b-1 or S.

If the output time is set to 0.00, **Hald** is displayed, and the output is held.

#### Input Signal Width (ごドしと) \*

Set the minimum signal input width (20 ms or 1 ms) for signal, reset, and gate inputs.

The same setting is used for all external inputs (signal, reset, and gate inputs).

If contacts are used for the input signal, set the input signal width to 20 ms.

Processing to eliminate chattering is performed for this setting.

#### NPN/PNP Input Mode (แักเอ็ส)

Select either NPN input (no-voltage input) or PNP input (voltage input) as the input format.

Set an NPN input when using a 2-wire sensor.

For details on input connections, refer to "Input Connections" on page 9.

### Display Color (LoLr)

### (Terminal block model: H5CX-A only)

Set the color used for the present value.

	Output OFF	Output ON
rE9	Red (	fixed)
űr a	Green	(fixed)
٥rű	Orange	e (fixed)
r-6	Red	Green
5	Green Red	
r-õ	Red	Orange
<u>a</u> -r	Orange Red	
ũ-ă	Green Orange	
õ-ũ	Orange Green	

#### Key Protect Level (\* 3Pt)

Set the key protect level. Refer to "Key Protect Level" on page 32.

#### Instantaneous/Time-limit (at ad)

Set the contact output to time-limit SPDT + instantaneous SPDT or time-limit SPDT operation.

#### Set Value Upper Limit (5L - H)

Set the upper limit for the set value when it is set in Run Mode. The limit can be set to between 1 and 9999. This setting does not apply to the ON duty in Z mode.

#### Output ON Count Alarm Set Value $(\tilde{a}_{2} - \tilde{B})$

Set the alarm value for the output ON count.

The limit can be set to between  $\underline{0} \times 1000$  (0 times) and  $\underline{9999} \times 1000$  (9,999,000 times). Only the underlined values are set. The alarm will be disabled if 0 is set.

If the total ON count of the output exceeds the alarm set value,  $\xi \exists$  will be displayed on the Timer to indicate that the output ON count alarm value was exceeded. Refer to "**Self-diagnostic Function**" on **page 32** for information on the  $\xi \exists$  display.

## ON Count Alarm Set Values for Outputs 1 and 2 (OUT1 and OUT2) ( $\delta \alpha R$ and $\delta \alpha R$ )

Set the ON count alarm values for the outputs 1 and 2. The limit can be set to between  $0 \times 1000$  (0 times) and  $9999 \times 1000$  (9,999,000 times). Only the underlined values are set. The alarm will be disabled if 0 is set.

If the total ON count of instantaneous output 1 or 2 exceeds the alarm set value,  $\mathcal{E}$  will be displayed on the Timer to indicate that the output ON count alarm value was exceeded. Refer to "**Self-diagnostic Function**" on **page 32** for information on the  $\mathcal{E}$  3 display.

#### Output ON Count Monitor Value (an-L)

The monitor value is only displayed. It cannot be set. The output ON count will be 1,000 times the displayed value.

## ON Count Monitor Values for Outputs 1 and 2 (OUT1 and OUT2) (an IC and and C)

The monitor value for output 1 or 2 is only displayed. It cannot be set. The output ON count will be 1,000 times the displayed value.

### Operation in Run Mode Operating Procedures for Timer Function



#### **Present Value and Set Value**

These items are displayed when the power is turned ON. The present value is displayed in the main display and the set value is displayed in the sub-display.

The values displayed will be determined by the settings made for the time range and the timer mode in function setting mode.

#### Present Value and ON Duty Ratio (Output Mode = Z)

The present value is displayed in the main display and the ON duty ratio is displayed in the sub-display. Set the ON duty ratio used in ON/ OFF-duty-adjustable flicker mode (Z) as a percentage.

The output accuracy will vary with the time range, even if the ON duty ratio setting is the same. Therefore, if fine output time adjustment is required, it is recommended that the time range for the cycle time is set as small as possible.

Examples: 1. When Time Range = - - - s (9999 s)

$$20(s) \ge \frac{31(\%)}{100} = 6.2(s)$$

Rounded off to the nearest integer (because of the time range setting)  $\rightarrow$  ON time = 6 s

2. When Time Range = - -. - - s (99.99 s)

$$20.00(s) \times \frac{31(\%)}{100} = 6.200(s)$$

Rounded off to 2 decimal places (because of the time range setting)  $\rightarrow$  ON time = 6.20 s

If a cycle time is set, cyclic control can be performed in ON/OFF-dutyadjustable flicker mode simply by changing the ON duty ratio.

#### Present Value and Cycle Time (Output Mode = Z)

The present value is displayed in the main display and the cycle time is displayed in the sub-display. Set the cycle time.



### Timing Charts Operating Procedures for Timer Function

Models without Instantaneous Contact Outputs



diagram An Set

DOWN

Note: Output is instantaneous when setting is 0.

20



21

### H5CX-A -N/-L -N Timer



### H5CX-A -N/-L -N Timer

#### Mode S: Stopwatch (Timer resets when power comes ON.) **Basic operation Detailed operation** Po Powe Start signa Start signal input Timing Gate/Reset Gate/Reset 9999 Set time diagram UF Display iming (for elapsed \* RST flashes Set t time) The signal starts and stops timing. DOWN The display is held and timing is continued if the reset or gate input is received during timing operation. The timer resets if the reset or gate input is received Output when the timing operation is stopped. Note: Output is instantaneous when setting is 0. Models with Instantaneous Contact Outputs Either one-shot output or sustained output can be selected.



#### Note: H5CX-L8E -N Precautions

Set the Timer's set value before using the Timer in a self-holding circuit.

### H5CX-A -N/-L -N Timer

Mode E: Interval (Timer resets when power comes ON.)				
Basic operation	Detailed operation			
Power Timing	Power			
Time-limit	Reset Key			
Instantaneous output	Time-limit contacts, NC			
The Timer starts when the power comes ON or when the reset input goes OFF.	Time-limit			
<b>Note:</b> Output is not instantaneous when setting is 0.	Instantaneous contacts, NC			
	Instantaneous contacts, NO			
	t = Set time, Rt = Reset time (0.5 s min.), t – a < t (Indicates the time is less than the set time.)			
Mode Z: ON/OFF-duty adjustable flicker (Timer res	ets when power comes ON.)			
Basic operation	Detailed operation			
PowerTiming (cycle time)	Power			
Time-limit output	Reset Key			
Instantaneous output	Time-limit contacts, NC			
The Timer starts when the power comes ON or when the reset input goes OFF.	Time-limit contacts, NO			
Note: Normal output operation will not be possible if the set time is too short. Set the value to at least 100 ms.	Instantaneous contacts, NC			
	Instantaneous contacts, NO			

Note: H5CX-L8E□-N Precautions Set the Timer's set value before using the Timer in a self-holding circuit.

### Setting Procedure Guide Operating Procedures for Twin Timer Function



After making DIP switch settings for basic operation, advanced functions can be added using the operation keys on the front panel. Refer to **Step3** on **page 26** for details.

### H5CX-A□-N/-L□-N Twin Timer



26

### H5CX-A -N/-L -N Twin Timer



### Explanation of Functions Operating Procedures for Twin Timer Function

#### Items marked with stars ( $\star$ ) can be set using the DIP switch.

#### 

Set the time range for the OFF time in the range 0.000 s to 9,999 h. Only settings of type --.-- s (99.99 s), ----- s (999.9 s), ---- s (9,999 s), and -- min -- s (99 min 59 s) can be made with the DIP switch. Use the operation keys if another type of setting is required.

#### ON Time Range (antr)★

Set the time range for the ON time in the range 0.001 s to 9,999 h. Only settings of type --.-- s (99.99 s), ---- s (999.9 s), ---- s (9,999 s), and -- min -- s (99 min 59 s) can be made with the DIP switch. Use the operation keys if another type of setting is required.

#### Timer Mode (とこのの)★

Set either the elapsed time (UP) or remaining time (DOWN) mode. In UP mode, the elapsed time is displayed, and in DOWN mode, the remaining time is displayed.

#### ON/OFF Start Mode (と△とっ)★

#### Set the output mode.

Set either flicker OFF start or flicker ON start. (For details on output mode operation, refer to "Timing Charts" on page 29.)

#### Input Signal Width (こFLと)★

**Operation in Run Mode** 

Set the minimum signal input width (20 ms or 1 ms) for signal, reset, and gate inputs.

The same setting is used for all external inputs (signal, reset, and gate inputs).

If contacts are used for the input signal, set the input signal width to 20 ms.

Processing to eliminate chattering is performed for this setting.

### NPN/PNP Input Mode (แักเอี่ส)

Select either NPN input (no-voltage input) or PNP input (voltage input) as the input format. Set an NPN input when using a 2-wire sensor. The same setting is used for all external inputs. For details on input connections, refer to "Input Connections" on

page 9.

#### Display Color (Lalr) (Terminal black model: H5CX-A□ only)

Set the color used for the present value.

	Output OFF	Output ON
rEd	Red (	fixed)
<u>Gra</u>	Green	(fixed)
<u>ö</u> rű	Orange	e (fixed)
r-6	Red	Green
<u>6</u>	Green	Red
r-õ	Red	Orange
0-r	Orange	Red
G-ā	Green	Orange
ā-6	Orange	Green

#### Key Protect Level (\* 3Pt)

Set the key protect level. Refer to "Key Protect Level" on page 32.



#### Present Value and OFF Set Time

The present value is displayed in the main display and the OFF set time is displayed in the sub-display. Set the OFF time.

#### Present Value and ON Set Time

The present value is displayed in the main display and the ON set time is displayed in the sub-display. Set the ON time.

### **Timing Charts Operating Procedures for Timer Function** Models without Instantaneous Contact Outputs

The gate input is not included in the H5CX-L8 models.



### **Detailed operation**



**Basic operation** 



The status of the control output is reversed when time is up (ON at start). While the start signal is ON, the timer starts when the

Timing starts when the start signal goes ON.

power comes ON or when the reset input goes OFF. Note: Normal output operation will not be possible if

the set time is too short. Set the value to at least 100 ms (contact output type).

Mode toff-1: Flicker OFF start 2 (Timer does not reset when power comes ON.) **Basic operation** 





Note: Normal output operation will not be possible if the set time is too short. Set the value to at least 100 ms (contact output type).



### H5CX-A -N/-L -N Twin Timer

#### Mode ton-1: Flicker ON start 2 (Timer does not reset when power comes ON.) **Basic operation** Detailed operation Powe Power Start signal Start signal input Timing ON Timing -Timing OFF b Gate Output (a + b = OFF time) \* Start signal input is disabled during timing. Control outpu Timing starts when the start signal goes ON. The status of the control output is reversed when time is OFF time up (ON at start). UP Timing diagram While the start signal is ON, the timer starts when the ON power comes ON or when the reset input goes OFF. c Note: Normal output operation will not be possible if OFF time the set time is too short. Set the value to at least 100 ms (contact output DOWN ON ti type). 0

### Models with Instantaneous Contact Outputs



Power	Power		
Time-limit	Reset Key		
Instantaneous	Time-limit contacts, NC		
The Timer starts when the power comes ON or when the reset input goes OFF.	Time-limit contacts, NO		
Note: Normal output operation will not be possible if the set time is too short. Set the ON time and OFF time to at least 100 ms.	Instantaneous contacts, NC		
		t-on = ON time, t-off = OFF time, Rt = Reset time (0.1 s min.), t – a < t-off and t – b < t-on (Indicates the time is less than the set time.)	

Note: H5CX-L8E -N Precautions

Set the Timer's set value before using the Timer in a self-holding circuit.

### H5CX-A -N/-L -N

### **Timer/Twin Timer Selection Mode (Function Selection)**

Select whether the H5CX is used as a timer or a twin timer in timer/twin timer selection mode. The H5CX is also equipped with a DIP switch monitor function, a convenient function that enables the settings of the DIP switch pins to be confirmed using the front display.



\*1. When the mode is changed to timer/twin timer selection mode, the present value is reset and output turns OFF. Timing operation is not performed in timer/twin timer selection mode.

\*2. Setting changes made in timer/twin timer selection mode are enabled when the mode is changed to run mode. If settings are changed, the HC5X is automatically reset (present value initialized, output turned OFF).

### **Key Protect Level**

When the key-protect switch is set to ON, it is possible to prevent setting errors by prohibiting the use of certain operation keys by specifying the key protect level (KP-1 to KP-7).

The key protect indicator is lit while the key-protect switch is set to ON.



			Det	ails	
Level	Meaning	Changing mode*	Switching display during operation	Reset Key	Up/down key
KP-1 (default setting)	MODE MODE	Invalid	Valid	Valid	Valid
KP-2	MODE TO TO TO TO TO TO TO TO TO TO	Invalid	Valid	Invalid	Valid
KP-3	MODE CONTROL H5CX	Invalid	Valid	Valid	Invalid
KP-4	MODE	Invalid	Valid	Invalid	Invalid
KP-5	MODE COMPANY	Invalid	Invalid	Invalid	Invalid
KP-6	MODE	Invalid	Invalid	Valid	Valid
KP-7	MODE OTRACH H5CX	Invalid	Invalid	Invalid	Valid

\* Changing mode to Timer/Twin Timer Selection Mode or Function Setting Mode.

### **Self-diagnostic Function**

The following displays will appear if an error occurs.

Main display	Sub-display	Error	Output status	Correction method	Set value after reset
Ε	Not lit	CPU	OFF	Either press the reset key or reset the power supply.	No change
53	Not lit	Memory error (RAM)	OFF	Reset the power supply.	No change
53	SUm	Memory error EEPROM *1	OFF	Reset Key	Factory setting
E3 *2	No change	Output ON count alarm set value exceeded	No change	Reset Key	No change

\*1. This includes times when the life of the EEPROM has expired.

\*2. The normal display and £3 will appear alternately. When the Reset Key is pressed, £3 will no longer be displayed even if the alarm set value is exceeded. (Monitoring is possible, however, because the Timer will continue without clearing the output ON count.)

### Digital Timer H5CX-B -N

- H5CX Digital Timers with 6-digit Display, 2-stage Setting, and Forecast Output (DIN 48 x 48-mm)
- Times the daily operating hours of machinery and tools, predicting and notifying when maintenance is required.
- Easy-to-read backlit negative LCD with 6 digits (displays to 99999.9 h).
- The 2-stage settings and forecast output are ideal for maintenance applications.

## **Specifications**

### Ratings

	•	
Classificat	ion	Digital Timer with 6-digit display, 2-stage setting, and forecast output
	Power supply voltage	12 to 24 VDC
Ratings	Operating voltage fluctuation range	90% to 110% rated supply voltage
	Power consumption	Approx. 2.3 W *1
Mounting r	nethod	Flush mounting
External co	onnections	Screw terminals
Degree of	protection	IEC IP66, UL508 Type 4X (indoors) for panel front surface only and only when Y92S-29 Waterproof Packing is used
Digits		6 digits
Time range	9	0.01 s to 9999.99 s, 1 s to 99 h 59 min 59 s, 0.1 min to 99999.9 min, 0.1 h to 99999.9 h
Timer mod	e	Elapsed time (Up)
	Input signals	Signal, reset, gate
Inputs	Input method	$ \begin{array}{llllllllllllllllllllllllllllllllllll$
	Signal, reset, gate	Minimum input signal width: 1 or 20 ms (selectable, same for all input)
Reset syst	em	Power resets (only for A mode), external and manual reset
Power rese	et	Minimum power-opening time: 0.5 s (except for F-1 mode)
Reset volta	age	10% max. of rated supply voltage
Sensor wa	iting time	250 ms max. (Control output is turned OFF and no input is accepted during sensor waiting time.)
	Output modes	A, F-1
Outputs	Output type	Transistor output: NPN open collector, 100 mA at 30 VDC max. residual voltage: 1.5 VDC max. (Approx. 1 V) Leakage current: 0.1 mA max.
Display		7-segment, negative transmissive LCD; Present value: 10-mm-high characters, red Set value: 6-mm-high characters, green <sup>*2</sup>
Memory ba	ackup	EEPROM (overwrites: 100,000 times min.) that can store data for 10 years min.
Operating	temperature range	-10 to 55°C (-10 to 50°C if counters are mounted side by side) (with no icing or condensation)
Storage ter	mperature range	-25 to 70°C (with no icing or condensation)
Operating	humidity range	25 to 85%
Case color	•	Black (N1.5)
Attachmen	its	Waterproof packing, flush mounting adapter, unit label
<ol> <li>Inrush c Inrush C</li> </ol>	urrent will flow for a short tir Current (Reference Values)	me when the power supply is turned ON.

Voltage	Applied voltage	Inrush current (peak value)	Time
12 to 24 VDC	26.4 VDC	4.4 A	1.7 ms

\*2. The display is lit only when the power is ON.



### Characteristics

Accuracy of ope and setting error (including tempe voltage influence	rating time erature and es)	Power-ON start: ±0.01% ±50 ms max. (See note 1.) Signal start: ±0.005%±0.03 ms max. (See note 1.) Signal start for transistor output model: ±0.005%±3 ms max. (See note 1 and 2.) If the set value is within the sensor waiting time at startup the control output of the H5CX will not turn ON until the sensor waiting time passes. Note: 1. The values are based on the set value. 2. The value is applied for a minimum pulse width of 1 ms.
Insulation resista	ance	100 M $\Omega$ min. (at 500 VDC) between current-carrying terminal and exposed non-current-carrying metal parts
Dielectric streng	th	2,000 VAC, 50/60 Hz for 1 min between current-carrying metal parts and non-current-carrying metal parts 1,000 VAC, 50/60 Hz for 1 min between control output, power supply, and input circuit
Impulse withstar	nd voltage	<ol> <li>1.0 kV (between power terminals)</li> <li>1.5 kV (between current-carrying terminal and exposed non-current-carrying metal parts)</li> </ol>
Noise immunity		$\pm$ 480 V (between power terminals) and $\pm$ 600 V (between input terminals), square-wave noise by noise simulator (pulse width: 100 ns/1 µs, 1-ns rise)
Static immunity		Destruction: 15 kV Malfunction: 8 kV
Vibration	Destruction	10 to 55 Hz with 0.75-mm single amplitude in three directions for 2 h each
resistance	Malfunction	10 to 55 Hz with 0.35-mm single amplitude in three directions for 10 min each
Shock	Destruction	300 m/s <sup>2</sup> in three directions, three cycles
resistance	Malfunction	100m/s <sup>2</sup> in three directions, three cycles
Weight		Approx. 105 g (Timer only)

### **Applicable Standards**

Approved safety standards	UL508/Listing, CSA C22.2 No. 14, co Conforms to VDE0106/P100 (finger	onforms to EN 61812-1 (pollution degree 2/overvoltage category III) protection).
EMC	(EMI) Emission Enclosure: (EMS) Immunity ESD: Immunity RF-interference: Immunity Conducted Disturbance: Immunity Burst: Immunity Surge:	EN61812-1 EN55011 Group 1 class A EN61812-1 EN61000-4-2: 6 kV contact discharge (level 2) 8 kV air discharge (level 3) EN61000-4-3: 10 V/m (Amplitude-modulated, 80 MHz to 1 GHz) (level 3); 10 V/m (Pulse-modulated, 900 MHz 5 MHz) (level 3) EN61000-4-6: 10 V (0.15 to 80 MHz) (level 3) EN61000-4-6: 10 V (0.15 to 80 MHz) (level 3) EN61000-4-6: 10 V (0.15 to 80 MHz) (level 3) EN61000-4-5: 1 kV l/O signal-line (level 4) EN61000-4-5: 1 kV line to lines (power and output lines) (level 3); 2 kV line to ground (power and output lines) (level 3)

### I/O Functions

	Start signal		itarts timing.			
Inputs	Reset		<ul> <li>Resets present value. (The present value returns to 0.)</li> <li>Timing stops and control output turns OFF while reset input is ON.</li> <li>Reset indicator is lit while reset input is ON.</li> </ul>			
	Gate		Inhibits timer operation.			
	Forecast value	Control output (OUT2)	Turns ON when the present value reaches the set value.			
Outputo	setting	Forecast output (OUT1)	Turns ON when the present value reaches the forecast value.			
outputs	Absolute value	Control output 2 (OUT2)	Turns ON when the present value reaches set value 2.			
	setting	Control output 1 (OUT1)	Turns ON when the present value reaches set value 1.			

### Response Delay Time When Resetting (Transistor Output)

The following table shows the delay from when the reset signal is input until the output is turned OFF. (Reference value)

Minimum reset signal width	Output delay time
1 ms	0.8 to 1.2 ms
20 ms	15 to 25 ms

### Connections

### **Block Diagram**



### **Terminal Arrangement**



### Note: 1. The power supply and input circuit are not isolated. Terminals 1 and 6 are connected

Terminals 7 and 10 have the same reset function. The same function will be performed whichever terminal is connected. Terminals 7 and 10 are not connected internally, however, so do not use them for cross-over wiring.

-th

Reset Signal

> 8 9 10

Note: Operate with transistor ON

Gate

inputs

for

>0

6

## **Input Circuits**

### Signal, Reset, and Gate Input

No-voltage Inputs (NPN Inputs) Voltage Inputs (PNP Inputs)



#### Approx. 4.7 kΩ Internal INĈ circuit

#### **Transistor Output**

- · The transistor output of the H5CX is insulated from the internal circuitry by a photocoupler, so the transistor output can be used as both NPN and PNP output.
- The diode connected to the collector of the output transistor is used to absorb inverted voltage that is generated when an inductive load is connected to the H5CX.



### Input Connections

The inputs of the H5CX-B are no-voltage (short-circuit or open) inputs or voltage inputs.

Sensor

Voltage Output

No-voltage Inputs (NPN Inputs)

### **Open Collector**



### **No-voltage Input Signal Levels**

No-contact input	eq:short-circuit level (Transistor ON)
	Open level (Transistor OFF) • Impedance when OFF: 100 kΩ min.
Contact input	Use contacts which can adequately switch 5 mA at 10 V

### **Contact Input**



### **DC Two-wire Sensor**



#### Applicable Two-wire Sensor Leakage current: 1.5 mA max.

Switching capacity: 5 mA min.

 Residual voltage: 3.0 VDC max.

#### Operating voltage: 10 VDC

### Voltage Inputs (PNP Inputs)

### **No-contact Input (NPN Transistor)**



#### **Voltage Input Signal Levels**

High level (Input ON): 4.5 to 30 VDC Low level (Input OFF): 0 to 2 VDC The DC voltage must be 30 VDC max. Input resistance: Approx. 4.7  $k\Omega$ Note: 1. 2.

**No-contact Input (PNP Transistor)** 



#### **Contact Input**



### H5CX-B

### Nomenclature

#### **Display Section**

1. Key Protection Indicator (orange) Lit when the reset input or Reset Key is ON.

2. Control Output Indicator (orange) Forecast value setting Forecast output ON: OUT 1 is lit. Control output ON: OUT 2 is lit. Absolute value setting Control output 1 ON: OUT 1 is lit. Control output 2 ON: OUT 2 is lit.

- 3. Reset Indicator (orange) Lit when the reset input or Reset Key is ON.
- 4. Present Value Display (red) Character height: 10 mm If the time range is 0.0 min or 0.0 h, the decimal point flashes to indicate timing operation.
- 5. Time Unit Indicators (green)
- 6. Set Value (green)
- Character height: 6 mm 7. Set Value 1, 2 Indicator (green)







#### **Operation Key**

- 8. Mode Key
- (Changes modes and setting items)
- 9. Reset Key
- Resets present value and output.
- 10. Up Keys 1 to 6

## Switches



#### 12. DIP Switch



### Key Protect Level

When the Key-protect Switch is ON, key operations are prohibited according to the settings for DIP switch pins 6 to 8, thus preventing setting errors.

6mm

The Key-protect Switch can be turned ON and OFF while the power is ON.

The Key Protection Indicator is lit orange when the Key-protect Switch is ON.

If the key protect switch is ON, you will not be able to switch to Function Setting Mode.

### Dimensions

### **Digital Timers**

**Digital Timers** H5CX-BWSD-N (Flush Mounting Models)





Note: M3.5 terminal screw (effective length: 6 mm)

### **Dimensions with Flush Mounting Adapter** H5CX-BWSD-N (Provided with Adapter and Waterproof Packing)





### **Panel Cutouts**

Panel cutouts areas shown below. (according to DIN43700)

(unit: mm)



The mounting panel thickness should be 1 to 5 mm. To allow easier operation, it is Note: 1.

2. recommended that Adapters be mounted so that the gap between sides with hooks is at least 15 mm (i.e., with the panel cutouts separated by at least 60 mm). It is possible to mount Timers side by

3. side, but only in the direction without the hooks. However, if Timers are mounted side by side, water resistance will be lost.



### Accessories (Order Separately)

Refer to page 12 for details.

### OMRON

## **Operating Procedures**

### **DIP Switch Settings**

All functions are set using the DIP switch.

	Item	OFF	ON		Pin 1	Pin 2	Time range	
1	Time and a	Refer to the table on the		-	OFF	OFF	0.1 h to 99999.9 h	
2	Time range	rig	right.		ON	OFF	0.01 s to 9999.99 s	
3	Output modes	F-1 mode	A mode	-	OFF	ON	0 h 00 min 01 s to	
4	Input signal width	20 ms	1 ms				99 h 59 min 59 s	
5	NPN/PNP input mode	NPN (no-voltage)	PNP (voltage)	_	ON	ON	0.1 min to 99999.9 min	
6	Reset Key protection	Disabled	Enabled					_
7	Up Key protection	Disabled	Enabled			TIMER		1
8	Mode Key protection	Disabled	Enabled	_				]
No	<ul> <li>All the pins are faction.</li> <li>DIP switch setting turned ON again. and power-up.)</li> </ul>	ctory-set to OFF s are effective (Set the DIP sw	= when the powe vitch before ins	er is stallation				

### **Operation in Run Mode**

Set the digits for the set values using the corresponding 😒 Key.



### **Absolute Value Setting**



Each time the  $\fbox{(MOE)}$  Key is pressed, the sub-display will switch between set value 1 ("SET 1" is lit) and set value 2 ("SET 2" is lit).

### H5CX-B -N

### **Operation in Function Setting Mode**



### Explanation of Functions Absolute value setting/forecast value setting

#### (582m)

Set value 1 can be set as the forecast value setting ( $\bar{a}F5t$ ) or the absolute value setting (Rb5).

### Forecast Value Setting



- OUT1 (forecast output) turns ON when the present value reaches the forecast value.
   Forecast value = Set value - Forecast set value
- Note: <u>The forecast set value is used to set the deviation for the set value.</u>
  OUT2 (control output) turns ON when the present value reaches
- If the forecast set value  $\geq$  set value, OUT1 (forecast output) will turn
- ON as soon as timing starts.

### **Self-diagnostic Function**

The following displays will appear if an error occurs.

### **Absolute Value Setting**



- OUT1 (control output 1) turns ON when the present value reaches set value 1.
- OUT2 (control output 2) turns ON when the present value reaches set value 2.

Refer to pages 18 and 28 for information on other functions.

Main display	Sub-display	Error	Output status	Correction method	Set value after reset
Ε Ι	Not lit	CPU	OFF	Either press the Reset Key or reset the power supply.	No change
53	Not lit	Memory error (RAM)	OFF	Reset the power supply.	No change
53	SUm	Memory error EEPROM *1	OFF	Reset Key.	Factory setting
E3 "2	No change	Output ON count alarm set value exceeded	No change	Reset Key	No change

\*1. This includes times when the life of the EEPROM has expired.

\*2. The normal display and  $E_{\overline{J}}$  will appear alternately.

When the Reset Key is pressed, *E3* will no longer be displayed even if the alarm set value is exceeded. (Monitoring is possible, however, because the Timer will continue without clearing the output ON count.)

### **Timing Charts**

![](_page_39_Figure_2.jpeg)

Note: 1. The forecast value = set value - forecast set value

2. The forecast set value is used to set the deviation for the set value.

## Safety Precautions for All H5CX Series (Common)

### 

Do not allow pieces of metal, wire clippings, or fine metallic shavings or fillings from installation to enter the product. Doing so may occasionally result in electric shock, fire, or malfunction.

![](_page_40_Picture_4.jpeg)

Minor injury due to explosion may occasionally occur. Do not use the Timer where subject to flammable or explosive gas.

![](_page_40_Picture_6.jpeg)

Fire may occasionally occur. Tighten the terminal screws to the rated torque. H5CX terminals: 6.55 to 7.97 lb-in (0.74 to 0.90 N·m) P2CF Socket terminals: 4.4 lb-in (0.5 N·m)

![](_page_40_Picture_8.jpeg)

Minor injury due to electric shock may occasionally occur. Do not touch any of the terminals while power is being supplied. Be sure to mount the terminal cover after wiring.

![](_page_40_Picture_10.jpeg)

The life expectancy of the output relay varies considerably according to its usage. Use the output relay within its rated load and electrical life expectancy. If the output relay is used beyond its life

expectancy, its contacts may become fused or there may be a risk of fire. Also, be sure that the load current does not exceed the rated load current and when using a heater, be sure to use a thermal switch in the load circuit.

Minor electric shock, fire, or malfunction may occasionally occur. Do not disassemble, modify, or repair the Timer or touch internal components.

![](_page_40_Picture_14.jpeg)

### Precautions for Safe Use

· The panel surface of the H5CX is water-resistant (conforming to NEMA4, IP66, UL Type 4X (Indoor Use Only). To protect the internal circuits from water penetration through the space between the H5CX and operating panel, waterproof packing is included. Attach the Y92F-30 Adapter with sufficient pressure with the reinforcing screws so that water does not penetrate the panel.

![](_page_40_Figure_17.jpeg)

- When mounting the Timer to a panel, tighten the two mounting screws alternately, a little at a time, so as to keep them at an equal tightness. If the panel screws are tightened unequally, water may enter the panel.
- Store the Timer at the specified temperature. If the Time has been stored at a temperature of less than -10°C, allow the Time to stand at room temperature for at least 3 hours before use.
- Mounting the Timer side-by-side may reduce the life expectancies of internal components.
- Use the Timer within the specified ranges for the ambient operating temperature and humidity.
- · Do not use in the following locations:
  - · Locations subject to sudden or extreme changes in temperature.
- · Locations where high humidity may result in condensation.
- · Do not use the Timer outside of the rated ranges for vibration, shock, water exposure, and oil exposure.
- · Do not use this Timer in dusty environments, in locations where corrosive gasses are present, or in locations subject to direct sunlight.
- · Install the Timer well away from any sources of static electricity, such as pipes transporting molding materials, powders, or liquids.

- · Internal elements may be destroyed if a voltage outside the rated voltage range is applied.
- Be sure that polarity is correct when wiring the terminals.
- Separate the Timer from sources of noise, such as devices with input signals from power lines carrying noise, and wiring for I/O signals.
- · Do not connect more than two crimp terminals to the same terminal.
- Up to two wires of the same size and type can be inserted into a single terminals.
- Use the specified wires for wiring. Applicable Wires: AWG 18 to AWG 22, solid or twisted, copper.
- · Install a switch or circuit breaker that allows the operator to immediately turn OFF the power, and label it to clearly indicate its function
- When the Timer is operated with no-voltage input (NPN input), approximately 14 V is output from the input terminals. Use a sensor that contains a diode.

![](_page_40_Figure_36.jpeg)

- · Use a switch, relay, or other contact so that the rated power supply voltage will be reached within 0.1 seconds. If the power supply voltage is not reached quickly enough, the Timer may malfunction or outputs may be unstable.
- Use a switch, relay, or other contact to turn the power supply OFF instantaneously. Outputs may malfunction and memory errors may occur if the power supply voltage is decreased gradually.
- H5CX-A□-N/-L□-N: When changing the set value during a timing operation, the output will turn ON if the set value is changed as follows because of the use of a constant read-in system:

Elapsed time (UP) mode: Present value  $\geq$  Set value Remaining time (DOWN) mode: Elapsed time ≥ Set value (The

present value is set to 0.)

When in the remaining time mode, the amount the set value is changed is added to or subtracted from the present value. Operation with a set value of 0 will vary with the output mode. Refer to the timing charts on page 20.

H5CX-B□-N:

When changing the set value during a timing operation, the output will turn ON if the set value is changed as follows because of the use of a constant read-in system:

1. Forecast Value Setting

When the present value  $\geq$  the set value, OUT2 (control output) turns ON.

When the present value  $\geq$  the forecast value (forecast value = set value - forecast set value), OUT1 (forecast output) turns ON.

2. Absolute Value Setting When the present value  $\geq$  set value 2, OUT2 (control output 2) turns ON.

When the present value  $\geq$  the forecast value (forecast value = set value - forecast set value), OUT1 (control output 1) turns ON.

When the set value is 0, the output turns ON the moment the signal is input. The reset operation turns OFF the output.

- Do not use organic solvents (such as paint thinners or benzine), strong alkali, or strong acids. They will damage the external finish.
- Confirm that indications are working normally, including the backlight LED, and LCD. The indicator LEDs, LCD, and resin parts may deteriorate more quickly depending on the application environment, preventing normal indications. Periodic inspection and replacement are required.
- The waterproof packing may deteriorate, shrink, or harden depending on the application environment. Periodic inspection and replacement are required.

### Precautions for Correct Use

- H5CX models with a 24-VDC/12 to 24-VDC power supply use a transformer-free power supply method in which the power supply terminals are not isolated from the signal input terminals. If a nonisolating DC power supply is used, unwanted current paths may occasionally burn or destroy internal components depending on the wiring. Always check the wiring sufficiently before use.
- An inrush current of approx. 10 A will flow for a short time when the power supply is turned ON. If the capacity of the power supply is not sufficient, the Timer may not start. Be sure to use a power supply with sufficient capacity.
- Maintain voltage fluctuations in the power supply within the specified operating voltage range.
- When turning the power ON and OFF, input signal reception is possible, unstable, or impossible as shown in the diagram below.

![](_page_41_Figure_6.jpeg)

- To allow for the startup time of peripheral devices (sensors, etc.), the Timer starts timing operation between 200 to 250 ms after power is turned ON. For this reason, in operations where timing starts from power ON, the time display will actually start from 249 ms. If the set value is 249 ms or less, the time until output turns ON will be a fixed value between 200 and 250. The present value display will start from 250 ms. (Normal operation is possible for set values of 250 ms or more.) In applications where a set value of 249 ms or less is required, use start timing with signal input.
- Inrush current generated by turning ON or OFF the power supply may deteriorate contacts on the power supply circuit. Turn ON or OFF to a device with the rated current of more than 10 A.
- Make sure that all settings are appropriate for the application. Unexpected operation resulting in property damage or accidents may occur if the settings are not appropriate.
- Do not leave the Timer for long periods at a high temperature with output current in the ON state. Doing so may result in the premature deterioration of internal components (e.g., electrolytic capacitors).
- EEPROM is used as backup memory when the power is interrupted. The write life of the EEPROM is 100,000 writes. The EEPROM is written at the following times:
  - When the power supply is turned OFF
  - When switching from Timer/Twin Timer Selection Mode or Function Setting Mode to Run Mode
- Dispose of the product according to local ordinances as they apply.
- Attach the front panel when using the Timer. The tabs in the middle of each of four sides secure the front panel to the main body. To remove the panel, widen the four tabs and pull the panel toward you. To mount the panel, fit all four tabs correctly into the grooves on the main body.

![](_page_41_Figure_16.jpeg)

#### ▲ Conformance to EN/IEC Standards

- When conforming to EMC standards, refer to the information provided in this datasheet for cable selection and other conditions.
- This is a class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.
- H5CX-A□-N/-L□-N:

Basic insulation is provided between the power supply and input terminals. (No insulation is provided between the power supply and input terminals for the H5CX- $\Box$ D-N.)

Basic insulation is provided between power supply and output terminals, and between input and output terminals.

 H5CX-B□-N: No insulation is provided between the power supply and input terminals.

Basic insulation is provided between the power supply and output terminals.

- When double insulation or reinforced insulation is required, apply double insulation or reinforced insulation as defined in IEC 60664 that is suitable for the maximum operating voltage with clearances or solid insulation.
- Connect the input and output terminals to devices that do not have any exposed charged parts.

## Terms and Conditions of Sale

- Offer: Acceptance. These terms and conditions (these "Terms") are deemed part of all quotes, agreements, purchase orders, acknowledgments, price lists, catalogs, manuals, brochures and other documents, whether electronic or in writing, relating to the sale of products or services (collectively, the "<u>Products</u>") by Omron Electronics LLC and its subsidiary companies ("<u>Omron</u>"). Omron objects to any terms or conditions proposed in Buyer's purchase\_order or other documents which are inconsistent with, or in addition to, these Terms
- Prices: Payment Terms. All prices stated are current, subject to change with-out notice by Omron. Omron reserves the right to increase or decrease prices 2. on any unshipped portions of outstanding orders. Payments for Products are due net 30 days unless otherwise stated in the invoice.
- biscounts. Cash discounts, if any, will apply only on the net amount of invoices sent to Buyer after deducting transportation charges, taxes and duties, and will be allowed only if (i) the invoice is paid according to Omron's payment terms З.
- and (ii) Buyer has no past due amounts. Interest. Omron, at its option, may charge Buyer 1-1/2% interest per month or the maximum legal rate, whichever is less, on any balance not paid within the 4 stated terms
- Orders. Omron will accept no order less than \$200 net billing.
- Governmental Approvals. Buyer shall be responsible for, and shall bear all 6 costs involved in, obtaining any government approvals required for the impor-tation or sale of the Products.
- Taxes. All taxes, duties and other governmental charges (other than general real property and income taxes), including any interest or penalties thereon, imposed directly or indirectly on Omron or required to be collected directly or 7. indirectly by Omron for the manufacture, production, sale, delivery, importa-tion, consumption or use of the Products sold hereunder (including customs duties and sales, excise, use, turnover and license taxes) shall be charged to and remitted by Buyer to Omron.
- Financial. If the financial position of Buyer at any time becomes unsatisfactory 8. to Omron, Omron reserves the right to stop shipments or require satisfactory security or payment in advance. If Buyer fails to make payment or otherwise comply with these Terms or any related agreement, Omron may (without liabil-ity and in addition to other remedies) cancel any unshipped portion of Prod-ucts sold hereunder and stop any Products in transit until Buyer pays all amounts, including amounts payable hereunder, whether or not then due, which are owing to it by Buyer. Buyer shall in any event remain liable for all unpaid accounts.
- Cancellation; Etc. Orders are not subject to rescheduling or cancellation unless Buyer indemnifies Omron against all related costs or expenses.
- 10. Force Majeure. Omron shall not be liable for any delay or failure in delivery resulting from causes beyond its control, including earthquakes, fires, floods, strikes or other labor disputes, shortage of labor or materials, accidents to machinery, acts of sabotage, riots, delay in or lack of transportation or the requirements of any government authority.
- <u>Shipping: Delivery</u> Unless otherwise expressly agreed in writing by Omron:
   a. Shipments shall be by a carrier selected by Omron; Omron will not drop ship except in "break down" situations.
  - b. Such carrier shall act as the agent of Buyer and delivery to such carrier shall constitute delivery to Buyer, c. All sales and shipments of Products shall be FOB shipping point (unless oth-
  - erwise stated in writing by Omron), at which point title and risk of loss shall pass from Omron to Buyer; provided that Omron shall retain a security interest in the Products until the full purchase price is paid; d. Delivery and shipping dates are estimates only; and e. Omron will package Products as it deems proper for protection against nor-
- and handling and extra charges apply to special conditions.
   <u>Claims</u>. Any claim by Buyer against Omron for shortage or damage to the Products occurring before delivery to the carrier must be presented in writing to Omron within 30 days of receipt of shipment and include the original trans-portation bill signed by the carrier noting that the carrier received the Products from Omron in the candition claims of the products. from Omron in the condition claimed.
- Warranties. (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed 13 (b) <u>Limitations</u>. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABIL-

## Certain Precautions on Specifications and Use

- Suitability of Use. Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, 1. Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases but the following is a non-exhaustive list of applications for which particular attention must be given: Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.

 (ii) Use in consumer products or any use in significant quantities.
 (iii) Energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equip-(iv) Systems, machines and equipment that could present a risk to life or prop-erty. Please know and observe all prohibitions of use applicable to this Product

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO

ITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. Omron further disclaims all warranties and responsibility of IN ISNDED USE. Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or oth-erwise of any intellectual property right. (c) <u>Buyer Remedy</u>. Omron's sole obli-gation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsi-ble for warapty consisting the non-the complex of the non-complying Product the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Compa-nies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty See http://www.omron247.com or contact your Omron representative for published information

- Iished information.
  Limitation on Liability: Etc. OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.
  Indemnities. Buyer shall indemnify and hold harmless Omron Companies and their employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim inves-
- 15 expenses (including attorney's fees and expenses) related to any claim, inves-tigation, litigation or proceeding (whether or not Omron is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Products. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless Omron and defend or setthe any action brought against such Companies to the extent based on a claim that any Product made to Buyer specifications infringed intellectual property
- that any Product made to buyer specifications immiged interfectual property rights of another party. <u>Property: Confidentiality.</u> Any intellectual property in the Products is the exclusive property of Omron Companies and Buyer shall not attempt to duplicate it in any way without the written permission of Omron. Notwithstanding any charges to Buyer for engineering or tooling, all engineering and tooling shall remain the exclusive property of Omron. All information and materials supplied to the Products are confidential and proprietary. 16 by Omron to Buyer relating to the Products are confidential and proprietary, and Buyer shall limit distribution thereof to its trusted employees and strictly
- Export Controls. Buyer shall comply with all applicable laws, regulations and licenses regarding (i) export of products or information; (iii) sale of products to 17 "forbidden" or other proscribed persons; and (ii) disclosure to non-citizens of regulated technology or information. <u>Miscellaneous</u>. (a) <u>Waiver</u>. No failure or delay by Omron in exercising any right
- 18 <u>Miscellaneous</u>. (a) <u>Waiver</u>. No failure or delay by Omron in exercising any right and no course of dealing between Buyer and Omron shall operate as a waiver of rights by Omron. (b) <u>Assignment</u>. Buyer may not assign its rights hereunder without Omron's written consent. (c) <u>Law</u>. These Terms are governed by the law of the jurisdiction of the home office of the Omron company from which Buyer is purchasing the Products (without regard to conflict of law princi-ples). (d) <u>Amendment</u>. These Terms constitute the entire agreement between Buyer and Omron relating to the Products, and no provision may be changed or waived unless in writing signed by the parties. (e) <u>Severability</u>. If any provi-sion hereof is rendered ineffective or invalid, such provision shall not invalidate any other provision. (f) <u>Setoff</u>. Buyer shall have no right to set off any amounts against the amount owing in respect of this invoice. (a) Definitions. As used against the amount owing in respect of this invoice. (g) <u>Definitions</u>. As used herein, "<u>including</u>" means "including without limitation"; and "<u>Omron Compa-nies" (or similar words) mean Omron Corporation and any direct or indirect</u> subsidiary or affiliate thereof.

ADDRESS THE RISKS, AND THAT THE OMRON'S PRODUCT IS PROP-ERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

- 2.
- Programmable Products. Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof. <u>Performance Data</u>. Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitabil-ity and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application require-ments. Actual performance is subject to the Omron's Warranty and Limitations of Limiting. 3. of Liability.
- <u>Change in Specifications</u>. Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our prac-4 or when significant construction changes are made. However, some specifica-tions of the Product may be changed without any notice. When in doubt, spe-cial part numbers may be changed without any notice. When in doubt, spe-cial part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to applicate the provident of the product provident specifications for
- Errors and Omissions. Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

# OMRON

#### OMRON ELECTRONICS LLC • THE AMERICAS HEADQUARTERS

Schaumburg, IL USA • 847.843.7900 • 800.556.6766 • www.omron247.com

#### **OMRON CANADA, INC. • HEAD OFFICE**

7/09

Toronto, ON, Canada • 416.286.6465 • 866.986.6766 • www.omron.ca

#### OMRON ELETRÔNICA DO BRASIL LTDA • HEAD OFFICE

São Paulo, SP, Brasil • 55.11.2101.6300 • www.omron.com.br

#### **OMRON ELECTRONICS MEXICO SA DE CV • HEAD OFFICE**

Apodaca, N.L. • 52.811.156.99.10 • mela@omron.com

L111-E1-01

Note: Specifications are subject to change.

#### **OMRON ARGENTINA • SALES OFFICE**

Cono Sur • 54.11.4787.1129

#### **OMRON CHILE • SALES OFFICE**

Santiago 56.2206.4592

#### OTHER OMRON LATIN AMERICA SALES

56.2206.4592

© 2008 Omron Electronics LLC

## **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Omron:

 H5CX-A-N AC100-240
 H5CX-A11-N AC100-240
 H5CX-ASD-N-DC12-24/AC24
 H5CX-L8D-N DC12-24/AC24
 H5CX 

 AD-N AC24/DC12-24
 H5CX-L8-N AC100-240
 H5CX-A11SD-N DC12-24/AC24
 H5CX-L8ED-N DC12-24/AC24
 H5CX 

 L8S-N AC100-240
 H5CX-A11D-N DC12-24/AC24
 H5CX-AS-N AC100-240
 H5CX-L8SD-N DC12-24/AC24
 H5CX-L8D-N DC12-24/AC24

 N AC12-24/AC24
 H5CX-BWSD-N DC12-24/AC24
 H5CX-L8E-N AC100-240
 H5CX-A11S-N AC100-240