

# POCKET TYPE **Digital Thermometer**

## INSTRUCTIONS

To use the thermometer, remove the protective sheath, press the ON/OFF button and insert at least “1/2” of the stem into the testing area. The current temperature will be displayed. To save battery life, the thermometer will automatically turn off after approximately 20 minutes.

## Specifications:

Temperature Range .....	-40° to +482° F	
		(-40° to +250° C)
Resolution .....	0.1°	
Accuracy.....	1.5%+2 °	full
scale		
Sampling Time .....	2.0 seconds	
Battery .....	LR44 (1.5V)	

## NOTE:

- When turning the thermometer on ,the LCD will display “- 0.0° C” or “32.0 ° F” for 2 seconds. Then it will display the current temperature.
- If errors occur, replace the battery (1.5V).