



Glove Laundering

For proper operation, the ESD Gloves must be laundered periodically. Woolite works well. Liquid detergents are better than dry detergents in that there is less caking and frictional wear. Launder glove in cool or warm water, tumble dry with low heat or hang dry. Machine washing works well if using a standard home machine on gentle cycle. It is not recommended to launder these gloves in heavy industrial laundry machines as it will lead to premature wear. Gloves should be tumbled dry using low heat. DO NOT BLEACH. After laundering, verify Rtt 1 x $10^5 < 1 x 10^9$ ohms. Desco's ESD inspection gloves will retain their ESD properties for 25 washing or approximately 1 year.

A. Dissipative (1 x 10^5 to < 1 x 10^8 ohms) Thunderon[®] Fibers

Protective Carrier Yarn

Seamless Fine Gauge Knit

- B. Polyurethane Coated Palm and Fingers
- C. Non-Scratch Touchscreen Compatible

Item	Size Cuff Color			
<u>68124</u>	X-Small	Orange		
<u>68125</u>	Small	Light Grey		
<u>68126</u>	Medium	Green		
<u>68127</u>	Large	Brown		
<u>68128</u>	X-Large	Yellow		
<u>68129</u>	XX-Large	Dark Grey		

Protection from mechanical risks. Tested per EU EN388.				
Test	Performance Level			
6.1 Abrasion Resistance	4			
6.2 Blade Cut Resistance	1			
6.3 Tear Resistance	3			
6.4 Puncture Resistance	1			

Sold in pairs

Specifications and procedures subject to change without notice

*Not recommended for use above 104°F (40°C)	DISSIPATIVE NYLON GLOVES WITH POLYURETHANE COATING			
DESCO	DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com PHONE (909) 627-8178 DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407 PHONE (781) 821-8370 PHONE (781) 821-8370	DRAWING NUMBER 68124	DATE: March 2019	

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Desco:

<u>68124</u> <u>68125</u> <u>68126</u> <u>68127</u> <u>68128</u> <u>68129</u>