



Instruction Manual

RS Stock No: 2013521

1080P PC USB Webcam

Features

- HD 1280 x 1080P high resolution
 - Built-in microphone for video calls
 - Snapshot button for taking still images
 - Multi-function bracket for any monitor or laptop
 - Compression format : YUY2
 - Video range : 60 degrees
 - Video resolution : 1280*1080P
 - Focus range : 30cm to infinity
 - Supports Windows 7,8,10 and MacOS X 10.9 or higher .
 - Plug and Play driver installation
-

Instructions

- 1, Place the camera mount in the correct position in the centre of the top of the screen.
- 2, Press down on the camera mount and clip the rear end of it on and over the back of your screen. The webcam will now be clipped to your screen, you can adjust the angle according to your preference.
- 3, Connect the USB cable to your computer
- 4, The Webcam has a 'Plug and Play' driver installation, once your computer is turned on, Microsoft Windows / Mac OS will automatically detect the webcam and install the drivers.

Detailed Specifications

- USB cable length: 150cm;
- Photo format: BMP, JPG
- Interface: USB 2.0
- Sensor: CMOS
- Built-in sound-absorbing and noise-reducing microphone
- Contrast Optimization engine: Contrast balance
- VM engine: 180M / 8MP high speed processor
- TWAIN

Safety and Health Messages

Warning:

Failure to properly set up, use, and care for this product can increase the risk of serious injury or death, or damage to the device or devices. Read this guide and keep all printed guides for future reference.

Health Warning

Use of electronic input devices may be linked to serious injuries or disorders. When using a computer, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL, even if symptoms occur when you are not working at your computer. Symptoms like these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, or other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, and other conditions.

While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence, including: overall health, stress and how one copes with it, medical and physical conditions, and how a person positions and uses their body during work and other activities (including use of a keyboard or mouse). The amount of time a person performs an activity may also be a factor. If you have questions about how your own lifestyle, activities, or medical, or physical condition may be related to MSDs, see a qualified health professional.

All Devices

Do Not Attempt Repairs

Do not attempt to take apart, open, service, or modify the hardware device or power supply. Doing so could present the risk of electric shock or other hazard. Any evidence of any attempt to open and/or modify the device, including any peeling, puncturing, or removal of any of the labels, will void the Warranty.

Choking Hazard

This device may contain small parts which may be a choking hazard to children under 3. Keep small parts away from children.

Usage and Cleaning

Use in accordance with these instructions:

- Do not use near any heat sources.
- Only use attachments/accessories specified
- Clean only with dry cloth.
- Do not allow this product to become wet. To reduce the risk of fire or shock, do not expose this product to rain or other types of moisture.

Statement of Compliance with EU Directives

Hereby, Ceratech Accuratus Limited declares that this product is in compliance with the essential requirements and other relevant provisions of Directives, 2015/863, EN 50581:2012 and 2011/65/EU, as applicable.



Company: Ceratech Accuratus Limited

Address: Ceratech House, Unit 3 Grove Park, Mill Lane, Alton, Hampshire, GU34 2QG. UK

Telephone number: +44 1420 85470

Product Disposal Instructions

WEEE Directive

The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.



The waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling methods to minimise the impact on the environment and to treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users:

When you have no further use for it, please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For more information please contact your local authority or the retailer where the item was purchased.

Product disposal instructions for business users:

Business users should use their own contracted disposal agreements with regards to following WEEE procedures so that this product is not mixed with other commercial waste.

Technical Support

This product is 'plug and play', however if you do experience problems setting up and need support you can contact the technical team at www.rs-components.com

Thankyou for purchasing our product.