





Texas INSTRUMENTS


OPAx189 Precision, Lowest-Noise, 36-V, Zero-Drift, 14-MHz, MUX-Friendly, Rail-to-Rail Output Operational Amplifiers

1 Features

- Ultra-high precision:
 - Zero-drift: 0.005 µV/°C (OPA189)
 - Ultra-low offset voltage: 3 µV maximum (OPA189)
- Excellent dc precision:
 - CMRR: 168 dB
 - Open-loop gain: 170 dB
- Low noise:
 - e_n at 1 kHz: 5.2 nV/ \sqrt{Hz}
 - 0.1-Hz to 10-Hz noise: 0.1 μV_{PP}
- Excellent dynamic performance:
 - Gain bandwidth: 14 MHz
 - Slew rate: 20 V/µs
- Fast settling: 10-V step, 0.01% in 1.1 µs
- Robust design: ٠
 - MUX-friendly inputs
 - RFI/EMI filtered inputs
- Wide supply range: 4.5 V to 36 V
- Quiescent current: 1.7 mA (maximum) •
- Rail-to-rail output
- Input includes negative rail

2 Applications

- Battery test
- Analog input module
- Weigh scale
- DC power supply, ac source, electronic load
- Multifunction relay



OPAx189 Preserves R-C Settling Performance in a Switched or Multiplexed Application

3 Description


The OPA189, OPA2189, and OPA4189 (OPAx189) high-precision operational amplifiers are ultra-low noise, fast-settling, zero-drift devices that provide railto-rail output operation and feature a unique MUXfriendly architecture and controlled start-up system. These features and excellent ac performance, combined with only 0.4 μ V of offset voltage and 0.005µV/°C of drift over temperature for the singlechannel version, make the OPAx189 a great choice for precision instrumentation, signal measurement, and active filtering applications. Moreover, the MUXfriendly input architecture prevents inrush current when applying large input differential voltages, which improves settling performance in multichannel systems, all while providing robust ESD protection during shipment, handling, and assembly.

All versions are specified from -40°C to +125°C.

Device Information

PART NUMBER ⁽¹⁾	PACKAGE	BODY SIZE (NOM)
	SOIC (8)	4.90 mm × 3.90 mm
OPA189	SOT-23 (5)	2.90 mm × 1.60 mm
	VSSOP (8)	3.00 mm × 3.00 mm
OPA2189	SOIC (8)	4.90 mm × 3.90 mm
0FA2109	VSSOP (8)	3.00 mm × 3.00 mm
OPA4189 (preview)	TSSOP (14)	5.00 mm × 4.40 mm

For all available packages, see the package option (1) addendum at the end of the data sheet.



Copyright © 2017, Texas Instruments Incorporated

OPAx189 MUX-Friendly Input Settles Quickly and Maintains High Input Impedance When Switched



Table of Contents

1 Features	1	
2 Applications		9
3 Description	1	
4 Revision History		
5 Device Comparison Table	4	
6 Pin Configuration and Functions		1
7 Specifications		1
7.1 Absolute Maximum Ratings		
7.2 ESD Ratings		
7.3 Recommended Operating Conditions	7	1
7.4 Thermal Information: OPA189	8	
7.5 Thermal Information: OPA2189	8	
7.6 Thermal Information: OPA4189	8	
7.7 Electrical Characteristics	9	
7.8 Typical Characteristics	12	
8 Detailed Description		
8.1 Overview	20	
8.2 Functional Block Diagram		1
8.3 Feature Description.		

	8.4 Device Functional Modes	.27
)	Application and Implementation	28
	9.1 Application Information	28
	9.2 Typical Applications	
	9.3 System Examples	
10) Power Supply Recommendations	
	Layout	
	11.1 Layout Guidelines	35
	11.2 Layout Example	35
12	2 Device and Documentation Support	
	12.1 Device Support	
	12.2 Documentation Support	
	12.3 Receiving Notification of Documentation Updates.	
	12.4 Support Resources	
	12.5 Trademarks	
	12.6 Electrostatic Discharge Caution	
	12.7 Glossary	
12	3 Mechanical, Packaging, and Orderable	
	Information	37
		01

4 Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

С	hanges from Revision F (July 2020) to Revision G (April 2021)	Page
•	Added OPA4189 in TSSOP-14 (PW) package as advanced information (preview)	1
С	hanges from Revision E (May 2019) to Revision F (July 2020)	Page
•	Changed OPA2189 VSSOP-8 (DGK) package from preview to production data (active)	1
•	Added Added input offset for OPA2189IDGK	9
•	Added Added input offset drift for OPA2189IDGK	9
С	hanges from Revision D (December 2018) to Revision E (May 2019)	Page
•	Changed OPA189 SOT-23 (DBV) package from preview to production data (active)	1
•	Changed Figure 3, Input Bias Current Production Distribution, to show updated data	12
•	Changed Figure 4, Input Offset Current Production Distribution, to show updated data	12
•	Changed Figure 8, Open-Loop Gain and Phase vs Frequency, for clarity	
•	Changed Figure 9, Closed-Loop Gain vs Frequency, for clarity	
•	Added new Figure 39, OPA2189 Long-Term Drift	12
С	hanges from Revision C (October 2018) to Revision D (November 2018)	Page
•	Changed OPA2189 SOIC (D) package from preview to production data	1
•	Added input bias current for OPA2189ID	
•	Added input offset current for OPA2189ID	9
•	Added crosstalk for OPA2189ID	9
•	Changed Maximum Output Voltage Amplitude vs Frequency to reflect undistorted operating range	
•	Added OPA189 long-term drift and OPA2189 channel separation curves	
С	hanges from Revision B (October 2018) to Revision C (October 2018)	Page
•	First release of production-data sheet for OPA189IDGK	



Changes from Revision A (November 2017) to Revision B (October 2018)	Page
Added input offset for OPA2189ID	9
Added input offset drift for OPA2189ID	
Changes from Revision * (September 2017) to Revision A (October 2017)	Page
First release of production-data sheet for OPA189ID device	1



5 Device Comparison Table

PRODUCT	FEATURES
OPA188 25-μV, 0.085-μV/°C, 8.8-nV/√ Hz̄, Rail-to-Rail Output, 36-V, Zero-Drift CMOS	
OPA388 5-µV, 0.05-µV/°C, 7-nV/√ Hz, 10-MHz, <i>True</i> Rail-to-Rail Input/Output, 5.5-V, Zero-Drift CMOS	
OPA333 10-μV, 0.05-μV/°C, 25-μA, Rail-to-Rail Input/Output, 5.5-V, Zero-Drift CMOS	
OPA192 25-µV, 0.8-µV/°C, 1-mA, 10-MHz, Rail-to-Rail Input/Output, 36-V, e-Trim CMOS	
OPA140 120-μV, 10-MHz, 5.1-nV/√ Hz, 36-V JFET Input Industrial Op Amp	
OPA209 2.2-nV/√ Hz̄, 150-μV, 18-MHz, 36-V Bipolar Op Amp in SOT-23 package	



6 Pin Configuration and Functions




Figure 6-1. OPA189 D (8-Pin SOIC) and DGK (8-Pin VSSOP) Packages, Top View




Figure 6-2. OPA189 DBV (5-Pin SOT-23) Package, Top View

	PIN			DESCRIPTION	
NAME	D (SOIC) DGK (VSSOP)	DBV (SOT-23)	I/O		
–IN	2	4	I	Inverting input	
+IN	3	3	I	Noninverting input	
NC	1, 5, 8			No internal connection (can be left floating)	
OUT	6	1	0	Output	
V-	4	2	—	Negative (lowest) power supply	
V+	7	5	_	Positive (highest) power supply	

Table 6-1. Pin Functions: OPA189




Figure 6-3. OPA2189 D (8-Pin SOIC) and DGK (8-Pin VSSOP) Packages, Top View

Table 6-2. Pin Functions: OPA2189

F	PIN		PIN		PIN		DESCRIPTION
NAME	NO.	I/O	DESCRIPTION				
–IN A	2	I	Inverting input channel A				
+IN A	3	I	Noninverting input channel A				
–IN B	6	I	Inverting input channel B				
+IN B	5	I	inverting input channel B				
OUT A	1	0	tput channel A				
OUT B	7	0	Output channel B				
V-	4	—	Negative supply				
V+	8	_	Positive supply				






Figure 6-4. OPA4189 PW (14-Pin TSSOP) Preview Package, Top View

PIN		I/O	DESCRIPTION
NAME	NO.		DESCRIPTION
–IN A	2	I	Inverting input channel A
+IN A	3	I	Noninverting input channel A
–IN B	6	I	Inverting input channel B
+IN B	5	I	Noninverting input channel B
–IN C	9	I	Inverting input channel C
+IN C	10	I	Noninverting input channel C
–IN D	13	I	Inverting input channel D
+IN D	12	I	Noninverting input channel D
OUT A	1	0	Output channel A
OUT B	7	0	Output channel B
OUT C	8	0	Output channel C
OUT D	14	0	Output channel D
V-	11	_	Negative supply
V+	4	_	Positive supply

Table 6-3. Pin Functions: OPA4189



7 Specifications

7.1 Absolute Maximum Ratings

over operating free-air temperature range (unless otherwise noted)⁽¹⁾

			MIN	MAX	UNIT
Cumple valtage	$\gamma = 0(+) - 0(-)$	Single-supply		40	
Supply voltage	$V_{\rm S} = (V+) - (V-)$	Dual-supply		±20	V
	Valtaga	Common-mode	(V–) – 0.5	(V+) + 0.5	v
Signal input pins	Voltage	Differential		(V+) - (V-) + 0.2	
	Current			±10	mA
Output short circuit ⁽²⁾			Continuous	Continuous	
	Operating, T _A		-55	150	
Temperature	Junction, T _J			150	°C
	Storage, T _{stg}		-65	150	

(1) Stresses beyond those listed under Absolute Maximum Ratings may cause permanent damage to the device. These are stress ratings only, which do not imply functional operation of the device at these or any other conditions beyond those indicated under Recommended Operating Conditions. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

(2) Short-circuit to ground, one amplifier per package.

7.2 ESD Ratings

			VALUE	UNIT	
V	Electrostatic discharge	Human-body model (HBM), per ANSI/ESDA/JEDEC JS-001 ⁽¹⁾	±4000	V	
V _(ESD)		Charged-device model (CDM), per JEDEC specification JESD22-C101 ⁽²⁾	±1000	v	

(1) JEDEC document JEP155 states that 500-V HBM allows safe manufacturing with a standard ESD control process.

(2) JEDEC document JEP157 states that 250-V CDM allows safe manufacturing with a standard ESD control process.

7.3 Recommended Operating Conditions

over operating free-air temperature range (unless otherwise noted)

		MIN	NOM MAX	UNIT	
Supply voltage, $V_S = (V+) - (V-)$	Single-supply	4.5	36	N N	
Supply voltage, $v_S = (v_T) = (v_{-})$	Dual-supply	±2.25	±18	v	
Specified temperature			125	°C	

7.4 Thermal Information: OPA189

			OPA189			
	THERMAL METRIC ⁽¹⁾	D (SOIC)	DGK (VSSOP)	DBV (SOT)	UNIT	
		8 PINS	8 PINS	5 PINS		
R _{θJA}	Junction-to-ambient thermal resistance	122.0	166.4	134.5	°C/W	
R _{0JC(top)}	Junction-to-case (top) thermal resistance	57.6	54.2	90.5	°C/W	
$R_{\theta JB}$	Junction-to-board thermal resistance	67.3	87.9	41.9	°C/W	
Ψ_{JT}	Junction-to-top characterization parameter	12.7	5.5	22.5	°C/W	
Ψ_{JB}	Junction-to-board characterization parameter	66.2	86.4	41.6	°C/W	
R _{0JC(bot)}	Junction-to-case (bottom) thermal resistance	N/A	N/A	N/A	°C/W	

(1) For more information about traditional and new thermal metrics, see the Semiconductor and IC Package Thermal Metrics application report.

7.5 Thermal Information: OPA2189

		OP	A2189	
	THERMAL METRIC ⁽¹⁾	D (SOIC)	DGK (VSSOP)	UNIT
		8 PINS	8 PINS	
R _{θJA}	Junction-to-ambient thermal resistance	115.7	150.2	°C/W
R _{0JC(top)}	Junction-to-case (top) thermal resistance	51.1	43.9	°C/W
$R_{\theta JB}$	Junction-to-board thermal resistance	60.8	71.4	°C/W
Ψ_{JT}	Junction-to-top characterization parameter	9.8	2.9	°C/W
Ψ_{JB}	Junction-to-board characterization parameter	59.7	70	°C/W
R _{0JC(bot)}	Junction-to-case (bottom) thermal resistance	N/A	N/A	°C/W

(1) For more information about traditional and new thermal metrics, see the Semiconductor and IC Package Thermal Metrics application report.

7.6 Thermal Information: OPA4189

		OPA4189	
	THERMAL METRIC ⁽¹⁾	PW (TSSOP)	UNIT
		14 PINS	
R _{θJA}	Junction-to-ambient thermal resistance	92.6	°C/W
R _{0JC(top)}	Junction-to-case (top) thermal resistance	27.5	°C/W
$R_{\theta JB}$	Junction-to-board thermal resistance	33.6	°C/W
Ψ_{JT}	Junction-to-top characterization parameter	1.9	°C/W
Ψ_{JB}	Junction-to-board characterization parameter	33.1	°C/W
R _{0JC(bot)}	Junction-to-case (bottom) thermal resistance	N/A	°C/W

(1) For more information about traditional and new thermal metrics, see the Semiconductor and IC Package Thermal Metrics application report.



7.7 Electrical Characteristics

at T_A = 25°C, V_S = ±18V, V_{CM} = V_{OUT} = V_S / 2, and R_{LOAD} = 10 k Ω connected to V_S / 2 (unless otherwise noted)

	PARAMETER	TEST CC	ONDITIONS	MIN	TYP	MAX	UNIT
OFFSET \	/OLTAGE	I					
	Input offset voltage,				±0.4	±3	
	OPA189	T _A = -40°C to 125°C				±4	μV
		V _S = ±2.25V			±0.5	±3	μV
V _{OS}	Input offset voltage, OPA2189IDGK	V _S = ±18V			±0.8	±5	μV
		$T_A = -40^{\circ}C$ to 125°C, $V_S = \pm 18$	V			±8	μV
	Input offset voltage,				±1.5	±5	μV
	OPA2189ID	T _A = -40°C to 125°C				±8	μV
	Input offset voltage drift, OPA189	$T_A = -40^{\circ}C$ to 125°C			±0.005	±0.02	µV/°C
	Input offset voltage drift,	T _A = 0°C to 85°C			±0.006	±0.015	μV/°C
dV _{OS} /dT	OPA2189IDGK	T _A = -40°C to 125°C			±0.01	±0.03	μV/°C
	Input offset voltage drift, OPA2189ID	T _A = 0°C to 85°C			±0.007	±0.03	μV/°C
		$T_A = -40^{\circ}C$ to 125°C			±0.01	±0.05	μV/°C
PSRR	Power-supply rejection ratio	T _A = -40°C to 125°C			±0.005	±0.05	μV/V
INPUT BIA	AS CURRENT						
					±70	±300	pА
	Input bias current, OPA189		$T_A = 0^{\circ}C$ to $85^{\circ}C$			±1	
			T _A = -40°C to 125°C			±10	nA
IB		Z _{IN} = 100 kΩ 500 pF			±70	±300	pА
	Input bias current, OPA2189		$T_A = 0^{\circ}C$ to $85^{\circ}C$			±1.5	0
			T _A = -40°C to 125°C			±10	nA
					±140	±600	pА
	Input offset current, OPA189		T _A = 0°C to 85°C			±1.6	~^
			T _A = -40°C to 125°C			±3	nA
l _{OS}		Z _{IN} = 100 kΩ 500 pF			±140	±600	pА
	Input offset current, OPA2189		$T_A = 0^{\circ}C$ to $85^{\circ}C$			±2.5	
			$T_A = -40^{\circ}C$ to $125^{\circ}C$			±5	nA



7.7 Electrical Characteristics (continued)

	PARAMETER	TEST CONDI	TIONS	MIN	TYP	MAX	UNIT
NOISE							
		f = 0, 1, Hz to 10, Hz			17		nV _{RMS}
En	Input voltage noise	f = 0.1 Hz to 10 Hz			0.1		μV _{PP}
		f = 10 Hz			5.2		
•	Input voltage noise density	f = 100 Hz		5.2			nV/√Hz
en	Input voltage holse density	f = 1 kHz			5.2		
		f = 10 kHz			5.2		
i _n	Input current noise density	f = 1 kHz			165		fA/√Hz
INPUT VO	OLTAGE						
V _{CM}	Common-mode voltage range			(V–) – 0.1		(V+) – 2.5	V
			V _S = ±2.25 V	120	140		
	Common-mode rejection	$(V-) - 0.1 V \le V_{CM} \le (V+) - 2.5 V$	V _S = ±18 V	146	168		
CMRR	ratio	$(V-) - 0.1 V \le V_{CM} \le (V+) - 2.5 V,$	V _S = ±18 V	120			dB
		$T_A = -40^{\circ}C$ to $125^{\circ}C$	V _S = ±2.25 V	110			
INPUT IM	IPEDANCE		I			1	
z _{id}	Differential input impedance				0.1 5.5		GΩ∥pF
z _{ic}	Common-mode input impedance				60 1.7		TΩ pF
OPEN-LC	DOP GAIN						
	Open-loop voltage gain		$(V-) + 0.3 V < V_O < (V+)$ - 0.3 V, R _{LOAD} = 10 kΩ	150	170		
		en-loop voltage gain V _S = ±18 V		140			dB
A _{OL}			$(V-) + 0.6 V < V_O < (V+)$ - 0.6 V, $R_{LOAD} = 2 k\Omega$	150	170		
				140			
FREQUE	NCY RESPONSE						
UGB	Unity-gain Bandwith	A _V = 1			8		MHz
GBW	Gain-bandwith Product	A _V = 1000			14		
SR	Slew rate	G = 1, 10-V step			20		V/µs
THD+N	Total harmonic distortion + noise	G = 1, f = 1 kHz, V _O = 3.5 V _{RMS}			0.00006%		
	Crosstalk	OPA2189ID, at dc			150		dB
		OPA2189ID, f = 100 kHz			120		
t-	Settling time	То 0.1%	$V_{S} = \pm 18 V, G = 1, 10-V$ step		0.8		
ts	Settling time	То 0.01%	V _S = ±18 V, G = 1, 10-V step		1.1		μs
t _{OR}	Overload recovery time	$V_{IN} \times G = V_S$			320		ns



7.7 Electrical Characteristics (continued)

at $T_A = 25^{\circ}$ C, $V_S = \pm 18$ V, $V_{CM} = V_{OUT} = V_S / 2$, and $R_{LOAD} = 10 \text{ k}\Omega$ connected to $V_S / 2$ (unless otherwise noted)

	PARAMETER	TEST CONDITI	ONS	MIN	TYP	MAX	UNIT
Ουτρυτ							
Vo			No load		5	15	
		Positive rail	R _{LOAD} = 10 kΩ		20	110	0
			R _{LOAD} = 2 kΩ		80	500	
	Voltage output swing from rail		No load		5	15	mV
		Negative rail	R _{LOAD} = 10 kΩ		20	110	110 500
			R _{LOAD} = 2 kΩ		80	500	
		$T_A = -40^{\circ}$ C to 125°C, both rails, R _{LOA}	_D = 10 kΩ		20	120	
I _{SC}	Short-circuit current				±65		mA
C _{LOAD}	Capacitive load drive	See Small-Signal Overshoot vs Capa	citive Load				
Z _O	Open-loop output impedance	f = 1 MHz, I _O = 0 A, see Open-Loop C Frequency	Dutput Impedance vs		380		Ω
POWER	SUPPLY	•				I	
	Quiescent current per	$V_{\rm S}$ = ±2.25 V to ±18 V ($V_{\rm S}$ = 4.5 V to	T _A = 25°C		1.3	1.7	m۸
l _Q	amplifier	36 V)	$T_A = -40^{\circ}C$ to $125^{\circ}C$			1.8	mA




7.8 Typical Characteristics

at $T_A = 25^{\circ}$ C, $V_S = \pm 18$ V, $V_{CM} = V_S / 2$, $R_{LOAD} = 10$ k Ω connected to $V_S / 2$, and $C_L = 100$ pF (unless otherwise noted)


Table 7-1. Typical Characteristic Graphs

Offset Voltage Production DistributionIFigure 7.1Offset Voltage Drift Distribution From 40° Cto 125°CFigure 7.3Input Blas Current Production DistributionFigure 7.3Offset Voltage vs TemperatureIFigure 7.4Offset Voltage vs TemperatureFigure 7.6Offset Voltage vs Common-Mode VoltageFigure 7.7Open-Loop Gain and Phase vs FrequencyIFigure 7.1Input Blas Current vs Common-Mode VoltageFigure 7.1Input Blas Current vs Common-Mode VoltageFigure 7.10Input Blas Current vs Common-Mode VoltageIFigure 7.11Output Voltage Swing vs Output Current (Sourcing)Figure 7.13Output Voltage Swing vs Output Current (Sourcing)Figure 7.13Output Voltage Swing vs Output Current (Sourcing)Figure 7.14Other Voltage Swing vs Output Current (Sourcing)Figure 7.16Other Voltage NoiseFigure 7.16Other Voltage Noise Spectral Density vs FrequencyFigure 7.17Input Voltage Noise Spectral Density vs FrequencyFigure 7.20Open-Loop Gain vs TemperatureFigure 7.20Open-Loop Gain vs Temperature (2k2)Figure 7.21Open-Loop Gain vs Temperature (2k2)Figure 7.23Open-Loop Gain vs Temperature (2k2)Figure 7.23Open-Loop Gain vs Temperature (2k2)Figure 7.23Open-Loop Gain vs TemperatureFigure 7.23Open-	DESCRIPTION	FIGURE
Input Bias Current Production DistributionFigure 7.3Input Offset Current Production DistributionFigure 7.4Offset Voltage vs Common-Mode VoltageFigure 7.5Offset Voltage vs Common-Mode VoltageFigure 7.6Offset Voltage vs Supply VoltageFigure 7.7Open-Loop Gain and Phase vs FrequencyFigure 7.6Input Bias Current vs Common-Mode VoltageFigure 7.10Input Bias Current vs Common-Mode VoltageFigure 7.10Input Bias Current vs Common-Mode VoltageFigure 7.12Output Voltage Swing vs Output Current (Sourcing)Figure 7.13Output Voltage Swing vs Output Current (Sinking)Figure 7.14CMRR and PSR vs FrequencyFigure 7.16Olt+z to 10-kz Voltage NoiseFigure 7.16Olt+z Voltage Noise Spectral Density vs FrequencyFigure 7.17Input Voltage Noise Spectral Density vs FrequencyFigure 7.20Quiescent Current vs Supply VoltageFigure 7.21Quiescent Current vs TemperatureFigure 7.22Open-Loop Cain vs Temperature (10-k0)Figure 7.23Open-Loop Cain vs Temperature (10-k0)Figure 7.23Open-Loop Cultut Impedance vs FrequencyFigure 7.26Small-Signal Step Response (10-mV Step)Figure 7.23Open-Loop Cultur Imperature (2-k0)Figure 7.26Small-Signal Step Response (10-mV Step)Figure 7.23Open-Loop Cultur Impedance vs FrequencyFigure 7.26Small-Signal Step Response (10-mV Step)Figure 7.33Setting TimeFigure 7.33Setting TimeFigure 7.33Setting Time <td>Offset Voltage Production Distribution</td> <td>Figure 7-1</td>	Offset Voltage Production Distribution	Figure 7-1
Input Offset Current Production DistributionFigure 7-4Offset Voltage vs TemperatureFigure 7-5Offset Voltage vs Common-Mode VoltageFigure 7-6Offset Voltage vs Supply VoltageFigure 7-7Open-Loop Gain and Phase vs FrequencyFigure 7-8Closed-Loop Gain vs FrequencyFigure 7-9Input Bias Current vs Common-Mode VoltageFigure 7-10Output Voltage Swing vs Output Current (Sourcing)Figure 7-11Output Voltage Swing vs Output Current (Sourcing)Figure 7-12Output Voltage Swing vs Output Current (Sourcing)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-16OHAR Voltage Noise Spectral Density vs FrequencyFigure 7-160.1-Hz to 10-Hz Voltage Noise Spectral Density vs FrequencyFigure 7-17Input Natio vs FrequencyFigure 7-18Unduscent Current vs Supply VoltageFigure 7-20Quiescent Current vs Supply VoltageFigure 7-20Quiescent Current vs Supply VoltageFigure 7-23Open-Loop Gain vs Temperature (10-KΩ)Figure 7-23Open-Loop Gain vs Temperature (2-KΩ)Figure 7-26Open-Loop Gain vs Temperature (2-KΩ)Figure 7-27Positive Overload RecoveryFigure 7-28Ne Phase ReversalFigure 7-28Ne Phase ReversalFigure 7-30No Phase ReversalFigure 7-30Pogure 7-30Figure 7-30Small-Signal Step Response (10W Step)Figure 7-30Small-Signal Step Response (10W Step)Figure 7-30Small-Signal Step Response (10W Step)Figure 7-30	Offset Voltage Drift Distribution From –40°C to 125°C	Figure 7-2
Offset Voltage vs TemperatureFigure 7-5Offset Voltage vs Common-Mode VoltageFigure 7-6Offset Voltage vs Common-Mode VoltageFigure 7-7Offset Voltage vs Somply VoltageFigure 7-8Closed-Loop Gain vs FrequencyFigure 7-9Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current vs Common-Mode VoltageFigure 7-12Output Voltage Swing vs Output Current (Surving)Figure 7-12Output Voltage Swing vs Output Current (Surving)Figure 7-14CMRR and PSRR vs FrequencyFigure 7-16Oltav Voltage Noise Spectral Density vs FrequencyFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-160.1-Hz to 10-Hz Voltage Noise Spectral Density vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-20Quiescent Current vs TemperatureFigure 7-20Open-Loop Gain vs Temperature (10-KΩ)Figure 7-23Open-Loop Gain vs Temperature (2-KQ)Figure 7-24Open-Loop Gain vs Temperature (2-KQ)Figure 7-26No Phase ReversalFigure 7-27Positivo Covertoad RecoveryFigure 7-28Nagative Overload RecoveryFigure 7-30Small-Signal Step Response (10-W Step)Figure 7-30Short-Circuit Current vs TemperatureFigure 7-34Short-Circuit Current vs TemperatureFigure 7-34Short-Circuit Current vs TemperatureFigure 7-36Open-Loop Gain vs Temperature (2-KQ)Figure 7-36Short-Circuit Current vs Temperatur	Input Bias Current Production Distribution	Figure 7-3
Offset Voltage vs Common-Mode VoltageFigure 7-6Offset Voltage vs Supply VoltageFigure 7-7Open-Loop Gain vs FrequencyFigure 7-9Input Bias Current vs Common-Mode VoltageFigure 7-9Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current vs Common-Mode VoltageFigure 7-10Output Voltage Swing vs Output Current (Sourcing)Figure 7-12Output Voltage Swing vs Output Current (Sinking)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-14CMRR vs TemperatureFigure 7-160.1-Hz Voltage Noise Spectral Density vs FrequencyFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-21Quiescent Current vs Supply VoltageFigure 7-23Open-Loop Gain vs Temperature (10-kQ)Figure 7-23Open-Loop Gain vs Temperature (2-kQ)Figure 7-24Open-Loop Gain vs Temperature (2-kQ)Figure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-30Small-Signal Step Response (10-mV Step)Figure 7-30Small-Signal Step Response (10-MV Step)Figure 7-34Short-Circuit Current vs TemperatureFigure 7-34Short-Circuit Current vs TemperatureFigure 7-34Open-Loop Alex PrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36	Input Offset Current Production Distribution	Figure 7-4
Offset Voltage vs Supply VoltageFigure 7.7Open-Loop Gain and Phase vs FrequencyFigure 7.8Closed-Loop Gain vs FrequencyFigure 7.9Input Bias Current vs Common-Mode VoltageFigure 7.10Input Bias Current and Offset vs TemperatureFigure 7.11Output Voltage Swing vs Output Current (Sourcing)Figure 7.12Output Voltage Swing vs Output Current (Sinking)Figure 7.13CMRR and PSRR vs FrequencyFigure 7.16PSRN vs TemperatureFigure 7.16Othz Voltage Noise Spectral Density vs FrequencyFigure 7.160.1-Hz to 10-Hz Voltage NoiseFigure 7.17Input Voltage Noise Spectral Density vs FrequencyFigure 7.18THD+N vs Output AmplitudeFigure 7.21Quiescent Current vs Supply VoltageFigure 7.21Quiescent Current vs Stephy VoltageFigure 7.22Open-Loop Gain vs Temperature (10-KΩ)Figure 7.23Open-Loop Gain vs Temperature (10-KΩ)Figure 7.23Open-Loop Gain vs Temperature (10-KΩ)Figure 7.26No Phase ReversalFigure 7.26No Phase ReversalFigure 7.27Positive Overload RecoveryFigure 7.23Open-Loop Gain vs Temperature (10-MX Step)Figure 7.23No Phase ReversalFigure 7.33Settling TimeFigure 7.32No Phase ReversalFigure 7.26No Phase ReversalFigure 7.33Settling TimeFigure 7.33Settling TimeFigure 7.33Settling TimeFigure 7.34Shot-Circuit Current vs TemperatureFigure 7.34	Offset Voltage vs Temperature	Figure 7-5
Open-Loop Gain and Phase vs FrequencyFigure 7-8Closed-Loop Gain vs FrequencyFigure 7-9Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current vs TemperatureFigure 7-11Output Voltage Swing vs Output Current (Sourcing)Figure 7-12Output Voltage Swing vs Output Current (Sourcing)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-15PSRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs Supply VoltageFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-25Open-Loop Gain vs Temperature (2-kΩ)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-30Small-Signal Step Response (10-W Step)Figure 7-30Setting TimeFigure 7-33Setting TimeFigure 7-34Shot-Circuit Current vs TemperatureFigure 7-33Setting TimeFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-37OpA189 Long-Term Drift<	Offset Voltage vs Common-Mode Voltage	Figure 7-6
Closed-Loop Gain vs FrequencyFigure 7-9Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current and Offset vs TemperatureFigure 7-11Output Voltage Swing vs Output Current (Suncing)Figure 7-12Output Voltage Swing vs Output Current (Sinking)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-160.1-Hz to 10-Hz Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-19THD+N Ratio vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-20Quiescent Current vs Temperature (10-kΩ)Figure 7-20Quiescent Current vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-28Ne Phase ReversalFigure 7-29No Phase ReversalFigure 7-30Negative Overload RecoveryFigure 7-30Setting TimeFigure 7-30Setting TimeFigure 7-33Setting TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-36Maximum Output Voltage vs FrequencyFigure 7	Offset Voltage vs Supply Voltage	Figure 7-7
Input Bias Current vs Common-Mode VoltageFigure 7-10Input Bias Current and Offset vs TemperatureFigure 7-11Output Voltage Swing vs Output Current (Sourcing)Figure 7-12Output Voltage Swing vs Output Current (Sinking)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-15PSRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N so Output AmplitudeFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs Temperature (0-kΩ)Figure 7-22Open-Loop Gain vs Temperature (0-kΩ)Figure 7-23Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitike Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-23Negative Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-23Setting TimeFigure 7-23Setting TimeFigure 7-26Small-Signal Step Response (10-W Step)Figure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-30Setting TimeFigure 7-33Setting TimeFigure 7-33Setting TimeFigure 7-34Shot-Circuit Current vs TemperatureFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure	Open-Loop Gain and Phase vs Frequency	Figure 7-8
Input Bias Current and Offset vs TemperatureFigure 7-11Output Voltage Swing vs Output Current (Sourcing)Figure 7-12Output Voltage Swing vs Output Current (Sinking)Figure 7-13CMRR and PSR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-15PSR vs TemperatureFigure 7-160.1-Hz to 10-HZ Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-20Quiescent Current vs Supply VoltageFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-29Stifting TimeFigure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-34, Figure 7-33Setting TimeFigure 7-34Shot-Circuit Current vs TemperatureFigure 7-34Shot-Circuit Current vs TemperatureFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Closed-Loop Gain vs Frequency	Figure 7-9
Output Voltage Swing vs Output Current (Sourcing)Figure 7-12Output Voltage Swing vs Output Current (Sinking)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-15PSR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs Temperature (10-KΩ)Figure 7-22Open-Loop Gain vs Temperature (10-KΩ)Figure 7-23Open-Loop Gain vs Temperature (2+CQ)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-W Step)Figure 7-33Setting TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-36EMIRR vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftOPA2189 Long-Term Drift	Input Bias Current vs Common-Mode Voltage	Figure 7-10
Output Voltage Swing vs Output Current (Sinking)Figure 7-13CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-15PSRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N vs Output AmplitudeFigure 7-19THD+N vs Output AmplitudeFigure 7-20Quiescent Current vs Supply VoltageFigure 7-20Quiescent Current vs TemperatureFigure 7-21Quiescent Current vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Gain vs Temperature (2-kΩ)Figure 7-26Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-W Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-37OPA189 Long-Term DriftOPA2189 Long-Term Drift	Input Bias Current and Offset vs Temperature	Figure 7-11
CMRR and PSRR vs FrequencyFigure 7-14CMRR vs TemperatureFigure 7-15PSRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-19THD+N N so Unput AmplitudeFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-33Setting TimeFigure 7-33, Figure 7-33Setting TimeFigure 7-34Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-33Setting TimeFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Output Voltage Swing vs Output Current (Sourcing)	Figure 7-12
CMRR vs TemperatureFigure 7-15PSRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-19THD+N N atto vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (10-kΩ)Figure 7-24Open-Loop Gain vs Temperature (24Ω)Figure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-28Negative Overload RecoveryFigure 7-30, Figure 7-31Large-Signal Step Response (10-mV Step)Figure 7-33, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36Settling TimeFigure 7-36Settling TimeFigure 7-36Short-Circuit Current vs TemperatureFigure 7-36Charles Vs TenperatureFigure 7-36Charles Vs TenperatureFigure 7-36Settling TimeFigure 7-36Short-Circuit Current vs TemperatureFigure 7-36Charles Vs TenperatureFigure 7-36Charles Vs TenperatureFigure 7-36Charles Vs TenperatureFigure 7-36Short-Circuit Current vs TemperatureFigure 7-36Charles Vs TenperatureFigure 7-36Charles Vs TenperatureFigure 7-36Charles Vs Tenperature <td< td=""><td>Output Voltage Swing vs Output Current (Sinking)</td><td>Figure 7-13</td></td<>	Output Voltage Swing vs Output Current (Sinking)	Figure 7-13
PSRR vs TemperatureFigure 7-160.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-19THD+N Ratio vs FrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-30Small-Signal Step Response (10-W Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	CMRR and PSRR vs Frequency	Figure 7-14
0.1-Hz to 10-Hz Voltage NoiseFigure 7-17Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-19THD+N vs Output AmplitudeFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-31Large-Signal Step Response (10-mV Step)Figure 7-32, Figure 7-31Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	CMRR vs Temperature	Figure 7-15
Input Voltage Noise Spectral Density vs FrequencyFigure 7-18THD+N Ratio vs FrequencyFigure 7-19THD+N Ratio vs SrequencyFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-KΩ)Figure 7-23Open-Loop Gain vs Temperature (2-KΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-28Negative Overload RecoveryFigure 7-30, Figure 7-31Large-Signal Step Response (10-MV Step)Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	PSRR vs Temperature	Figure 7-16
THD+N Ratio vs FrequencyFigure 7-19THD+N vs Output AmplitudeFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs TemperatureFigure 7-21Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-mV Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	0.1-Hz to 10-Hz Voltage Noise	Figure 7-17
THD+N vs Output AmplitudeFigure 7-20Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-mV Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Input Voltage Noise Spectral Density vs Frequency	Figure 7-18
Quiescent Current vs Supply VoltageFigure 7-21Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38	THD+N Ratio vs Frequency	Figure 7-19
Quiescent Current vs TemperatureFigure 7-22Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-mV Step)Figure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	THD+N vs Output Amplitude	Figure 7-20
Open-Loop Gain vs Temperature (10-kΩ)Figure 7-23Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Quiescent Current vs Supply Voltage	Figure 7-21
Open-Loop Gain vs Temperature (2-kΩ)Figure 7-24Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38	Quiescent Current vs Temperature	Figure 7-22
Open-Loop Output Impedance vs FrequencyFigure 7-25Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-W Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-39	Open-Loop Gain vs Temperature (10-kΩ)	Figure 7-23
Small-Signal Overshoot vs Capacitive Load (10-mV Step)Figure 7-26No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-V Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-39	Open-Loop Gain vs Temperature (2-kΩ)	Figure 7-24
No Phase ReversalFigure 7-27Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-V Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-39	Open-Loop Output Impedance vs Frequency	Figure 7-25
Positive Overload RecoveryFigure 7-28Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-V Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-36Maximum Output Voltage vs FrequencyFigure 7-37OPA189 Long-Term DriftOPA2189 Long-Term Drift	Small-Signal Overshoot vs Capacitive Load (10-mV Step)	Figure 7-26
Negative Overload RecoveryFigure 7-29Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-V Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	No Phase Reversal	Figure 7-27
Small-Signal Step Response (10-mV Step)Figure 7-30, Figure 7-31Large-Signal Step Response (10-V Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-39	Positive Overload Recovery	Figure 7-28
Large-Signal Step Response (10-V Step)Figure 7-32, Figure 7-33Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Negative Overload Recovery	Figure 7-29
Settling TimeFigure 7-34Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Small-Signal Step Response (10-mV Step)	Figure 7-30, Figure 7-31
Short-Circuit Current vs TemperatureFigure 7-35Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Large-Signal Step Response (10-V Step)	Figure 7-32, Figure 7-33
Maximum Output Voltage vs FrequencyFigure 7-36EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Settling Time	Figure 7-34
EMIRR vs FrequencyFigure 7-37OPA189 Long-Term DriftFigure 7-38OPA2189 Long-Term DriftFigure 7-39	Short-Circuit Current vs Temperature	Figure 7-35
OPA189 Long-Term Drift Figure 7-38 OPA2189 Long-Term Drift Figure 7-39	Maximum Output Voltage vs Frequency	Figure 7-36
OPA2189 Long-Term Drift Figure 7-39	EMIRR vs Frequency	Figure 7-37
	OPA189 Long-Term Drift	Figure 7-38
Channel Separation Figure 7-40	OPA2189 Long-Term Drift	Figure 7-39
	Channel Separation	Figure 7-40
































at T_A = 25°C, V_S = ±18 V, V_{CM} = V_S / 2, R_{LOAD} = 10 k Ω connected to V_S / 2, and C_L = 100 pF (unless otherwise noted)






8 Detailed Description

8.1 Overview

The OPAx189 operational amplifiers combine precision offset and drift with excellent overall performance, making these devices an excellent choice for many precision applications. The precision offset drift of only 0.005 μ V/°C provides stability over the entire temperature range. In addition, these devices offer excellent linear performance with high CMRR, PSRR, and A_{OL}. As with all amplifiers, applications with noisy or high-impedance power supplies require decoupling capacitors close to the device pins. In most cases, 0.1- μ F capacitors are adequate. See the *Layout Guidelines* section for details and layout example.

The OPAx189 are part of a family of zero-drift, MUX-friendly, rail-to-rail output operational amplifiers. These devices operate from 4.5 V to 36 V, are unity-gain stable, and are designed for a wide range of general-purpose and precision applications. The zero-drift architecture provides ultra-low input offset voltage and near-zero input offset voltage drift over temperature and time. This choice of architecture also offers outstanding ac performance, such as ultra-low broadband noise, zero flicker noise, and outstanding distortion performance when operating below the chopper frequency.

8.2 Functional Block Diagram



The *Functional Block Diagram* shows a representation of the proprietary OPAx189 architecture.



8.3 Feature Description

The OPAx189 series of op amps can be used with single or dual supplies from an operating range of $V_S = 4.5$ V (±2.25 V) up to $V_S = 36$ V (±18 V). These devices do not require symmetrical supplies; they only require a minimum supply voltage of 4.5 V (±2.25 V). For V_S less than ±2.5 V, the

common-mode input range does not include midsupply. Supply voltages higher than 40 V can permanently damage the device; see the *Absolute Maximum Ratings* table for details. Key parameters are given over the specified temperature range, $T_A = -40^{\circ}$ C to +125°C, in the *Electrical Characteristics* table. Key parameters that vary over the supply voltage, temperature range, or frequency are shown in the *Typical Characteristics* section.

The OPAx189 is unity-gain stable and free from unexpected output phase reversal. This device uses a proprietary, periodic autocalibration technique to provide low input offset voltage and very low input offset voltage drift over time and temperature. For lowest offset voltage and precision performance, optimize circuit layout and mechanical conditions. Avoid temperature gradients that create thermoelectric (Seebeck) effects in the thermocouple junctions formed from connecting dissimilar conductors. Cancel these thermally-generated potentials by ensuring they are equal on both input pins. Other layout and design considerations include:

- Use low thermoelectric-coefficient conditions (avoid dissimilar metals).
- Thermally isolate components from power supplies or other heat sources.
- Shield operational amplifier and input circuitry from air currents, such as cooling fans.

Follow these guidelines to reduce the likelihood of junctions being at different temperatures, which may cause thermoelectric voltages of 0.1 μ V/°C or higher, depending on the materials used. See the *Layout Guidelines* section for details and a layout example.

8.3.1 Operating Characteristics

The OPAx189 is specified for operation from 4.5 V to 36 V (± 2.25 V to ± 18 V). Many specifications apply from – 40°C to +125°C. Parameters that can exhibit significant variance with regard to operating voltage or temperature are presented in the *Typical Characteristics* section.

8.3.2 Phase-Reversal Protection

The OPAx189 has an internal phase-reversal protection. Many op amps exhibit a phase reversal when the input is driven beyond the linear common-mode range. This condition is most often encountered in noninverting circuits when the input is driven beyond the specified common-mode voltage range, causing the output to reverse into the opposite rail. The OPAx189 input prevents phase reversal with excessive common-mode voltage. Instead, the output limits into the appropriate rail. This performance is shown in Figure 8-1.




Figure 8-1. No Phase Reversal



8.3.3 Input Bias Current Clock Feedthrough

Zero-drift amplifiers such as the OPAx189 use switching on the inputs to correct for the intrinsic offset and drift of the amplifier. Charge injection from the integrated switches on the inputs can introduce short transients in the input bias current of the amplifier. The extremely short duration of these pulses prevents the pulses from amplifying, however the pulses may be coupled to the output of the amplifier through the feedback network. The most effective method to prevent transients in the input bias current from producing additional noise at the amplifier output is to use a low-pass filter such as an RC network.

8.3.4 EMI Rejection

The OPAx189 uses integrated electromagnetic interference (EMI) filtering to reduce the effects of EMI interference from sources such as wireless communications and densely-populated boards with a mix of analog signal chain and digital components. EMI immunity can be improved with circuit design techniques; the OPAx189 benefits from these design improvements. Texas Instruments has developed the ability to accurately measure and quantify the immunity of an operational amplifier over a broad frequency spectrum extending from 10 MHz to 6 GHz. Figure 8-2 shows the results of this testing on the OPAx189. Table 8-1 lists the EMIRR +IN values for the OPAx189 at particular frequencies commonly encountered in real-world applications. Applications listed in Table 8-1 may be centered on or operated near the particular frequency shown. Detailed information can also be found in the *EMI Rejection Ratio of Operational Amplifiers* application report, available for download from www.ti.com.




Figure 8-2. EMIRR Testing

FREQUENCY	APPLICATION AND ALLOCATION	EMIRR IN+	
400 MHz	00 MHz Mobile radio, mobile satellite, space operation, weather, radar, ultra-high frequency (UHF) applications		
900 MHz	Global system for mobile communications (GSM) applications, radio communication, navigation, GPS (to 1.6 GHz), GSM, aeronautical mobile, UHF applications		
1.8 GHz	GSM applications, mobile personal communications, broadband, satellite, L-band (1 GHz to 2 GHz)	69.1 dB	
2.4 GHz	802.11b, 802.11g, 802.11n, Bluetooth [®] , mobile personal communications, industrial, scientific and medical (ISM) radio band, amateur radio and satellite, S-band (2 GHz to 4 GHz)	88.9 dB	
3.6 GHz	3.6 GHz Radiolocation, aero communication and navigation, satellite, mobile, S-band		
5 GHz	802.11a, 802.11n, aero communication and navigation, mobile communication, space and satellite operation, C-band (4 GHz to 8 GHz)	95.5 dB	

The electromagnetic interference (EMI) rejection ratio, or EMIRR, describes the EMI immunity of operational amplifiers. An adverse effect that is common to many op amps is a change in the offset voltage as a result of RF signal rectification. An op amp that is more efficient at rejecting this change in offset as a result of EMI has a higher EMIRR and is quantified by a decibel value. Measuring EMIRR can be performed in many ways, but



this section provides the EMIRR +IN, which specifically describes the EMIRR performance when the RF signal is applied to the noninverting input pin of the op amp. In general, only the noninverting input is tested for EMIRR for the following three reasons:

- Op amp input pins are known to be the most sensitive to EMI, and typically rectify RF signals better than the supply or output pins.
- The noninverting and inverting op amp inputs have symmetrical physical layouts and exhibit nearly matching EMIRR performance
- EMIRR is more simple to measure on noninverting pins than on other pins because the noninverting input terminal can be isolated on a PCB. This isolation allows the RF signal to be applied directly to the noninverting input terminal with no complex interactions from other components or connecting PCB traces.

High-frequency signals conducted or radiated to any pin of the operational amplifier may result in adverse effects, as the amplifier would not have sufficient loop gain to correct for signals with spectral content outside the bandwidth. Conducted or radiated EMI on inputs, power supply, or output may result in unexpected DC offsets, transient voltages, or other unknown behavior. Take care to properly shield and isolate sensitive analog nodes from noisy radio signals and digital clocks and interfaces.

The EMIRR +IN of the OPAx189 is plotted versus frequency as shown in Figure 8-2. If available, any dual and quad op amp device versions have nearly similar EMIRR +IN performance. The OPAx189 unity-gain bandwidth is 14 MHz. EMIRR performance below this frequency denotes interfering signals that fall within the op amp bandwidth.

8.3.5 EMIRR +IN Test Configuration

Figure 8-3 shows the circuit configuration for testing the EMIRR +IN. An RF source is connected to the op amp noninverting input terminal using a transmission line. The op amp is configured in a unity-gain buffer topology with the output connected to a low-pass filter (LPF) and a digital multimeter (DMM). A large impedance mismatch at the op amp input causes a voltage reflection; however, this effect is characterized and accounted for when determining the EMIRR IN+. The multimeter samples and measures the resulting DC offset voltage. The LPF isolates the multimeter from residual RF signals that may interfere with multimeter accuracy.





Figure 8-3. EMIRR +IN Test Configuration



8.3.6 Electrical Overstress

Designers often ask questions about the capability of an operational amplifier to withstand electrical overstress. These questions tend to focus on the device inputs, but may involve the supply voltage pins or even the output pin. Each of these different pin functions have electrical stress limits determined by the voltage breakdown characteristics of the particular semiconductor fabrication process and specific circuits connected to the pin. Additionally, internal electrostatic discharge (ESD) protection is built into these circuits to protect from accidental ESD events both before and during product assembly.

Having a good understanding of this basic ESD circuitry and the relevance to an electrical overstress event is helpful. See Figure 8-4 for an illustration of the ESD circuits contained in the OPAx189 (indicated by the dashed line area). The ESD protection circuitry involves several current-steering diodes connected from the input and output pins and routed back to the internal power-supply lines, where the diodes meet at an absorption device internal to the operational amplifier. This protection circuitry is intended to remain inactive during normal circuit operation.



(1) V_{IN} = V+ + 500 mV.

(2) TVS: 40 V > $V_{\text{TVSBR (min)}}$ > V+ ; where $V_{\text{TVSBR (min)}}$ is the minimum specified value for the transient voltage suppressor breakdown voltage.

(3) Suggested value is approximately 5 k Ω in overvoltage conditions.

Figure 8-4. Equivalent Internal ESD Circuitry Relative to a Typical Circuit Application

An ESD event produces a short-duration, high-voltage pulse that is transformed into a short-duration, highcurrent pulse while discharging through a semiconductor device. The ESD protection circuits are designed to provide a current path around the operational amplifier core to prevent damage. The energy absorbed by the protection circuitry is then dissipated as heat.

When an ESD voltage develops across two or more amplifier device pins, current flows through one or more steering diodes. Depending on the path that the current takes, the absorption device may activate. The absorption device has a trigger or threshold voltage that is above the normal operating voltage of the OPAx189 but below the device breakdown voltage level. When this threshold is exceeded, the absorption device quickly activates and clamps the voltage across the supply rails to a safe level.

When the operational amplifier connects into a circuit (as shown in Figure 8-4), the ESD protection components are intended to remain inactive and do not become involved in the application circuit operation. However,



circumstances may arise where an applied voltage exceeds the operating voltage range of a given pin. Should this condition occur, there is a risk that some internal ESD protection circuits may be biased on, and conduct current. Any such current flow occurs through steering-diode paths and rarely involves the absorption device.

Figure 8-4 shows a specific example where the input voltage (V_{IN}) exceeds the positive supply voltage (V+) by 500 mV or more. Much of what happens in the circuit depends on the supply characteristics. If V+ can sink the current, one of the upper input steering diodes conducts and directs current to +V_S. Excessively high current levels can flow with increasingly higher V_{IN}. As a result, the data sheet specifications recommend that applications limit the input current to 10 mA.

If the supply is not capable of sinking the current, V_{IN} may begin sourcing current to the operational amplifier, and then take over as the source of positive supply voltage. The danger in this case is that the voltage can rise to levels that exceed the operational amplifier absolute maximum ratings.

Another common question involves what happens to the amplifier if an input signal is applied to the input while the power supplies V+ or V– are at 0 V. Again, this question depends on the supply characteristic while at 0 V, or at a level below the input signal amplitude. If the supplies appear as high impedance, then the operational amplifier supply current may be supplied by the input source through the current-steering diodes. This state is not a normal bias condition; the amplifier most likely does not operate normally. If the supplies are low impedance, then the current through the steering diodes can become quite high. The current level depends on the ability of the input source to deliver current, and any resistance in the input path.

If there is any uncertainty about the ability of the supply to absorb this current, external zener diodes must be added to the supply pins, as shown in Figure 8-4. The zener voltage must be selected such that the diode does not turn on during normal operation. However, the zener voltage must be low enough so that the zener diode conducts if the supply pin begins to rise above the safe operating supply voltage level.

8.3.7 MUX-Friendly Inputs

The OPAx189 features a proprietary input stage design that allows an input differential voltage to be applied while maintaining high input impedance. Typically, high-voltage CMOS or bipolar-junction input amplifiers feature anti-parallel diodes that protect input transistors from large V_{GS} voltages that may exceed the semiconductor process maximum and permanently damage the device. Large V_{GS} voltages can be forced when applying a large input step, switching between channels, or attempting to use the amplifier as a comparator.

OPAx189 solves these problems with a switched-input technique that prevents large input bias currents when large differential voltages are applied. This solves many issues seen in switched or multiplexed applications, where large disruptions to RC filtering networks are caused by fast switching between large potentials. OPAx189 offers outstanding settling performance due to these design innovations and built-in slew rate boost and wide bandwidth. The OPAx189 can also be used as a comparator. Differential and common-mode *Absolute Maximum Ratings* still apply relative to the power supplies.




8.3.8 Noise Performance

Figure 8-5 shows the total circuit noise for varying source impedances with the operational amplifier in a unity-gain configuration (with no feedback resistor network and therefore no additional noise contributions). The OPAx189 and OPA211 are shown with total circuit noise calculated. The op amp itself contributes both a voltage noise component and a current noise component. The voltage noise is commonly modeled as a time-varying component of the offset voltage. The current noise is modeled as the time-varying component of the input bias current and reacts with the source resistance to create a voltage component of noise. Therefore, the lowest noise op amp for a given application depends on the source impedance. For low source impedance, current noise is negligible, and voltage noise generally dominates. The OPAx189 family has both low voltage noise and low current noise because of the CMOS input of the op amp. As a result, the current noise contribution of the OPAx189 series is negligible for any practical source impedance, which makes this device the better choice for applications with high source impedance.

The equation in Figure 8-5 shows the calculation of the total circuit noise, with these parameters:

- e_n = voltage noise
- i_n = current noise
- R_S = source impedance
- k = Boltzmann's constant = 1.38×10^{-23} J/K
- T = temperature in kelvins (K)

For more details on calculating noise, see the Basic Noise Calculations section.



NOTE: $R_s = 3.6 k\Omega$ is indicated in Figure 8-5. This is the source impedance above which OPAx189 is a lower noise option than the OPA211.

Figure 8-5. Noise Performance of the OPAx189 and OPA211 in Unity-Gain Buffer Configuration

8.3.9 Basic Noise Calculations

Low-noise circuit design requires careful analysis of all noise sources. External noise sources can dominate in many cases; consider the effect of source resistance on overall op amp noise performance. Total noise of the circuit is the root-sum-square combination of all noise components.

The resistive portion of the source impedance produces thermal noise proportional to the square root of the resistance. This function is plotted in Figure 8-5. The source impedance is usually fixed; consequently, select the op amp and the feedback resistors to minimize the respective contributions to the total noise.

Figure 8-6 illustrates both noninverting (A) and inverting (B) op amp circuit configurations with gain. In circuit configurations with gain, the feedback network resistors also contribute noise. In general, the current noise of the op amp reacts with the feedback resistors to create additional noise components. However, the extremely low current noise of the OPAx189 means that the current noise contribution can be neglected.

The feedback resistor values can generally be chosen to make these noise sources negligible. Low impedance feedback resistors load the output of the amplifier. The equations for total noise are shown for both configurations. For additional resources on noise calculations visit *TI's Precision Labs Series*



(A) Noise in Noninverting Gain Configuration


R.

GND

 R_{s}

GND

Noise at the output is given as Eo, where:



(B) Noise in Inverting Gain Configuration

Noise at the output is given as E₀, where:

$$\begin{array}{c} \mathsf{R}_{1} & \mathsf{R}_{2} \\ \mathsf{R}_{5} & \mathsf{R}_{1} & \mathsf{R}_{2} \\ \mathsf{R$$

where:

- e_n is the voltage noise spectral density of the amplifier. For the OPAx189 series of operational amplifiers, e_n = ٠ 5.2 nV/ $\sqrt{\text{Hz}}$ at 1 kHz.
- in is the current noise spectral density of the amplifier. For the OPAx189 series of operational amplifiers, in = 165 fA/ $\sqrt{\text{Hz}}$ at 1 kHz.

Figure 8-6. Noise Calculation in Gain Configurations

8.4 Device Functional Modes

The OPAx189 has a single functional mode, and is operational when the power-supply voltage is greater than 4.5 V (±2.25 V). The maximum power supply voltage for the OPAx189 is 36 V (±18 V).



9 Application and Implementation

Note

Information in the following applications sections is not part of the TI component specification, and TI does not warrant its accuracy or completeness. TI's customers are responsible for determining suitability of components for their purposes, as well as validating and testing their design implementation to confirm system functionality.


9.1 Application Information

The OPAx189 operational amplifier combines precision offset and drift with excellent overall performance, making the series an excellent for many precision applications. The precision offset drift of only 0.005 μ V/°C provides stability over the entire temperature range. In addition, the device pairs excellent CMRR, PSRR, and A_{OL} dc performance with outstanding low-noise operation. As with all amplifiers, applications with noisy or high-impedance power supplies require decoupling capacitors close to the device pins. In most cases, 0.1- μ F capacitors are adequate.

The following application examples highlight only a few of the circuits where the OPAx189 can be used.

9.2 Typical Applications

9.2.1 25-kHz Low-Pass Filter



Copyright © 2017, Texas Instruments Incorporated

Figure 9-1. 25-kHz Low-Pass Filter

9.2.1.1 Design Requirements

Low-pass filters are commonly employed in signal processing applications to reduce noise and prevent aliasing. The OPAx189 devices are designed to construct high-speed, high-precision active filters. Figure 9-1 shows a second-order, low-pass filter commonly encountered in signal processing applications.

Use the following parameters for this design example:

- Gain = 5 V/V (inverting gain)
- Low-pass cutoff frequency = 25 kHz
- Second-order Chebyshev filter response with 3-dB gain peaking in the passband



9.2.1.2 Detailed Design Procedure

The infinite-gain multiple-feedback circuit for a low-pass network function is shown in Figure 9-1. Use Equation 1 to calculate the voltage transfer function.

$$\frac{Output}{Input}(s) = \frac{-1/R_1R_3C_2C_5}{s^2 + (s/C_2)(1/R_1 + 1/R_3 + 1/R_4) + 1/R_3R_4C_2C_5}$$
(1)

This circuit produces a signal inversion. For this circuit, the gain at dc and the low-pass cutoff frequency are calculated by Equation 2:

$$Gain = \frac{R_4}{R_1}$$
$$f_C = \frac{1}{2\pi} \sqrt{(1/R_3 R_4 C_2 C_5)}$$
(2)

Software tools are readily available to simplify filter design. WEBENCH[®] Filter Designer is a simple, powerful, and easy-to-use active filter design program. The WEBENCH[®] Filter Designer lets the user create optimized filter designs using a selection of TI operational amplifiers and passive components from TI's vendor partners.

Available as a web based tool from the WEBENCH Design Center, WEBENCH Filter Designer allows boardlevel designers to create, optimize, and simulate complete multistage active filter solutions within minutes.

9.2.1.3 Application Curve




Figure 9-2. OPAx189 Second-Order, 25-kHz, Chebyshev, Low-Pass Filter




9.2.2 Discrete INA + Attenuation for ADC With 3.3-V Supply

Note


The TINA-TI[™] software files shown in the following sections require that either the TINA[™] software (from DesignSoft[™]) or TINA-TI simulation software be installed. See Section 12.1.1.1 for more information.

Figure 9-3 shows an example of how the OPAx189 is used as a high-voltage, high-impedance front end for a precision, discrete instrumentation amplifier with attenuation. The INA159 provides the attenuation that allows this circuit to simply interface with 3.3-V or 5-V analog-to-digital converters (ADCs). Click the following link download the TINA-TI software file: Discrete INA.



Copyright © 2017, Texas Instruments Incorporated


(1) $V_{OUT} = V_{DIFF} \times (41 / 5) + (Ref 1) / 2$.





9.2.3 Bridge Amplifier

Figure 9-4 shows the basic configuration for a bridge amplifier. Click the following link to download the TINA-TI software file: Bridge Amplifier Circuit.



Copyright © 2017, Texas Instruments Incorporated

Figure 9-4. Bridge Amplifier

9.2.4 Low-Side Current Monitor

Figure 9-5 shows the OPAx189 configured in a low-side current-sensing application. The load current (I_{LOAD}) creates a voltage drop across the shunt resistor (R_{SHUNT}). This voltage is amplified by the OPAx189, with a gain of 201. In this example the load current is set from 0 A to 500 mA, which corresponds to an output voltage range from 0 V to 10 V. The output range can be adjusted by changing the shunt resistor or gain of the configuration. Click the following link to download the TINA-TI software file: Current-Sensing Circuit.





Figure 9-5. Low-Side Current Monitor



9.2.5 Programmable Power Supply

Figure 9-6 shows the OPAx189 configured as a precision programmable power supply using the 16-bit, voltage output DAC8581 and the OPA548 high-current amplifier. This application amplifies the digital-to-analog converter (DAC) voltage by a value of five, and handles a large variety of capacitive and current loads. The OPAx189 in the front-end provides precision and low drift across a wide range of inputs and conditions. Click the following link to download the TINA-TI software file: Programmable Power-Supply Circuit.




Copyright © 2017, Texas Instruments Incorporated

Figure 9-6. Programmable Power Supply

9.2.6 RTD Amplifier With Linearization

See *Analog Linearization of Resistance Temperature Detectors* for an in-depth analysis of Figure 9-7. Click the following link to download the TINA-TI software file: RTD Amplifier with Linearization.



(1) R₅ provides positive-varying excitation to linearize output.

Figure 9-7. RTD Amplifier With Linearization



9.3 System Examples

9.3.1 24-Bit, Delta-Sigma, Differential Load Cell or Strain Gauge Sensor Signal Conditioning

OPAx189 is used in a 24-bit, differential load cell or strain gauge sensor signal conditioning system alongside the ADS1225. A pair of OPAx189 amplifiers are configured in a two-amp instrumentation amplifier (IA) configuration and are band-limited to reduce noise and allow heavy capacitive drive. The load cell is powered by an excitation voltage (denoted V_{EX}) of 5-V and provides a differential voltage proportional to force applied. The differential voltage can be quite small and both outputs are biased to V_{EX} / 2.

In this example the OPAx189 is employed here due to the excellent input offset voltage (0.4 μ V) and input offset voltage drift (0.005 μ V/°C), the low broadband noise (5.2 nV/ \sqrt{Hz}) and zero-flicker noise, and excellent linearity and high input impedance. The two-amp IA configuration removes the dc bias and amplifies the differential signal of interest and drives the 24-bit, delta-sigma ADS1225 analog-to-digital converter (ADC) for acquisition and conversion. The ADS1225 features a 100-SPS data rate, single-cycle settling, and simple conversion control with the dedicated START pin.




Figure 9-8. 24-Bit, Differential Load Cell or Strain Gauge Sensor Signal Conditioning Schematic



10 Power Supply Recommendations

The OPAx189 is specified for operation from 4.5 V to 36 V (± 2.25 V to ± 18 V); many specifications apply from -40° C to $\pm 125^{\circ}$ C. The *Typical Characteristics* section presents parameters that can exhibit significant variance with regard to operating voltage or temperature.

CAUTION

Supply voltages larger than 40 V can permanently damage the device (see the *Absolute Maximum Ratings* table).

Place 0.1-µF bypass capacitors close to the power-supply pins to reduce errors coupling in from noisy or high-impedance power supplies. For more detailed information on bypass capacitor placement, see the *Layout* section.




11 Layout

11.1 Layout Guidelines

For best operational performance of the device, use good PCB layout practices, including:

- Noise can propagate into analog circuitry through the power pins of the circuit as a whole and the op amp itself. Bypass capacitors reduce the coupled noise by providing low-impedance power sources local to the analog circuitry.
 - Connect low-ESR, 0.1-µF ceramic bypass capacitors between each supply pin and ground, placed as close as possible to the device. A single bypass capacitor from V+ to ground is applicable for singlesupply applications.
- Separate grounding for analog and digital portions of circuitry is one of the simplest and most effective methods of noise suppression. One or more layers on multilayer PCBs are usually devoted to ground planes. A ground plane helps distribute heat and reduces EMI noise pickup. Make sure to physically separate digital and analog grounds paying attention to the flow of the ground current. For more detailed information, see *The PCB is a component of op amp design* techincal brief.
- To reduce parasitic coupling, run the input traces as far away as possible from the supply or output traces. If
 these traces cannot be kept separate, crossing the sensitive trace perpendicular is much better as opposed
 to in parallel with the noisy trace.
- Place the external components as close as possible to the device. As illustrated in Figure 11-1, keeping RF and RG close to the inverting input minimizes parasitic capacitance.
- Keep the length of input traces as short as possible. Always remember that the input traces are the most sensitive part of the circuit.
- Consider a driven, low-impedance guard ring around the critical traces. A guard ring can significantly reduce leakage currents from nearby traces that are at different potentials.
- For best performance, TI recommends cleaning the PCB following board assembly.
- Any precision integrated circuit may experience performance shifts due to moisture ingress into the plastic package. Following any aqueous PCB cleaning process, TI recommends baking the PCB assembly to remove moisture introduced into the device packaging during the cleaning process. A low temperature, post cleaning bake at 85°C for 30 minutes is sufficient for most circumstances.

11.2 Layout Example



Copyright © 2017, Texas Instruments Incorporated

Figure 11-1. Operational Amplifier Board Layout for Difference Amplifier Configuration



12 Device and Documentation Support

12.1 Device Support

12.1.1 Development Support

12.1.1.1 TINA-TI™ Simulation Software (Free Download)

TINA-TI simulation software is a simple, powerful, and easy-to-use circuit simulation program based on a SPICE engine. TINA-TI simulation software is a free, fully-functional version of the TINA software, preloaded with a library of macromodels in addition to a range of both passive and active models. TINA-TI simulation software provides all the conventional dc, transient, and frequency domain analysis of SPICE, as well as additional design capabilities.

Available as a free download from the Analog eLab Design Center, TINA-TI simulation software offers extensive post-processing capability that allows users to format results in a variety of ways. Virtual instruments offer the ability to select input waveforms and probe circuit nodes, voltages, and waveforms, creating a dynamic quick-start tool.

Note

These files require that either the TINA software (from DesignSoft) or TINA-TI software be installed. Download the free TINA-TI simulation software from the TINA-TI folder.

12.1.1.2 TI Precision Designs

TI Precision Designs are available online at http://www.ti.com/ww/en/analog/precision-designs/. TI Precision Designs are analog solutions created by TI's precision analog applications experts and offer the theory of operation, component selection, simulation, complete PCB schematic and layout, bill of materials, and measured performance of many useful circuits.

12.2 Documentation Support

12.2.1 Related Documentation

For related documentation see the following:

- Texas Instruments, Zero-drift Amplifiers: Features and Benefits application brief
- Texas Instruments, The PCB is a component of op amp design technical brief
- Texas Instruments, Operational amplifier gain stability, Part 3: AC gain-error analysis technical brief
- Texas Instruments, Operational amplifier gain stability, Part 2: DC gain-error analysis technical brief
- Texas Instruments, Using infinite-gain, MFB filter topology in fully differential active filters technical brief
- Texas Instruments, Op Amp Performance Analysis application bulletin
- Texas Instruments, Single-Supply Operation of Operational Amplifiers application bulletin
- Texas Instruments, Tuning in Amplifiers application bulletin
- Texas Instruments, Shelf-Life Evaluation of Lead-Free Component Finishes application report
- Texas Instruments, Feedback Plots Define Op Amp AC Performance application bulletin
- Texas Instruments, *EMI Rejection Ratio of Operational Amplifiers (With OPA333 and OPA333-Q1 as an Example)* application report
- · Texas Instruments, Analog linearization of resistance temperature detectors technical brief
- Texas Instruments, TI Precision Design TIPD102 High-Side Voltage-to-Current (V-I) Converter reference guide

12.3 Receiving Notification of Documentation Updates

To receive notification of documentation updates, navigate to the device product folder on ti.com. Click on *Subscribe to updates* to register and receive a weekly digest of any product information that has changed. For change details, review the revision history included in any revised document.

12.4 Support Resources

TI E2E[™] support forums are an engineer's go-to source for fast, verified answers and design help — straight from the experts. Search existing answers or ask your own question to get the quick design help you need.



Linked content is provided "AS IS" by the respective contributors. They do not constitute TI specifications and do not necessarily reflect TI's views; see TI's Terms of Use.

12.5 Trademarks

TINA-TI[™] and TI E2E[™] are trademarks of Texas Instruments. TINA[™] and DesignSoft[™] are trademarks of DesignSoft, Inc. Bluetooth[®] is a registered trademark of Bluetooth SIG, Inc. WEBENCH[®] is a registered trademark of Texas Instruments. All trademarks are the property of their respective owners.

12.6 Electrostatic Discharge Caution



This integrated circuit can be damaged by ESD. Texas Instruments recommends that all integrated circuits be handled with appropriate precautions. Failure to observe proper handling and installation procedures can cause damage.

ESD damage can range from subtle performance degradation to complete device failure. Precision integrated circuits may be more susceptible to damage because very small parametric changes could cause the device not to meet its published specifications.

12.7 Glossary

TI Glossary This glossary lists and explains terms, acronyms, and definitions.

13 Mechanical, Packaging, and Orderable Information

The following pages include mechanical packaging and orderable information. This information is the most current data available for the designated devices. This data is subject to change without notice and revision of this document. For browser-based versions of this data sheet, refer to the left-hand navigation.



PACKAGING INFORMATION

Orderable Device	Status (1)	Package Type	Package Drawing	Pins	Package Qty	Eco Plan (2)	Lead finish/ Ball material	MSL Peak Temp (3)	Op Temp (°C)	Device Marking (4/5)	Samples
OPA189ID	ACTIVE	SOIC	D	8	75	RoHS & Green	NIPDAU	Level-2-260C-1 YEAR	-40 to 125	OPA189	Samples
OPA189IDBVR	ACTIVE	SOT-23	DBV	5	3000	RoHS & Green	NIPDAU	Level-2-260C-1 YEAR	-40 to 125	1CTV	Samples
OPA189IDBVT	ACTIVE	SOT-23	DBV	5	250	RoHS & Green	NIPDAU	Level-2-260C-1 YEAR	-40 to 125	1CTV	Samples
OPA189IDGKR	ACTIVE	VSSOP	DGK	8	2500	RoHS & Green	NIPDAUAG	Level-2-260C-1 YEAR	-40 to 125	1CS6	Samples
OPA189IDGKT	ACTIVE	VSSOP	DGK	8	250	RoHS & Green	NIPDAUAG	Level-2-260C-1 YEAR	-40 to 125	1CS6	Samples
OPA189IDR	ACTIVE	SOIC	D	8	2500	RoHS & Green	NIPDAU	Level-2-260C-1 YEAR	-40 to 125	OPA189	Samples
OPA2189ID	ACTIVE	SOIC	D	8	75	RoHS & Green	SN	Level-2-260C-1 YEAR	-40 to 125	OP2189	Samples
OPA2189IDGKR	ACTIVE	VSSOP	DGK	8	2500	RoHS & Green	SN	Level-2-260C-1 YEAR	-40 to 125	1VQQ	Samples
OPA2189IDGKT	ACTIVE	VSSOP	DGK	8	250	RoHS & Green	SN	Level-2-260C-1 YEAR	-40 to 125	1VQQ	Samples
OPA2189IDR	ACTIVE	SOIC	D	8	2500	RoHS & Green	SN	Level-2-260C-1 YEAR	-40 to 125	OP2189	Samples
POPA4189IPWR	ACTIVE	TSSOP	PW	14	3000	Non-RoHS & Non-Green	Call TI	Call TI	-40 to 125		Samples

⁽¹⁾ The marketing status values are defined as follows:

ACTIVE: Product device recommended for new designs.

LIFEBUY: TI has announced that the device will be discontinued, and a lifetime-buy period is in effect.

NRND: Not recommended for new designs. Device is in production to support existing customers, but TI does not recommend using this part in a new design.

PREVIEW: Device has been announced but is not in production. Samples may or may not be available.

OBSOLETE: TI has discontinued the production of the device.

⁽²⁾ RoHS: TI defines "RoHS" to mean semiconductor products that are compliant with the current EU RoHS requirements for all 10 RoHS substances, including the requirement that RoHS substance do not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, "RoHS" products are suitable for use in specified lead-free processes. TI may reference these types of products as "Pb-Free".

RoHS Exempt: TI defines "RoHS Exempt" to mean products that contain lead but are compliant with EU RoHS pursuant to a specific EU RoHS exemption.

Green: TI defines "Green" to mean the content of Chlorine (CI) and Bromine (Br) based flame retardants meet JS709B low halogen requirements of <=1000ppm threshold. Antimony trioxide based flame retardants must also meet the <=1000ppm threshold requirement.

⁽³⁾ MSL, Peak Temp. - The Moisture Sensitivity Level rating according to the JEDEC industry standard classifications, and peak solder temperature.



PACKAGE OPTION ADDENDUM

⁽⁴⁾ There may be additional marking, which relates to the logo, the lot trace code information, or the environmental category on the device.

⁽⁵⁾ Multiple Device Markings will be inside parentheses. Only one Device Marking contained in parentheses and separated by a "~" will appear on a device. If a line is indented then it is a continuation of the previous line and the two combined represent the entire Device Marking for that device.

⁽⁶⁾ Lead finish/Ball material - Orderable Devices may have multiple material finish options. Finish options are separated by a vertical ruled line. Lead finish/Ball material values may wrap to two lines if the finish value exceeds the maximum column width.

Important Information and Disclaimer:The information provided on this page represents TI's knowledge and belief as of the date that it is provided. TI bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. TI has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. TI and TI suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

In no event shall TI's liability arising out of such information exceed the total purchase price of the TI part(s) at issue in this document sold by TI to Customer on an annual basis.


PACKAGE MATERIALS INFORMATION

www.ti.com

Texas Instruments

TAPE AND REEL INFORMATION





QUADRANT ASSIGNMENTS FOR PIN 1 ORIENTATION IN TAPE




*All dimensions are nominal												
Device	Package Type	Package Drawing		SPQ	Reel Diameter (mm)	Reel Width W1 (mm)	A0 (mm)	B0 (mm)	K0 (mm)	P1 (mm)	W (mm)	Pin1 Quadrant
OPA189IDBVR	SOT-23	DBV	5	3000	180.0	8.4	3.23	3.17	1.37	4.0	8.0	Q3
OPA189IDBVT	SOT-23	DBV	5	250	180.0	8.4	3.23	3.17	1.37	4.0	8.0	Q3
OPA189IDGKR	VSSOP	DGK	8	2500	330.0	12.4	5.3	3.4	1.4	8.0	12.0	Q1
OPA189IDGKT	VSSOP	DGK	8	250	330.0	12.4	5.3	3.4	1.4	8.0	12.0	Q1
OPA189IDR	SOIC	D	8	2500	330.0	12.4	6.4	5.2	2.1	8.0	12.0	Q1
OPA2189IDGKR	VSSOP	DGK	8	2500	330.0	12.4	5.3	3.4	1.4	8.0	12.0	Q1
OPA2189IDGKT	VSSOP	DGK	8	250	330.0	12.4	5.3	3.4	1.4	8.0	12.0	Q1
OPA2189IDR	SOIC	D	8	2500	330.0	12.8	6.4	5.2	2.1	8.0	12.0	Q1

TEXAS INSTRUMENTS

www.ti.com

PACKAGE MATERIALS INFORMATION

28-Apr-2021



Device	Package Type	Package Drawing	Pins	SPQ	Length (mm)	Width (mm)	Height (mm)
OPA189IDBVR	SOT-23	DBV	5	3000	213.0	191.0	35.0
OPA189IDBVT	SOT-23	DBV	5	250	213.0	191.0	35.0
OPA189IDGKR	VSSOP	DGK	8	2500	366.0	364.0	50.0
OPA189IDGKT	VSSOP	DGK	8	250	366.0	364.0	50.0
OPA189IDR	SOIC	D	8	2500	853.0	449.0	35.0
OPA2189IDGKR	VSSOP	DGK	8	2500	366.0	364.0	50.0
OPA2189IDGKT	VSSOP	DGK	8	250	366.0	364.0	50.0
OPA2189IDR	SOIC	D	8	2500	366.0	364.0	50.0

PW (R-PDSO-G14)

PLASTIC SMALL OUTLINE



A. An integration of the information o

Body length does not include mold flash, protrusions, or gate burrs. Mold flash, protrusions, or gate burrs shall not exceed 0,15 each side.

Body width does not include interlead flash. Interlead flash shall not exceed 0,25 each side.

E. Falls within JEDEC MO-153



D0008A



PACKAGE OUTLINE

SOIC - 1.75 mm max height

SMALL OUTLINE INTEGRATED CIRCUIT



NOTES:

1. Linear dimensions are in inches [millimeters]. Dimensions in parenthesis are for reference only. Controlling dimensions are in inches. Dimensioning and tolerancing per ASME Y14.5M.

- 2. This drawing is subject to change without notice.
- 3. This dimension does not include mold flash, protrusions, or gate burrs. Mold flash, protrusions, or gate burrs shall not exceed .006 [0.15] per side.
- 4. This dimension does not include interlead flash.
- 5. Reference JEDEC registration MS-012, variation AA.



D0008A

EXAMPLE BOARD LAYOUT

SOIC - 1.75 mm max height

SMALL OUTLINE INTEGRATED CIRCUIT



NOTES: (continued)

6. Publication IPC-7351 may have alternate designs.

7. Solder mask tolerances between and around signal pads can vary based on board fabrication site.



D0008A

EXAMPLE STENCIL DESIGN

SOIC - 1.75 mm max height

SMALL OUTLINE INTEGRATED CIRCUIT



NOTES: (continued)

8. Laser cutting apertures with trapezoidal walls and rounded corners may offer better paste release. IPC-7525 may have alternate design recommendations.

9. Board assembly site may have different recommendations for stencil design.



DGK (S-PDSO-G8)

PLASTIC SMALL-OUTLINE PACKAGE



NOTES: A. All linear dimensions are in millimeters.

B. This drawing is subject to change without notice.

Body length does not include mold flash, protrusions, or gate burrs. Mold flash, protrusions, or gate burrs shall not exceed 0.15 per end.

- D Body width does not include interlead flash. Interlead flash shall not exceed 0.50 per side.
- E. Falls within JEDEC MO-187 variation AA, except interlead flash.



DGK (S-PDSO-G8)

PLASTIC SMALL OUTLINE PACKAGE



NOTES: A. All linear dimensions are in millimeters.

- B. This drawing is subject to change without notice.
- C. Publication IPC-7351 is recommended for alternate designs.
- D. Laser cutting apertures with trapezoidal walls and also rounding corners will offer better paste release. Customers should contact their board assembly site for stencil design recommendations. Refer to IPC-7525 for other stencil recommendations.
- E. Customers should contact their board fabrication site for solder mask tolerances between and around signal pads.



DBV0005A



PACKAGE OUTLINE

SOT-23 - 1.45 mm max height

SMALL OUTLINE TRANSISTOR



NOTES:

- 1. All linear dimensions are in millimeters. Any dimensions in parenthesis are for reference only. Dimensioning and tolerancing per ASME Y14.5M. 2. This drawing is subject to change without notice. 3. Refernce JEDEC MO-178.

- 4. Body dimensions do not include mold flash, protrusions, or gate burrs. Mold flash, protrusions, or gate burrs shall not exceed 0.15 mm per side.



DBV0005A

EXAMPLE BOARD LAYOUT

SOT-23 - 1.45 mm max height

SMALL OUTLINE TRANSISTOR



NOTES: (continued)

5. Publication IPC-7351 may have alternate designs.

6. Solder mask tolerances between and around signal pads can vary based on board fabrication site.



DBV0005A

EXAMPLE STENCIL DESIGN

SOT-23 - 1.45 mm max height

SMALL OUTLINE TRANSISTOR



NOTES: (continued)

7. Laser cutting apertures with trapezoidal walls and rounded corners may offer better paste release. IPC-7525 may have alternate design recommendations.

8. Board assembly site may have different recommendations for stencil design.



IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (https://www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2021, Texas Instruments Incorporated