

# **UM1658 User manual**

## Discovery kit for STM32F030 Value Line microcontrollers

### Introduction

The STM32F030 Value Line Discovery kit (32F0308DISCOVERY) helps you to discover the device features and to develop your applications easily. It is based on STM32F030R8T6, an STM32 F0 series 32-bit ARM<sup>®</sup> Cortex™-M0 microcontroller, and includes an ST-LINK/V2 embedded debug tool, LEDs, push buttons and a prototyping board.




Figure 1. 32F0308DISCOVERY

DocID025097 Rev 1 September 2013 1/39 Contents UM1658

## **Contents**

1	Con	ventions	5
2	Quic	k start	6
	2.1	Getting started	6
	2.2	System requirements	6
	2.3	Development toolchains supporting the 32F0308DISCOVERY	3
	2.4	Order code	6
3	Feat	ures	7
4	Hard	lware and layout	3
	4.1	STM32F030R8T6 microcontroller1	1
	4.2	Embedded ST-LINK/V213	3
		4.2.1 Using ST-LINK/V2 to program/debug the STM32 F0 on board 14	4
		4.2.2 Using ST-LINK/V2 to program/debug an external STM32 application 19	5
	4.3	Power supply and power selection	6
	4.4	LEDs	6
	4.5	Push buttons	6
	4.6	JP2 (ldd)	6
	4.7	OSC clock	7
		4.7.1 OSC clock supply1	7
		4.7.2 OSC 32 KHz clock supply	7
	4.8	Solder bridges	8
	4.9	Extension connectors	9
5	Con	necting modules on the prototyping board 25	5
	5.1	Mikroelektronica accessory boards	5
	5.2	ST MEMS "adapter boards", standard DIL24 socket 28	3
	5.3	Arduino shield boards	1
6	Mec	hanical drawing	4
7	Elec	trical schematics	5
8	Revi	sion history	3

UM1658 List of tables

# List of tables

ON/OFF conventions	. 5
Jumper states	13
Debug connector CN3 (SWD)	15
Solder bridge settings	18
MCU pin description versus board function	19
Connecting using mikroBUS™	25
Connecting using IDC10	26
Connecting with a DIL24 board	28
Supported MEMS adapter boards	30
Connecting with Arduino shields	31
Document revision history	38
	Jumper states  Debug connector CN3 (SWD)  Solder bridge settings  MCU pin description versus board function  Connecting using mikroBUS™  Connecting using IDC10  Connecting with a DIL24 board  Supported MEMS adapter boards  Connecting with Arduino shields



List of figures UM1658

# List of figures

Figure 1.	32F0308DISCOVERY	. 1
Figure 2.	Hardware block diagram	. 8
Figure 3.	Top layout	. 9
Figure 4.	Bottom layout	10
Figure 5.	STM32F030R8T6 package	11
Figure 6.	STM32F030R8T6 block diagram	12
Figure 7.	Typical configuration	13
Figure 8.	32F0308DISCOVERY connections image	14
Figure 9.	ST-LINK connections image	15
Figure 10.	Using IDC10 and mikroBUS™ connectors	27
Figure 11.	DIL24 socket connections	29
Figure 12.	Arduino shield board connections	33
Figure 13.	32F0308DISCOVERY mechanical drawing	34
Figure 14.	32F0308DISCOVERY	35
Figure 15.	ST-LINK/V2 (SWD only)	36
Figure 16	MCU	37



UM1658 Conventions

## 1 Conventions

*Table 1* provides the definition of some conventions used in the present document.

**Table 1. ON/OFF conventions** 

Convention	Definition
Jumper JP1 ON	Jumper fitted
Jumper JP1 OFF	Jumper not fitted
Solder bridge SBx ON	SBx connections closed by solder
Solder bridge SBx OFF	SBx connections left open

Quick start UM1658

### 2 Quick start

The STM32F030 Value Line Discovery kit is a low-cost and easy-to-use development kit to quickly evaluate and start development with an STM32 F0 series microcontroller.

Before installing and using the product, please accept the Evaluation Product License Agreement from <a href="https://www.st.com/stm32f0-discovery">www.st.com/stm32f0-discovery</a>.

For more information on the STM32F030 Value Line Discovery kit and for demonstration software, visit <a href="https://www.st.com/stm32f0-discovery">www.st.com/stm32f0-discovery</a>.

### 2.1 Getting started

Follow the sequence below to configure the STM32F030 Value Line Discovery kit and launch the DISCOVER application:

- Check jumper position on the board, JP2 on, CN2 on (Discovery selected).
- Connect the 32F0308DISCOVERY board to a PC with a USB cable 'type A to mini-B' through USB connector CN1 to power the board. Red LED LD1 (PWR) and LD2 (COM) light up and green LED LD3 blinks.
- 3. Press user button B1 (bottom left corner of the board).
- 4. Observe how the green LED LD3 blinking changes according to USER button B1 clicks.
- 5. Each click on USER button B1 is confirmed by the blue LED LD4.
- 6. To study or modify the DISCOVER project related to this demo, visit <a href="https://www.st.com/stm32f0-discovery">www.st.com/stm32f0-discovery</a> and follow the tutorial.
- Discover the STM32F0 features, download and execute programs proposed in the list of projects.
- 8. Develop your own application using available examples.

## 2.2 System requirements

- Windows PC (XP, Vista, 7)
- USB type A to Mini-B USB cable

## 2.3 Development toolchains supporting the 32F0308DISCOVERY

- Altium®, TASKING™ VX-toolset
- ARM®, Atollic TrueSTUDIO®
- IAR™, EWARM (IAR Embedded Workbench®)
- Keil™, MDK-ARM™

#### 2.4 Order code

6/39

To order the STM32F030 Value Line Discovery kit, use the order code STM32F0308-DISCO.

DocID025097 Rev 1

UM1658 Features

### 3 Features

The STM32F030 Value Line Discovery kit offers the following features:

 STM32F030R8T6 microcontroller featuring 64 KB Flash, 8 KB RAM in an LQFP64 package

- On-board ST-LINK/V2 with selection mode switch to use the kit as a standalone ST-LINK/V2 (with SWD connector for programming and debugging)
- Board power supply: through USB bus or from an external 5 V supply voltage
- External application power supply: 3 V and 5 V
- Four LEDs:
  - LD1 (red) for 3.3 V power on
  - LD2 (red/green) for USB communication
  - LD3 (green) for PC9 output
  - LD4 (blue) for PC8 output
- Two push buttons (user and reset)
- Extension header for LQFP64 I/Os for quick connection to prototyping board and easy probing.
- An additional board is provided with the kit which can be connected to the extension connector for even easier prototyping and probing.
- A large number of free ready-to-run application firmware examples are available on www.st.com/stm32f0-discovery to support quick evaluation and development.

## 4 Hardware and layout

The STM32F030 Value Line Discovery board is designed around the STM32F030R8T6 microcontroller in a 64-pin LQFP package.

*Figure 2* illustrates the connections between the STM32F030R8T6 and its peripherals (ST-LINK/V2, push button, LEDs and connectors).

*Figure 3* and *Figure 4* help you to locate these features on the STM32F030 Value Line Discovery board.




Figure 2. Hardware block diagram

(red/green LED) LD2 LD1 (red LED) ST-LINK/V2 COM PWR 5V power supply 3V power supply input output input output GND GND VDD PB9 CN3 CN2 PC13 SWD connector ST-LINK/DISCOVERY PC14 selector PC15 PF0 PF1 GND • NRS1 PB3 PC0 PD2 PC1 • • PC2 • PC12 www.st.com/stm32f0-discovery PC3 PC11 IDD measurement ▶ Pe10 PA0 • PA1 PA15 PA2 PA14 SB1 (VDD) PA3 • PF4 PF6 • PF5 PA13 PA12 PA4 • PA11 PA5 • • SB3 (B1-USER) • PA6 • PA10 PA7 PA9 B2 reset button PA8 STM32F030R8T6 PC4 PC5 PC9 SB4 (B2-RESET) PB0 PC8 B1 user button PB1 • PC7 RESET ► R33 ■ PB2 PC6 (green LED) LD3 PB15 C23 PB11 LD4 (blue LED) PB14 PB12 • PB13 MB1134 revA STM32F0308-DISCO GND • GND MS31936V1

Figure 3. Top layout

Note: Pin 1 of CN2, CN3, P1 and P2 connectors are identified by a square.

SB5, SB7, SB9, SB11 (RESERVED)-• SB6, SB8, SB10, SB12 •••• (DEFAULT) SB13 (STM\_RST)-SB14, SB15 (RX, TX)~ • -SB16, SB17 (X2 crystal) -SB18 (MCO) • SB19 (NRST) -SB20, SB21 (X3 crystal) • -SB22 (T\_SWO) • • SN • • • • • MS30025V1


Figure 4. Bottom layout



#### 4.1 STM32F030R8T6 microcontroller

The STM32F030R8T6 microcontroller incorporates the high-performance ARM Cortex™-M0 32-bit RISC core operating at a 48 MHz frequency, high-speed embedded memories (up to 64 Kbytes of Flash memory and up to 8 Kbytes of SRAM), and an extensive range of enhanced peripherals and I/Os. All devices offer standard communication interfaces (up to two I<sup>2</sup>Cs, up to two SPIs, and up to two USARTs), one 12-bit ADC, up to 6 general-purpose 16-bit timers and an advanced-control PWM timer.

Figure 5. STM32F030R8T6 package



The STM32F030R8T6 microcontroller operates in the -40 to +85 °C temperature range, from a 2.4 V to 3.6 V power supply. A comprehensive set of power-saving modes allows the design of low-power applications.

These features make the STM32F030R8T6 microcontroller suitable for a wide range of applications such as application control and user interfaces, handheld equipment, A/V receivers and digital TV, PC peripherals, gaming platforms, e-bikes, consumer appliances, printers, scanners, alarm systems, video intercoms, and HVACs.




Figure 6. STM32F030R8T6 block diagram



#### 4.2 Embedded ST-LINK/V2

The ST-LINK/V2 programming and debugging tool is integrated on the 32F0308DISCOVERY. The embedded ST-LINK/V2 can be used in 2 different ways according to the jumper states (see *Table 2*):

- Program/debug the MCU on board,
- Program/debug an MCU in an external application board using a cable connected to SWD connector CN3.

The embedded ST-LINK/V2 supports only SWD for STM32 devices. For information about debugging and programming features refer to user manual UM1075 (*ST-LINK/V2 in-circuit debugger/programmer for STM8 and STM32*) which describes in detail all the ST-LINK/V2 features.

Figure 7. Typical configuration



Hardware requirements:

- USB cable type A to mini-B
- computer with Windows XP, Vista or 7

Development toolchain: Altium, TASKING VX-Toolset, Atollic, TrueSTUDIO IAR, EWARM Keil, MDK-ARM

MS19052V2

Table 2. Jumper states

Jumper state	Description
Both CN2 jumpers ON	ST-LINK/V2 functions enabled for on board programming (default)
Both CN2 jumpers OFF	ST-LINK/V2 functions enabled for application through external CN3 connector (SWD supported)

### 4.2.1 Using ST-LINK/V2 to program/debug the STM32 F0 on board

To program the STM32 F0 on board, simply plug in the two jumpers on CN2, as shown in *Figure 8* in red, but do not use the CN3 connector as that could disturb communication with the STM32F030R8T6 of the 32F0308DISCOVERY.

CN3
SWD connector

SWD connector

SWD connector

SWD connector

SWD connector

CN2
SWD connector

CN2 jumpers on

CN3 jumpers on

Figure 8. 32F0308DISCOVERY connections image

4

### 4.2.2 Using ST-LINK/V2 to program/debug an external STM32 application


It is very easy to use the ST-LINK/V2 to program the STM32 on an external application. Simply remove the 2 jumpers from CN2 as shown in *Figure 9*, and connect your application to the CN3 debug connector according to *Table 3*.

Note: SB19 and SB22 must be OFF if you use CN3 pin 5 in your external application.

Table 3. Debug connector CN3 (SWD)

	` `	
Pin	CN3	Designation
1	VDD_TARGET	VDD from application
2	SWCLK	SWD clock
3	GND	Ground
4	SWDIO	SWD data input/output
5	NRST	RESET of target MCU
6	SWO	Reserved

Figure 9. ST-LINK connections image



### 4.3 Power supply and power selection

The power supply is provided either by the host PC through the USB cable, or by an external 5 V power supply.

The D1 and D2 diodes protect the 5 V and 3 V pins from external power supplies:

- 5 V and 3 V can be used as output power supplies when another application board is connected to pins P1 and P2.
  - In this case, the 5 V and 3 V pins deliver a 5 V or 3 V power supply and power consumption must be lower than 100 mA.
- 5 V can also be used as input power supplies; for example, when the USB connector is not connected to the PC.
  - In this case, the 32F0308DISCOVERY board must be powered by a power supply unit or by auxiliary equipment complying with standard EN-60950-1: 2006+A11/2009, and must be Safety Extra Low Voltage (SELV) with limited power capability.

#### 4.4 LEDs

- LD1 PWR: Red LED indicates that the board is powered.
- LD2 COM: Tricolor LED (COM) advises on the communication status as follows:
  - Slow blinking Red LED/Off: At power on before USB initialization
  - Fast blinking Red LED/Off: After the first correct communication between PC and STLINK/V2 (enumeration)
  - Red LED On: When initialization between PC and ST-LINK/V2 is successfully finished
  - Green LED On: After successful target communication initialization
  - Blinking Red/Green LED: During communication with target
  - Red LED On: Communication finished and OK
  - Orange LED On: Communication failure
- User LD3: Green user LED connected to the I/O PC9 of the STM32F030R8T6.
- User LD4: Blue user LED connected to the I/O PC8 of the STM32F030R8T6.

#### 4.5 Push buttons

- B1 USER: User push button connected to the I/O PA0 of the STM32F030R8T6.
- B2 RESET: Push button used to RESET the STM32F030R8T6.

## 4.6 JP2 (ldd)

Jumper JP2, labeled Idd, allows the consumption of STM32F030R8T6 to be measured by removing the jumper and connecting an ammeter.

- Jumper on: STM32F030R8T6 is powered (default).
- Jumper off: an ammeter must be connected to measure the STM32F030R8T6 current, (if there is no ammeter, the STM32F030R8T6 is not powered).

16/39 DocID025097 Rev 1



#### 4.7 OSC clock

### 4.7.1 OSC clock supply

PF0 and PF1 can be used as GPIO or as HSE oscillator. By default these I/Os are configured as GPIO, so SB16 and SB17 are closed, SB18 is open and R22, R23, C13 and C14 are not populated.

An external HSE clock can be provided to the MCU in three ways:

- MCO from ST-LINK. From MCO of the STM32F103. This frequency cannot be changed, it is fixed at 8 MHz and connected to PF0-OSC\_IN of the STM32F030R8T6. Configuration needed:
  - SB16, SB18 CLOSED
  - R22, R23 removed
  - SB17 OPEN
- Oscillator onboard. From X2 crystal (not provided). For typical frequencies and its capacitors and resistors, please refer to the STM32F030R8T6 datasheet. Configuration needed:
  - SB16, SB17, SB18 OPEN
  - R22, R23, C13, C14 soldered
- Oscillator from external PF0. From external oscillator through pin 7 of the P1 connector. Configuration needed:
  - SB16, SB17 CLOSED
  - SB18 OPEN
  - R22 and R23 removed

#### 4.7.2 OSC 32 KHz clock supply

PC14 and PC15 can be used as GPIO or as LSE oscillator. By default these I/Os are configured as GPIO, so SB20 & SB21 are closed and X3, R24, R25 are not populated.

An external LSE clock can be provided to the MCU in two ways:

- Oscillator onboard. From X3 crystal (not provided). Configuration needed:
  - SB20, SB21 OPEN
  - C15, C16, R24 and R25 soldered.
- Oscillator from external PC14. From external oscillator trough the pin 5 of P1 connector. Configuration needed:
  - SB20, SB21 CLOSED
  - R24 and R25 removed

## 4.8 Solder bridges

Table 4. Solder bridge settings

Bridge	State <sup>(1)</sup>	Description
SB16,17	OFF	X2, C13, C14, R22 and R23 provide a clock. PF0, PF1 are disconnected from P1.
(X2 crystal) <sup>(2)</sup>	ON	PF0, PF1 are connected to P1 (R22, R23 and SB18 must not be fitted).
SB6,8,10,12 (Default)	ON	Reserved, do not modify.
SB5,7,9,11 (Reserved)	OFF	Reserved, do not modify.
SB20,21	OFF	X3, C15, C16, R24 and R25 deliver a 32 KHz clock. PC14, PC15 are not connected to P1.
(X3 crystal)	ON	PC14, PC15 are only connected to P1 (R24, R25 must not be fitted).
SB4	ON	B2 push button is connected to the NRST pin of the STM32F030R8T6 MCU.
(B2-RESET)	OFF	B2 push button is not connected the NRST pin of the STM32F030R8T6 MCU.
SB3	ON	B1 push button is connected to PA0.
(B1-USER)	OFF	B1 push button is not connected to PA0.
SB1	ON	VDD_3 must be permanently connected to VDD for normal use.
(VDD_3)	OFF	Reserved, do not modify.
SB14,15	OFF	Reserved, do not modify.
(RX,TX)	ON	Reserved, do not modify.
SB19	ON	NRST signal of the CN3 connector is connected to the NRST pin of the STM32F030R8T6 MCU.
(NRST)	OFF	NRST signal of the CN3 connector is not connected to the NRST pin of the STM32F030R8T6 MCU.
SB22	ON	SWO signal of the CN3 connector is connected to PB3.
(T_SWO)	OFF	SWO signal is not connected.
SB13	OFF	No incidence on STM32F103C8T6 (ST-LINK/V2) NRST signal.
(STM_RST)	ON	STM32F103C8T6 (ST-LINK/V2) NRST signal is connected to GND.
SB2	ON	BOOT0 signal of the STM32F030R8T6 MCU is held low through a 510 Ohm pull-down resistor.
(BOOT0)	OFF	BOOT0 signal of the STM32F030R8T6 MCU can be set high through a 10 KOhm pull-up resistor R27 to solder.
SB18	ON	Provides the 8 MHz for OSC_IN from MCO of STM32F030R8T6.
(MCO) <sup>(2)</sup>	OFF	See SB16, SB17 description.

<sup>1.</sup> Default SBx state is shown in bold.

OSC\_IN clock comes from MCO if SB18 is ON and SB16,17 are OFF and comes from X2 if SB18 is OFF and SB16,17 are ON.

### 4.9 Extension connectors

The male headers P1 and P2 can connect the 32F0308DISCOVERY to a standard prototyping/wrapping board. STM32F030R8T6 GPI/Os are available on these connectors. P1 and P2 can also be probed by an oscilloscope, logical analyzer or voltmeter.

Table 5. MCU pin description versus board function

	MCU pin		Board function								
Main function	Alternate functions	LQFP64	Push button	LED	SWD	osc	Free I/O	Power supply	CN3	P1	P2
воото	воото	60									6
NRST	NRST	7	RESET		NRST				5	10	
PA0	USART1_CTS, USART2_CTS, ADC_IN0, RTC_TAMP2, WKUP1	14	USER							15	
PA1	USART1_RTS, USART2_RTS, EVENTOUT, ADC_IN1	15								16	
PA2	USART1_TX, USART2_TX, TIM15_CH1, ADC_IN2	16								17	
PA3	USART1_RX, USART2_RX, TIM15_CH2, ADC_IN3	17								18	
PA4	SPI1_NSS, USART1_CK USART2_CK, TIM14_CH1, ADC_IN4	20								21	
PA5	SPI1_SCK, ADC_IN5	21								22	

Table 5. MCU pin description versus board function (continued)

	MCU pin	-				Boar	d fun	ction			
Main function	Alternate functions	LQFP64	Push button	LED	SWD	osc	Free I/O	Power supply	CN3	Ρ1	P2
PA6	SPI1_MISO, TIM3_CH1, TIM1_BKIN, TIM16_CH1, EVENTOUT, ADC_IN6	22								23	
PA7	SPI1_MOSI, TIM3_CH2, TIM14_CH1, TIM1_CH1N, TIM17_CH1, EVENTOUT, ADC_IN7	23								24	
PA8	USART1_CK, TIM1_CH1, EVENTOUT, MCO	41									25
PA9	USART1_TX, TIM1_CH2, TIM15_BKIN, I2C1_SCL	42									24
PA10	USART1_RX, TIM1_CH3, TIM17_BKIN, I2C1_SDA	43									23
PA11	USART1_CTS, TIM1_CH4, EVENTOUT	44									22
PA12	USART1_RTS, TIM1_ETR, EVENTOUT	45									21
PA13	IR_OUT, SWDIO	46			SWDIO				4		20
PA14	USART1_TX, USART2_TX, SWCLK	49			SWCLK				2		17

UM1658 Hardware and layout

Table 5. MCU pin description versus board function (continued)

	MCU pin	<u>-</u>	Board function								
Main function	Alternate functions	LQFP64	Push button	LED	SWD	osc	Free I/O	Power supply	CN3	Р1	P2
PA15	SPI1_NSS, USART1_RX, USART2_RX, EVENTOUT	50									16
PB0	TIM3_CH3, TIM1_CH2N, EVENTOUT	26								27	
PB1	TIM3_CH4, TIM14_CH1, TIM1_CH3N	27								28	
PB2	-	28								29	
PB3	SPI1_SCK, EVENTOUT	55			SWO				6		11
PB4	SPI1_MISO, TIM3_CH1, EVENTOUT	56									10
PB5	SPI1_MOSI, I2C1_SMBA, TIM16_BKIN, TIM3_CH2	57									9
PB6	I2C1_SCL, USART1_TX, TIM16_CH1N	58									8
PB7	I2C1_SDA, USART1_RX, TIM17_CH1N	59									7
PB8	I2C1_SCL, TIM16_CH1	61									4
PB9	I2C1_SDA, IR_OUT, TIM17_CH1, EVENTOUT	62									3
PB10	I2C1_SCL, I2C2_SCL	29								30	



Table 5. MCU pin description versus board function (continued)

	MCU pin	•	Board function								
Main function	Alternate functions	LQFP64	Push button	LED	SWD	osc	Free I/O	Power supply	CN3	P1	P2
PB11	I2C1_SDA, I2C2_SDA, EVENTOUT	30								31	
PB12	SPI1_NSS, SPI2_NSS, TIM1_BKIN, EVENTOUT	33								32	
PB13	SPI1_SCK, SPI2_SCK, TIM1_CH1N	34									32
PB14	SPI1_MISO, SPI2_MISO, TIM1_CH2N, TIM15_CH1	35									31
PB15	SPI1_MOSI, SPI2_MOSI, TIM1_CH3N, TIM15_CH1N, TIM15_CH2	36									30
PC0	EVENTOUT ADC_IN10	8								11	
PC1	EVENTOUT ADC_IN11	9								12	
PC2	EVENTOUT ADC_IN12	10								13	
PC3	EVENTOUT ADC_IN13	11								14	
PC4	EVENTOUT ADC_IN14	24								25	
PC5	ADC_IN15	25								26	
PC6	TIM3_CH1	37									29
PC7	TIM3_CH2	38									28
PC8	TIM3_CH3	39		BLUE							27
PC9	TIM3_CH4	40		GREEN							26
PC10	-	51									15

UM1658 Hardware and layout

Table 5. MCU pin description versus board function (continued)

	MCU pin	<u>-                                      </u>				Boar	d fun	ction			
Main function	Alternate functions	LQFP64	Push button	LED	SWD	osc	Free I/O	Power supply	CN3	Ρ1	P2
PC11	-	52									14
PC12	-	53									13
PC13	RTC_TAMP1, RTC_TS, RTC_OUT, WKUP2	2								4	
PC14- OSC32_ IN	OSC32_IN	3				OSC32_IN				5	
PC15- OSC32_ OUT	OSC32_OUT	4				OSC32_OUT				6	
PD2	TIM3_ETR	54									12
PF0- OSC_IN	OSC_IN	5				OSC_IN				7	
PF1- OSC_ OUT	OSC_OUT	6				OSC_OUT				8	
PF4	EVENTOUT	18								19	
PF5	EVENTOUT	19								20	
PF6	I2C1_SCL, I2C2_SCL	47									19
PF7	I2C1_SDA, I2C2_SDA	48									18
VDD_3	VDD	1								3	
VDD_1		64									
VDD_2		32									
VDDA		13									



Table 5. MCU pin description versus board function (continued)

	MCU pin					Boar	d fun	ction			
Main function	Alternate functions	LQFP64	Push button	LED	SWD	osc	Free I/O	Power supply	CN3	Р1	P2
VSS_1		63									
VSS_2		31									
VSSA		12									
								5V			1
								3V		1	
								VDD			5
								GND		2	2
					GND			GND	3		
								GND		9	
								GND		33	33

## 5 Connecting modules on the prototyping board

This section gives some examples of how to connect ready-to-use modules available from different manufacturers to the STM32F030 Value Line Discovery kit via the prototyping board included in the kit.

Software examples, based on the connections described below, are available at <a href="https://www.st.com/stm32f0-discovery">www.st.com/stm32f0-discovery</a>.

## 5.1 Mikroelektronica accessory boards

Mikroelektronika, http://www.mikroe.com, has specified two standard connectors for their accessory boards, named mikroBUS™ (http://www.mikroe.com/mikrobus\_specs.pdf) and IDC10.

MikroBUS™ is a 16-pin connector to connect accessory boards very quickly and easily to a microcontroller board through SPI, USART or I<sup>2</sup>C communications, along with additional pins such as Analog Input, PWM and Interrupt.

The set of mikroElektronika boards compatible with mikroBUS™ is called "Click boards".

IDC10 is a 10-pin connector to connect the general purpose I/O of an MCU to other accessory boards.

The tables below are one solution for connecting mikroBUS<sup>™</sup> and IDC boards to the 32F0308DISCOVERY; this solution used in the different examples is available at <a href="https://www.st.com/stm32f0-discovery">www.st.com/stm32f0-discovery</a>.

Mikroelektronica mikroBUS™ 32F0308DISCOVERY Pin Description Pin Description PA4 AN Analog pin DAC1 OUT **PB13** GPIO OUTPUT (5V tolerant) **RST** Reset pin CS SPI Chip Select line **PA11** GPIO OUTPUT (5V tolerant) SCK SPI Clock line PB3 SPI1 SCK **MISO** SPI Slave Output line PB4 SPI1 MISO PB5 SPI1\_MOSI MOSI SPI Slave Input line **PWM** PWM output line PA8 TIM1\_CH1 PB12 GPIO INPUT EXTI (5V tolerant) INT Hardware Interrupt line RX **UART** Receive line PA3 USART2\_RX TX **UART Transmit line** PA2 USART2\_TX SCL **I2C Clock line** PF6 I2C2\_SCL I2C Data line PF7 SDA I2C2\_SDA 5V VCC 5V power line 5V Power line

Table 6. Connecting using mikroBUS™

Table 7. Connecting using IDC10

Mikroele	Mikroelektronica IDC10 connector		32F0308DISCOVERY		
P0	GPIO	PC0	GPIO OUTPUT (3.3V tolerant)		
P1	GPIO	PC1	GPIO OUTPUT (3.3V tolerant)		
P2	GPIO	PC2	GPIO OUTPUT (3.3V tolerant)		
P3	GPIO	PC3	GPIO OUTPUT (3.3V tolerant)		
P4	GPIO	PC4	GPIO OUTPUT (3.3V tolerant)		
P5	GPIO	PC5	GPIO OUTPUT (3.3V tolerant)		
P6	GPIO	PC6	GPIO OUTPUT (5V tolerant)		
P7	GPIO	PC7	GPIO OUTPUT (5V tolerant)		
VCC	VCC 5V power line	3V	VDD		
GND	Reference Ground	GND	VSS		
P0	GPIO	PC0	GPIO OUTPUT (3.3V tolerant)		
P1	GPIO	PC1	GPIO OUTPUT (3.3V tolerant)		
P2	GPIO	PC2	GPIO OUTPUT (3.3V tolerant)		
P3	GPIO	PC3	GPIO OUTPUT (3.3V tolerant)		

The *Figure 10* illustrates the connections between the 32F0308DISCOVERY and the 2 connectors, IDC10 and mikroBUS $^{\text{TM}}$ .




Figure 10. Using IDC10 and mikroBUS™ connectors



## 5.2 ST MEMS "adapter boards", standard DIL24 socket

STMicroelectronics has defined a standard DIL24 connector to easily evaluate its MEMS sensors connected to a microcontroller through SPI or I2C communications.

*Table 8* is one solution for connecting the DIL24 boards to the 32F0308DISCOVERY, this solution is used in different examples and available at <a href="https://www.st.com/stm32f0-discovery">www.st.com/stm32f0-discovery</a>.

Table 8. Connecting with a DIL24 board

ST MEMS DIL24 Eval board		32F0308DISCOVERY		
P01	VDD Power supply	3V	VDD	
P02	Vdd_IO Power supply for I/O pins	3V	VDD	
P03	NC			
P04	NC			
P05	NC			
P06	NC			
P07	NC			
P08	NC			
P09	NC			
P10	NC			
P11	NC			
P12	NC			
P13	GND 0V supply	GND	GND	
P14	INT1 Inertial interrupt 1	PB12	GPIO INPUT EXTI (5V tolerant)	
P15	INT2 inertial interrupt 2	PB11	GPIO INPUT EXTI (5V tolerant)	
P16	NC			
P17	NC			
P18	NC			
P19	CS - 0:SPI enabled 1:I2C mode	PA11	GPIO OUTPUT (5V tolerant)	
P20	SCL (I2C serial clock) SPC (SPI serial clock)	PB6 PB3	I2C1_SCL SPI1_SCK	
P21	SDA I2C Serial Data SDI SPI Serial Data Input	PB7 PB5	I2C1_SDA SPI1_MOSI	
P22	SDO SPI Serial Data Output I2C less significant bit of the device address	PB4	SPI1_MISO	
P23	NC			
P24	NC			

28/39 DocID025097 Rev 1

*Figure 11* illustrates the connections between the 32F0308DISCOVERY and the DIL24 socket.




Figure 11. DIL24 socket connections



## **Supported MEMS adapter boards**

Table 9 is a list of supported MEMS adapter boards as of April, 2012.

Table 9. Supported MEMS adapter boards

ST MEMS DIL24 Eval Board	Core product
STEVAL-MKI009V1	LIS3LV02DL
STEVAL-MKI013V1	LIS302DL
STEVAL-MKI015V1	LIS344ALH
STEVAL-MKI082V1	LPY4150AL
STEVAL-MKI083V1	LPY450AL
STEVAL-MKI084V1	LPY430AL
STEVAL-MKI085V1	LPY410AL
STEVAL-MKI086V1	LPY403AL
STEVAL-MKI087V1	LIS331DL
STEVAL-MKI088V1	LIS33DE
STEVAL-MKI089V1	LIS331DLH
STEVAL-MKI090V1	LIS331DLF
STEVAL-MKI091V1	LIS331DLM
STEVAL-MKI092V1	LIS331HH
STEVAL-MKI095V1	LPR4150AL
STEVAL-MKI096V1	LPR450AL
STEVAL-MKI097V1	LPR430AL
STEVAL-MKI098V1	LPR410AL
STEVAL-MKI099V1	LPR403AL
STEVAL-MKI105V1	LIS3DH
STEVAL-MKI106V1	LSM303DLHC
STEVAL-MKI107V1	L3G4200D
STEVAL-MKI107V2	L3GD20
STEVAL-MKI108V1	9AXISMODULE v1 [LSM303DLHC + L3G4200D]
STEVAL-MKI108V2	9AXISMODULE v2 [LSM303DLHC + L3GD20]
STEVAL-MKI110V1	AIS328DQ
STEVAL-MKI113V1	LSM303DLM
STEVAL-MKI114V1	MAG PROBE (based on LSM303DLHC)
STEVAL-MKI120V1	LPS331AP
STEVAL-MKI122V1	LSM330DLC
STEVAL-MKI123V1	LSM330D




Table 9. Supported MEMS adapter boards (continued)

ST MEMS DIL24 Eval Board	Core product
STEVAL-MKI124V1	10AXISMODULE [LSM303DLHC + L3GD20+ LPS331AP]
STEVAL-MKI125V1	A3G4250D

Note:

For an up-to-date list, visit http://www.st.com/internet/evalboard/subclass/1116.jsp. The DIL24 boards are described as "adapter boards" in the field "General Description".

## 5.3 Arduino shield boards

Arduino™ is an open-source electronics prototyping platform based on flexible, easy-to-use hardware and software. See http://www.arduino.cc for more information.

Arduino accessory boards are called "Shields" and can be easily connected to the 32F0308DISCOVERY according to the following table.

Table 10. Connecting with Arduino shields

Arduino power connector		32F0308DISCOVERY		
Reset	Reset from Shield board	NRST	Reset discovery	
3V3	VCC 3.3V power line	3V	VDD	
5V	VCC 5V power line	5V	VDD	
GND	Reference Ground	GND	Reference Ground	
GND	Reference Ground	GND	Reference Ground	
Vin	External alimentation	3 V	Jumper fitted to power board by External 3 V power supply.	
Arduino analog in connector		32F0308DISCOVERY		
A0	Analog input or Digital pin 14	PC0	ADC_IN10	
A1	Analog input or Digital pin 15	PC1	ADC_IN11	
A2	Analog input or Digital pin 16	PC2	ADC_IN12	
A3	Analog input or Digital pin 17	PC3	ADC_IN13	
A4	Analog input or SDA or Digital pin 18	PC4 or PF7	ADC_IN14 or I2C2_SDA	
A5	Analog input or SCL or Digital pin 19	PC5 or PF6	ADC_IN15 or I2C2_SCL	

Table 10. Connecting with Arduino shields (continued)

Arduino digital connector		32F0308DISCOVERY		
D0	Digital pin 0 or RX	PA3	USART2_RX	
D1	Digital pin 1 or TX	PA2	USART2_TX	
D2	Digital pin 2 / External interrupt	PB12	EXTI (5V tolerant)	
D3	Digital pin 3 / Ext int or PWM	PB11	EXTI (5V tolerant) or TIM2_CH4	
D4	Digital pin 4	PA7	GPIO (3V tolerant)	
D5	Digital pin 5 or PWM	PB9	TIM17_CH1	
D6	Digital pin 6 or PWM	PB8	TIM16_CH1	
D7	Digital pin 7	PA6	GPIO (3V tolerant)	
D8	Digital pin 8	PA5	GPIO (3V tolerant)	
D9	Digital pin 9 or PWM	PA4	TIM14_CH1	
D10	Digital pin 10 or CS or PWM	PA11	TIM1_CH4	
D11	Digital pin 11 or MOSI or PWM	PB5	SPI1_MOSI or TIM3_CH2	
D12	Digital pin 12 or MISO	PB4	SPI1_MISO	
D13	Digital pin 13 or SCK	PB3	SPI1_SCK	
GND	Reference Ground	GND	Reference Ground	
AREF	ADC voltage reference	NC	Not connected	
Arduino ICSP connector		32	F0308DISCOVERY	
1	MISO	PB4	SPI1_MISO	
2	VCC 3.3V	3V	VDD	
3	SCK	PB3	SPI1_SCK	
4	MOSI	PB5	SPI1_MOSI	
5	RST	NRST	Reset discovery	
6	GND	GND	Reference Ground	

32/39 DocID025097 Rev 1

*Figure 12* illustrates the connections between the 32F0308DISCOVERY and the Arduino shield boards.




Figure 12. Arduino shield board connections

Mechanical drawing UM1658

## 6 Mechanical drawing




Figure 13. 32F0308DISCOVERY mechanical drawing

UM1658 Electrical schematics

## 7 Electrical schematics

Figure 14. 32F0308DISCOVERY **STMicroelectronics** STM32F030 DISCOVERY T\_NRST T\_SWO ST\_LINK\_V2.SCHDOC U\_ST\_LINK

Electrical schematics UM1658




Figure 15. ST-LINK/V2 (SWD only)



UM1658 Electrical schematics

Figure 16. MCU SW-PUSH-CMS STM32F030 DISCOVERY MCU **STMicroelectronics** U3 STM32F030R8T6 Close to STM32

Revision history UM1658

# 8 Revision history

38/39

**Table 11. Document revision history** 

Date	Revision	Changes
03-Sep-2013	1	Initial release.

#### Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

ST PRODUCTS ARE NOT AUTHORIZED FOR USE IN WEAPONS. NOR ARE ST PRODUCTS DESIGNED OR AUTHORIZED FOR USE IN: (A) SAFETY CRITICAL APPLICATIONS SUCH AS LIFE SUPPORTING, ACTIVE IMPLANTED DEVICES OR SYSTEMS WITH PRODUCT FUNCTIONAL SAFETY REQUIREMENTS; (B) AERONAUTIC APPLICATIONS; (C) AUTOMOTIVE APPLICATIONS OR ENVIRONMENTS, AND/OR (D) AEROSPACE APPLICATIONS OR ENVIRONMENTS. WHERE ST PRODUCTS ARE NOT DESIGNED FOR SUCH USE, THE PURCHASER SHALL USE PRODUCTS AT PURCHASER'S SOLE RISK, EVEN IF ST HAS BEEN INFORMED IN WRITING OF SUCH USAGE, UNLESS A PRODUCT IS EXPRESSLY DESIGNATED BY ST AS BEING INTENDED FOR "AUTOMOTIVE, AUTOMOTIVE SAFETY OR MEDICAL" INDUSTRY DOMAINS ACCORDING TO ST PRODUCT DESIGN SPECIFICATIONS. PRODUCTS FORMALLY ESCC, QML OR JAN QUALIFIED ARE DEEMED SUITABLE FOR USE IN AEROSPACE BY THE CORRESPONDING GOVERNMENTAL AGENCY.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2013 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com

