

About Your GA2002

Please note, when the GA2002 is powered on, it runs a 10-15 second initialisation check of the processor and instrument settings. During this period the unit will display the last taken reading, before engaging the input stage and reading from the accelerometer.

It is possible that an operator may inadvertently “scramble” the instrument’s setup if during the start-up time they should accidentally press a sequence of key presses that reset the processor to the default state. If this happens, the unit cannot be reset by the end user and the instrument must be returned to the factory for a full reset and recalibration.

It is for this reason that when switching the unit on, please allow 10-15 seconds for the unit to initialise before taking readings.