MOLEX APPLICATION SPECIFICATION

1.0 SCOPE

This specification covers the requirements for the application of Nano-Fit 2.50 mm pitch wire to board connector systems.

2.0 PRODUCT NAME AND SERIES NUMBERS

Nano-Fit Female Crimp Terminal Nano-Fit Receptacle Housing TPA Nano-Fit Vertical Header Nano-Fit Right Angle Header 105300 105307 / 105308 105325 105309 / 105310 / 105311 / 105312 105313 / 105314

3.0 REFERENCE DOCUMENTS

See the appropriate sales drawings for information on specific part numbers and materials.

4.0 GENERAL APPLICATION NOTES

Appearance:

 Parts conform to class "B" requirements of cosmetic specification PS-45499-002 except where noted on the sales drawings.

Connector Application

- This connector system is designed to mate gold plating to gold plating OR tin plating to tin plating. Never cross mate tin plated parts to gold plated parts.
- This connector system is not designed for current sharing (i.e. splitting one current load across multiple circuits)
- Connectors are not to be mated or unmated while circuits are live except per the current interrupt rating listed in product specification: PS-105300-100
- UL rating only maintained when used with molex application tooling
- the product was tested and qualified with molex application tooling

Packaging

• The parts should remain in the original Molex packaging until ready for use to prevent damage.

Chemical Exposure

• Do not store terminals or header assemblies near any chemicals listed below as they may cause corrosion in the terminal contacts.

Alkalies	Ammonia	Citrates	Phosphates Citrates	Sulfur Compounds
Amines	Carbonates	Nitrites	Sulfur Nitrites	Tartrates


REVISION:	ECR/ECN INFORMATION:		ON SPECIFICATIO	ON FOR	SHEET No.
D	EC No: 649262		FIT WIRE TO BOA		1 of 13
B	<u>DATE:</u> 2020/11/16	CONNECTOR SYSTEM			I OT 13
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	<u>APPRO\</u>	/ED BY:
AS-105300-100		Dixon Li Jonny Zheng Jonny Zheng			Zheng
TEMPLATE FILENAME: APPLICATION SPECISIZE A](V.1).DOC					

Crimped Terminal Extraction

• Female terminal extraction tool: See Molex part# 63824-4600 instructions online on website. Do not reuse terminals that have been removed with the extraction tool. The receptacle housing can be reused if it was not damaged.

Minimum wire bend, cable tie or twist location

Circuit Sizes	Dim T Min. (single row)	Dim T Min. (dual row)	
	(Single IOW)	(uuai iuw)	
2	.50" (12.7 mm)		
4-6	.75" (19.1 mm)	.75" (19.1 mm)	
8	1.00" (25.4 mm)	1.00" (25.4 mm)	
10-12		1.25" (31.75 mm)	
14-16		1.25" (31.75 mm)	



- The "T" dimension defines a "free" length of wire, or a length of wire that is not subject to significant bias by external factors such as a wire tie, wire twisting, or other means of bending or deforming of the wires that repositions them from their natural relaxed state or location where they enter the housing. This dimension is a general recommendation and may need to be adjusted for different wire gauges and wire type and insulation thickness and insulation material.
- Wires are to be dressed in such a manner to allow the terminals to float freely in the receptacle pocket.


Connector Testing


 Do not use Nano-Fit connectors as test parts, they are not intended to be used with repeated mating. Follow durability cycles as listed in PS-105300-100

REVISION:	ECR/ECN INFORMATION:		ON SPECIFICATIO	ON FOR	SHEET No.
В	<u>EC No:</u> 649262	NANO-	FIT WIRE TO BOA	RD	2 of 13
D	<u>DATE:</u> 2020/11/16	CON	20113		
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	APPRO\	/ED BY:
AS-105300-100		Dixon Li Jonny Zheng Jonny Zheng			Zheng
	TEMPI ATE FILENAME: APPLICATION SPECISIZE AI(V 1) DOC				

Crimped Terminal Insertion

- Terminals are inserted in same orientation for top and bottom row. Details refer to below **pictures**.
- DO NOT reuse receptacle housing if a crimped terminal was pushed out without an extraction tool.






interface. Store and handle crimped terminals so the interface does not make contact with other terminals or foreign objects. If terminal interface is damaged please discard prior to assembly.

Crimping

- For acceptable crimp tools and specifications see application tooling section on Molex.com listed for each terminal part number.
- Use with multi strand wire only. Single strand wire should not be used.
- This female crimp terminal is designed for single wire crimping only, no double wire crimping is allowed.
- Use only Molex specified crimp tooling, refer to Molex.com for acceptable crimp tooling. Crimped terminals must also meet Molex crimp specifications. Using crimp tooling/specifications other than specified voids any product warranties and will negatively impact mechanical and electrical performance.

Receptacle latch pressing notice

Avoid pressing latch except for operation of mating and unmating



Header Appearance

 Discoloration in the bandolier carrier area of the pin is inherent to the plating process and is due to the masking effect of the carrier. This discoloration is in a non-functional area of the pin and will not affect the performance of the header assembly. Refer to cosmetic specification PS-45499-002.


Right Angle Header Appearance


• Forming marks on header pins are acceptable. Refer to cosmetic specification PS-45499-002.

Header Assembly to Board


- Headers are designed with press fit pegs and need to be pushed into the circuit board.
- Header should be flush with board after insertion.
- See below for solder process information.

REVISION:	ECR/ECN INFORMATION:		ON SPECIFICATIO	ON FOR	SHEET No.
D	EC No: 649262	_	FIT WIRE TO BOA		5 -4 12
B	<u>DATE:</u> 2020/11/16	CONNECTOR SYSTEM			5 of 13
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	<u>APPROV</u>	/ED BY:
AS-105300-100		Dixon Li Jonny Zheng Jonny Zheng			Zheng
TEMPLATE FILENAME: APPLICATION SPECISIZE A)(V.1).DOC				APPLICATION_SPEC	[SIZE_A](V.1).DOC





REVISION: B	ECR/ECN INFORMATION: EC No: 649262 DATE: 2020/11/16	TITLE: APPLICATION SPECIFICATION FOR NANO-FIT WIRE TO BOARD CONNECTOR SYSTEM			<u>SHEET No.</u> 7 of 13
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	<u>APPROV</u>	/ED BY:
AS-105300-100		Dixon Li Jonny Zheng Jonny Zheng		Zheng	
TEMPLATE FILENAME: APPLICATION_SPEC[SIZE_A](V.1).DOC					



3.0 REFERENCE DOCUMENT

3.1 DRAWINGS:

Packaging Specification Drawings (PSD) is available from the Molex service network. By referring to the appropriate PSD for information on number of parts per tray, number of trays per carton, orientation of parts and trays vs packaging method.

In the event of any discrepancies between the information contained in the PSD and this specification or with any other technical documentation supplied. PSD take precedence.

4.0 PROCEDURES

4.1 HANDLING OF PACKAGING

Simulations have been done on the potential of on spot handling scenario by the material handlers/operators. This session will guide them on the dos and don'ts when handling the received packaging.

a) Avoid stacking the pallet on another pallet.





b) Ensure the 'Molex' logo is at upright location when opening the box.



c) Lift up the stack of trays from the carton. Grab the stack, using both hands, by the packing tape as shown.




d) After removing the stretch film around the stack of trays, it is advisable to take out only 1 tray at a time with both hands in vertical direction. Avoid lifting the trays from the box at an angle or pour the trays out.



4.2 HANDLING OF CONNECTORS

a) Handle the stack of trays using both hands.







b) Pick one tray out of stack one at a time, using both hands.

c) It is not advisable to carry the tray from one side. Hold both sides of the tray so that the tray will be balanced.



d) Avoid touching the terminals. Do not hold the connector by its terminals but from the outer housing walls in order to prevent potential bent pins.





e) Do not take more than one connector at a time. Improper handling can cause connector damage.



f) When placing unused connectors back into the tray, ensure that they are put in the correct orientation



REVISION:	ECR/ECN INFORMATION:		ON SPECIFICATIO	ON FOR	SHEET No.
В	<u>EC No:</u> 649262	NANO-	FIT WIRE TO BOA	RD	12 of 13
	DATE: 2020/11/16	CONNECTOR SYSTEM			
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	<u>APPRO\</u>	/ED BY:
AS-105300-100		Dixon Li	Dixon Li Jonny Zheng Jonny Zheng		Zheng
TEMPLATE FILENAME: APPLICATION_SPEC[SIZE_A](V.1).DOC					

g) Only a reasonable number of trays are allow to stack on one another. Do not stack more than a single carton's quantity of trays in any one stack. Over-stacking may damage the connectors and solder tails (if any of the trays falls off the stack, or if trays are mishandled when removing from the stack.)



- End of Document -

REVISION:	ECR/ECN INFORMATION:		ON SPECIFICATIO	ON FOR	SHEET No.
В	<u>EC No:</u> 649262	NANO-FIT WIRE TO BOARD		RD	13 of 13
D	<u>DATE:</u> 2020/11/16	CONNECTOR SYSTEM			
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	<u>APPRO\</u>	/ED BY:
AS-105300-100		Dixon Li Jonny Zheng Jonny Zheng			Zheng
TEMPLATE FILENAME: APPLICATION_SPEC[SIZE_A](V.1).DOC					