

Data sheet | Item number: 249-130

Syringe; Contents: 20 ml Alu-Plus contact paste

www.wago.com/249-130



Data

Technical data

Main product function	"Alu-Plus" contact paste
-----------------------	--------------------------

Material data

Weight	35.3 g
--------	--------

Subject to changes. Please also observe the further product documentation!

WAGO GmbH & Co. KG
Hansastr. 27
32423 Minden
Phone: +49571 887-0 | Fax: +49571 887-169
Email: info.de@wago.com | Web: www.wago.com

Do you have any questions about our products?
We are always happy to take your call at +49 (571) 887-44222.



Commercial data

Product Group	2 (Terminal Block Accessories)
eCl@ss 10.0	27-14-11-92
eCl@ss 9.0	27-14-11-92
ETIM 7.0	EC002848
ETIM 6.0	EC002848
PU (SPU)	20 (5) Stück
Packaging type	box
Country of origin	DE
GTIN	4017332133890
Customs tariff number	34039900900

Downloads

Documentation

Bid Text

249-130 X81 - Datei	19 февр. 2019 г.	xml 2.5 kB	Download
249-130 doc - Datei	17 мая 2017 г.	doc 24.1 kB	Download

CAD/CAE-Data

CAE data

EPLAN Data Portal 249-130	URL	Download
---------------------------	-----	----------

Environmental Product Compliance

Compliance Search

Environmental Product Compliance 249-130 Syringe; Contents: 20 ml Alu-Plus contact paste	URL	Download
---	-----	----------

Installation Notes

Application

Subject to changes. Please also observe the further product documentation!

WAGO GmbH & Co. KG
 Hansastr. 27
 32423 Minden
 Phone: +49571 887-0 | Fax: +49571 887-169
 Email: info.de@wago.com | Web: www.wago.com

Do you have any questions about our products?
 We are always happy to take your call at +49 (571) 887-44222.




WAGO Rail-Mount Terminal Blocks (up to 4 mm²/12 AWG)

Press plunger down until "Alu-Plus" has filled all conductor entry holes.

For each conductor entry: Insert nozzle of the "Alu-Plus" syringe in every open conductor entry hole (one after the other).

Application



WAGO Lighting Connectors

Push nozzle of the "Alu-Plus" syringe first into the circular entry and then into the square conductor entry hole of the WAGO Lighting Connector.

Press the plunger down until "Alu-Plus" has filled both entry holes.

Note: Not suitable for higher temperature applications!

Application

Subject to changes. Please also observe the further product documentation!



1. Push nozzle of the "Alu-Plus" syringe into every open conductor entry hole (one after the other).

2. Press plunger down until "Alu-Plus" has filled all conductor entry holes.

Subject to changes. Please also observe the further product documentation!