
# Air Cylinder

ø 20, ø 25, ø 32, ø 40

New


- Female rod end available as standard
- Rod end styles suitable for the application can be selected.



# Easy fine adjustment of auto switch position


Fine adjustment of the auto switch position is possible by simply loosening the screw attached to the auto switch.

Transparent switch bracket improves visibility of indicator LED.



# Single clevis and trunnion pivot brackets are available.

Rotating angle: Max. 202° (Bore size 40 mm)





# New Part numbers with rod end bracket and/or pivot bracket available

Not necessary to order a bracket for the applicable cylinder separately Note) Mounting bracket is shipped together with the product, but not assembled.


# Example) CDM2E20-50Z- N W -M9BW

# Pivot bracket — None Pivot bracket is shipped together with the product, but not assembled. N: Kit of pivot integral sing




Rod end bracket								
_	None							
V	Single knuckle joint							
W Double knuckle joint								






# Easy fine adjustment of auto switch position

Fine adjustment of the auto switch set position can be performed by loosening the auto switch attached screw without loosening the auto switch mounting band. Operability improved compared with the conventional auto switch set position adjustment, where the complete switch mounting band requires loosening.



# Total length is shortened with boss-cut type.

Boss for the head cover bracket is eliminated and the total length of cylinder is shortened.



Mounting

- Boss-cut/Basic (BZ)
- Boss-cut/Rod flange (FZ)
- Boss-cut/Rod trunnion (UZ)

#### No environmental hazardous substances used

Compliant with EU RoHS directive.

Lead free bushing is used as sliding material.


Specifications, performance and mounting method are same as the existing product.

#### Grease is selectable. (Option)

- Grease for food processing equipment (XC85)
- PTFE grease (X446)


Water resistant compact auto switch now available

Solid state auto switch D-M9□A(V)



#### **Series Variations**

\* For details about the clean series, consult SMC.



# **Combinations of Standard Products and Made to Order Specifications**

CM2

CM2K

Series

# Series CM2

: Standard
○ : Made to Order
$\bigcirc$ : Special product (Please contact SMC for details.)
— · Not available

• 0: 1 1				(Sta	andard ty	ype)		(Non-rotating rod type)					
<ul><li>Standard</li><li>Made to O</li></ul>	rder	Action/		Double	e acting		Single acting		Doubl	e acting		Single acting	
	oduct (Please contact SMC for details.)	Туре	Singl	e rod	Doubl	e rod	Single rod	Singl	e rod	Doubl	e rod	Single rod	
— : Not availat	ple	Cushion	Rubber	Air	Rubber	Air	Rubber	Rubber	Air	Rubber	Air	Rubber	
		Page	Pag	e 5	Page	e 26	Page 36	Pag	e 51	Page	e 57	Page 62	
Symbol	Specifications	Applicable bore size					ø 20 t	o ø 40					
Standard	Standard			•		•	•		•		•	•	
D	Built-in magnet												
CM2□F	With One-touch fittings Note 7)	ø 20 to ø 40						0	0	0	0	0	
CM2□-□ <sub>K</sub>	With rod boot	0 20 10 0 40					_						
CM2□H	Air-hydro type					_	_				_		
10-	Clean series					0	_	_	_				
<b>25A-</b> Note 6)	Copper (Cu) and Zinc (Zn)-free Note 7)	ø 10, ø 16		0	0	0	0	0	0	0	0	0	
<b>20-</b> Note 4)	Copper Note 3) and Fluorine-free		•	•			•	•	•			•	
CM2□ <sup>R</sup> <sub>V</sub>	Water resistant	ø 20 to ø 40			0	0	_	_	_	-	_	-	
CM2□X	Low speed cylinder	0 20 10 0 40		_	_	_	_	_	_		_		
CM2□M	Cylinder with stable lubrication function (Lube-retainer)			0	0	0	<u> </u>	_	_	-	_	$\mid - \mid$	
XB6	Heat resistant cylinder (-10 to 150 °C) Note 1)		0	$\bigcirc$	0	$\bigcirc$	0	0	0	0	$\bigcirc$	0	
XB7	Cold resistant cylinder (-40 to 70 °C) Note 1)		0	0	0	0	0	0	0	0	0	0	
XB9	Low speed cylinder (10 to 50 mm/s)	-	0	0	0	0	_	0	0	0	0		
XB12	External stainless steel cylinder Note 7)		0	0	0	0	0	0	0	0	0	0	
XB13	Low speed cylinder (5 to 50 mm/s) Note 7)		0	0	0	0	_	0	0	0	0		
XC3	Special port location		0	$\bigcirc$	0	0	0	0	0	0	$\bigcirc$	0	
XC4	With heavy duty scraper		0	0	0	0	0		_		_	0	
XC5	Heat resistant cylinder (-10 to 110 °C) Note 1)		0	0	0	0	0	0	0	0	0	0	
XC6	Made of stainless steel		0	0	0	0	0	0	0	0	$\bigcirc$	0	
XC8	Adjustable stroke cylinder/Adjustable extension type		0	0	_	_	0	0	0		_	0	
XC9	Adjustable stroke cylinder/Adjustable retraction type		0	$\bigcirc$	_	_	0	0	0		_	0	
XC10	Dual stroke cylinder/Double rod type		0	0		_	0	0	0			0	
XC11	Dual stroke cylinder/Single rod type		0	0		_	<u> </u>	0	0			-	
XC12	Tandem cylinder	ø 20 to ø 40	0		<u> </u>	_	<u> </u>	0	_	<u> </u>	_	-	
XC13	Auto switch rail mounting		0	0	0	0	0	0	0		0	0	
XC20	Head cover axial port		0	0	<u> </u>	_	0	0	0	<u> </u>	_	0	
XC22	Fluororubber seal		0	0	0	0	0	0	0	0	0	0	
XC25	No fixed throttle of connection port		0		0		0	0	_	0	_	0	
XC27	Double clevis and double knuckle joint pins made of stainless steel		0	$\bigcirc$	_	_	0	0	0		_	0	
XC29	Double knuckle joint with spring pin	-	0	0	0	0	0	0	0	0	0	0	
XC35	With coil scraper	]	0	0	0	0	1 —	_	_	1 — 1	_		
XC38	Vacuum specification (Rod through-hole)	]	_	_	0	0	1 —	_	_	1 — 1	_		
XC52	Mounting nut with set screw		0	0	0	0	0	0	0	0	0	0	
XC85	Grease for food processing equipment	1	0	0	0	0	0	0	0	0	0	0	
X446	PTFE grease	1	0	<u> </u>	0	0	0	0	0	0	0	0	
	ucts with an auto switch are not compatible.	'			, -					, -	=	, ,	

Note 2) For details about the smooth cylinder and low speed cylinder, consult SMC.

Note 3) Copper-free for the externally exposed part

Note 4) For details, consult SMC.

Note 5) Available only for locking at head end.

Note 6) Available only for locking at rod end.

Note 7) The shape is the same as the existing product.




	CM2X Low Speed Cylinder Note 2)	CM2Y Smooth Cylinder Note 2)		CBI (With end le	CM2□P (Centralised piping) Note 7)	CM2RK (Direct mount, Non-rotating rod type)	(amus toma)	CM2R (Direct mount type)		
	Double acting	Double acting	acting	Double	Double acting	Double acting	acting	Double		
	Single rod	Single rod	rod	Single	Single rod	Single rod	e rod	Singl		
	Rubber	Rubber	Air	Rubber	Rubber	Rubber	Air	Rubber		
	_	_	84	Page	Page 79	Page 75	e 68	Pag		
Symbol				o ø 40	ø 20 t					
Standard	•		•	•		•	•	•		
D	•	•	•	•	•	•	•	•		
CM2□F	0	•	0	0	0	0	0	0		
CM2□-□ <sup>J</sup>	_	_	_	•	•	0	0	0		
CM2□H	_	_	_	_	_	_	_	•		
10-	•	0	0	Note 5)	0	_	0	•		
<b>25A-</b> Note 6)	_	0	0	0	_	0	0	0		
<b>20-</b> Note 4)	_	_	0	•	0	•	•	•		
CM2□R V	_	_	0	Note 5)	0			0		
CM2□X		_		_	0	_	_	•		
CM2□M	_	_	_	_	_	_	0	0		
XB6	_	_	0	0	_	0	0	0		
XB7		_	_	_		0	0	0		
XB9		_	0	0	0	0	0	0		
XB12	0	_	0	0		0	0	0		
XB13				_	0	0	0	0		
XC3	<u> </u>	<u> </u>	0	0		0	0	0		
XC4			0	Note 5)	<u> </u>		0	0		
XC5			0	0		0	0	0		
XC6	<u> </u>		0	0	_	0	0	0		
XC8	0	0	O Note 5)	Note 5)		0	0	0		
XC9	0	0	Note 6)	Note 6)		0	0	0		
XC10	0	0								
	$\cup$		0	0		0	0	0		
XC11	_	_	0	0	_	0	0	0		
XC12	_	<u> </u>	_	_	_	0	<u> </u>	0		
XC13	0	<u> </u>	0	O Note 6)	0	0	0	0		
XC20	0	0	<u> </u>	Note 6)		0	0	0		
XC22	<u> </u>	<u> </u>	0	0		0	0	0		
XC25	0	0	_	0		0		0		
XC27	0	0	0	0	0	_	_			
XC29	0			0	0	0		0		
XC35		_	0	Note 5)	0	_	0	0		
XC38	0	0	_	_		_				
XC52	0	0	0	0	0	_	_			
XC85	_	_	0	0	0	0	0	0		
X446	_	_				0	0	0		

# Air Cylinder: Standard Type Double Acting, Single Rod

Series CM2 ø 20, ø 25, ø 32, ø 40






# Applicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.

App	Ilicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.  Load voltage Auto switch model Lead wire length [m]																	
Туре	Special function	Electrical entry	Indicator light	Wiring (Output)	ı	DC	ľ	Perpendicular	In-line	0.5	1 (M)	3	5	None (N)	Pre-wired connector	Applica	ble load	
				3-wire (NPN)		5 V. 12 V		M9NV	M9N	•	•	•	0	_	0	IC circuit		
		Grommet		3-wire (PNP)		5 V, 12 V		M9PV	M9P				0	—	0	io circuit		
당				2-wire		12 V		M9BV	M9B	•	•	•	0	_	0	_		
switch		Connector						_	H7C	•	_		•	•	_			
18 0		Terminal		3-wire (NPN)		5 V, 12 V			_	G39A	_	_	_	<u>  — </u>	•	_	IC circuit	
auto		conduit	S	2-wire		12 V			K39A	_	_	_	_	•	_		Relay,	
e	Diagnostic indication		Yes	3-wire (NPN)	24 V	5 V, 12 V		M9NWV	M9NW	•	•		0	_	0	IC circuit	PLC	
tat	(2-colour indication)			3-wire (PNP)				M9PWV	M9PW	•	•	•	0	_	0			
Solid state	, ,	_		2-wire		12 V		M9BWV	M9BW	•	•	•	0	_	0	_		
io	Water resistant	Grommet		3-wire (NPN)		5 V. 12 V		M9NAV***	M9NA***	0	0	•	0	_	0	IC circuit		
0)	(2-colour indication)			3-wire (PNP)				M9PAV***	M9PA***	0	0	•	0	_	0			
	,			2-wire		12 V		M9BAV***	M9BA***	0	0	•	0	_	0			
	With diagnostic output (2-colour indication)			4-wire (NPN)		5 V, 12 V		_	H7NF	•	_	•	0	_	0	IC circuit		
			Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	-	_	_	IC circuit	_	
_		Crammat	1				100 V	A93V	A93	•	-	•	•	_	_	_		
switch		Grommet	No Yes No				100 V or less	A90V	A90	•	_	•	—	_	_	IC circuit		
wi			Yes				100 V, 200 V		B54	•	_		•	_	_		Relay,	
			9			l	200 V or less		B64	•	_	•	_	_	_	_	PLC	
aut		Connector	No Yes	2-wire	24 V	12 V	_	_	C73C		_				_			
Reed auto		Connector	ટ	2-WIIE	24 V		24 V or less	_	C80C	•	<u> </u>		•		_	IC circuit		
Rei		Terminal					_	_	A33A	_	_	_	<u> </u>	•	_		PLC	
		conduit	es				100 V, 200 V	_	A34A	_	<u> </u>	_	<u> </u>	•	_	_	Relay, PLC	
		DIN terminal	×				100 V, 200 V	_	A44A	_		_	<u>  —</u>	•		_		
	Diagnostic indication (2-colour indication)	Grommet				_	_	_	B59W		-		<u> </u>	l —	_		0	

- \*\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance.

  A water-resistant type cylinder is recommended for use in an environment which requires water resistance.
- \* Lead wire length symbols: 0.5 m ...... (Example) M9NW

  1 m ...... M (Example) M9NWM
  - 1 m ······ M (Example) M9NWM 3 m ····· L (Example) M9NWL
  - 5 m ······ Z (Example) M9NWZ None ····· N (Example) H7CN
- $\ast$  Solid state auto switches marked with "O" are produced upon receipt of order.
- \* Do not indicate suffix "N" for no lead wire on the D-A3 A/A44A/G39A/K39A models.
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details.
- \* For details about auto switches with pre-wired connector, refer to the **Auto Switch Guide**.
- \* The D-A9 \( \Box \) M9 \( \Box \) auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)



\* Operate the cylinder with in the allowable kinetic energy.

# **Specifications**

	1	'	
Refer to pag	ges 95 to 99 f	or cylinders	with

Air cushion

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- . Minimum stroke for auto switch mounting
- Operating range

auto switches

Auto switch mounting brackets/Part no.

# **Standard Strokes**

Bore size [mm]	Standard stroke [mm] Note 1)	Maximum manufacturable stroke [mm]
20		1000
25	25, 50, 75, 100, 125, 150, 200, 250, 300	1500
32	25, 50, 75, 100, 125, 150, 200, 250, 500	2000
40		2000

Note 1) Intermediate strokes not listed above are produced upon receipt of order.

Manufacture of intermediate strokes in 1 mm intervals is possible. (Spacers are not used.) Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.

**Symbol** 


Double acting, Single rod

Made to Order (For details, refer to pages 101 to 117.)

Symbol	Specifications
-XA□	Change of rod end shape
-XB6	Heat resistant cylinder (-10 to 150 °C)
-XB7	Cold resistant cylinder (-40 to 70 °C)*1
-XB9	Low speed cylinder (10 to 50 mm/s)*1
-XB12	External stainless steel cylinder*2
-XB13	Low speed cylinder (5 to 50 mm/s)*2
-XC3	Special port location
-XC4	With heavy duty scraper
-XC5	Heat resistant cylinder (-10 to 110 °C)
-XC6	Made of stainless steel
-XC8	Adjustable stroke cylinder/Adjustable extension type
-XC9	Adjustable stroke cylinder/Adjustable retraction type
-XC10	Dual stroke cylinder/Double rod type*1
-XC11	Dual stroke cylinder/Single rod type
-XC12	Tandem cylinder*1
-XC13	Auto switch rail mounting
-XC20	Head cover axial port
-XC22	Fluororubber seal
-XC25	No fixed throttle of connection port*1
-XC27	Double clevis and double knuckle pins made of stainless steel
-XC29	Double knuckle joint with spring pin
-XC35	With coil scraper*1
-XC52	Mounting nut with set screw
-XC85	Grease for food processing equipment
-X446	PTFE grease

- \*1 Rubber bumper only.
- \*2 The shape is the same as the existing product.

# Option: Ordering Example of Cylinder Assembly



Mounting C: Single clevis Pivot bracket N: Yes Rod end bracket V: Single knuckle joint Auto switch D-M9BW: 2 pcs.

- Pivot bracket, single knuckle joint and auto switch are shipped together with the product, but not assembled.
- Pivot bracket is available only for C, T, U, E, V, UZ mounting types.
- \* No bracket is provided for the female rod end.

# **Mounting and Accessories**

	Accessories		Star	idard (m	ounted	to the b	ody)		Sta	andard (	packag	ed toge	ether, b	ut not a	ssembl	ed)			tion
Mo	punting	Body	Mounting nut	Rod end nut (Male thread)	Single clevis	Double clevis	Note 7)	Mounting	Foot	Flange	Pivot bracket	Pivot Note 5) bracket pin	Double Note 5)	Trunnion	Mounting nut (For trunnion)	Clevis pivot bracket (CM2E/CM2V)	Clevis pivot Maesi) bracket pin (CM2E/CM2V)	Single knuckle joint (Male thread only)	Note 6) Double knuckle joint (Male thread only)
В	Basic (Double-side bossed)	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
L	Axial foot	●(1 pc.)	(1 pc.) <sup>Note 2)</sup>	●(1 pc.)	_	_	_	(1 pc.) <sup>Note 2)</sup>	●(2 pcs.)	_	_	_	_	_	_	_	_	•	•
F	Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
G	Head flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
С	Single clevis	●(1 pc.)	Note 3)	●(1 pc.)	●(1 pc.)	_	●(Max. 3 pcs.)	Note 3)	_	_	_	_	_	_	_	_	_	•	•
D	Double clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	●(1 pc.)	●(Max. 3 pcs.)	Note 3)	_	_	_	_	●(1 pc.)	_	_	_	_	•	•
U	Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Т	Head trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Е	Integral clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	_	_	•	•
٧	Integral clevis (90°)	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	_	_	•	•
BZ	Boss-cut/Basic	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
FZ	Boss-cut/ Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
UZ	Boss-cut/ Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•

		Standard (mounted to the body)						Option										
Mounting: <b>C</b> Pivot bracket symbol: <b>N</b> Single clevis + Pivot bracket + Pin	●(1 pc.)	Note 3)	●(1 pc.)	●(1 pc.)	_	(Max. 3 pcs.)	Note 3)	_	_	●(2 pcs.)	●(1 pc.)	_	_	_	_	_	•	•
Mounting: <b>T, U, UZ</b> Pivot bracket symbol: <b>N</b> Trunnion + Pivot bracket	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	Note 3)	_	_	●(2 pcs.)	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Mounting: <b>E</b> Pivot bracket symbol: <b>N</b> Integral clevis + Pivot bracket + Pin	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	•	•
Mounting: <b>V</b> Pivot bracket symbol: <b>N</b> Integral clevis (90°) + Pivot bracket + Pin	●(1 pc.)	Note 3)	●(1 pc.)	_	1	_	Note 3)	1	_	_	1	1	_	_	●(1 pc.)	●(1 pc.)	•	•

Note 1) Rod end nut is not provided for the female rod end. Note 2) Two mounting nuts are packaged together. Note 3) Mounting nut is not packaged for the clevis.

Note 5) Retaining rings are included. Note 6) A pin and retaining rings (split pins for ø 40) are included. Note 7) This is the part(s) used to adjust the clevis angle. Mounting quantity can vary.

# Mounting Brackets/Part No.

Note 4) Trunnion nut is packaged for U, T, UZ.

Mounting brookst	Min. order		Bore siz	ze [mm]		Contents (for minimum order quantity)				
Mounting bracket	q'ty	20	25	32	40	Contents (for minimum order quantity)				
Foot*	2	CM-L020B	CM-L	.032B	CM-L040B	2 foots, 1 mounting nut				
Flange	1	CM-F020B	CM-F	032B	CM-F040B	1 flange				
Single clevis**	1	CM-C020B	CM-C	032B	CM-C040B	1 single clevis, 3 liners				
Double clevis (with pin)***	1	CM-D020B	CM-E	0032B	CM-D040B	1 double clevis, 3 liners, 1 clevis pin, 2 retaining rings				
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut				
Rod end nut	1	NT-02	NT	-03	NT-04	1 rod end nut				
Mounting nut	1	SN-020B	SN-0	)32B	SN-040B	1 mounting nut				
Trunnion nut	1	TN-020B	TN-0	)32B	TN-040B	1 trunnion nut				
Single knuckle joint	1	I-020B	I-03	32B	I-040B	1 single knuckle joint				
Double knuckle joint	1	Y-020B	Y-0	32B	Y-040B	1 double knuckle joint, 1 clevis pin, 2 retaining rings				
Clevis pin (Double clevis)	1		CDP-1		CDP-2	1 clevis pin, 2 retaining rings (split pins)				
Clevis pin (Double knuckle joint)	1		CDP-1		CDP-3	1 clevis pin, 2 retaining rings (split pins)				
Pivot bracket pin	1		CDP-1		CD-S03	1 pin, 2 retaining rings				
Clevis pivot bracket pin (For CM2E/CM2V)	1	CD-	-S02 CD		D-S03	1 clevis pin, 2 retaining rings				
Clevis pivot bracket (For CM2E/CM2V)	1	CM-E	E020B CM-		1-E032B	1 clevis pivot bracket, 1 clevis pin, 2 retaining ring				
Pivot bracket (For CM2C)	1		CM-B032		CM-B040	2 pivot brackets (1 of each type)				
Pivot bracket (For CM2T)	1	CM-B020	CM-B032		CM-B040	2 pivot brackets (1 of each type)				



<sup>\*</sup> Order 2 foots per cylinder.

\*\* 3 liners are included with a clevis bracket for adjusting the mounting angle.

\*\*\* A clevis pin and retaining rings (split pins for ø 40) are included.

### Mounting Brackets, Accessories/Material, Surface Treatment

Segment	Description	Material	Surface treatment
	Foot	Carbon steel	Nickel plating
	Flange	Carbon steel	Nickel plating
Mounting brackets	Single clevis	Carbon steel	Nickel plating
DIACKETS	Double clevis	Carbon steel	Nickel plating
	Trunnion	Cast iron	Electroless nickel plating
	Rod end nut	Carbon steel	Zinc chromated
	Mounting nut	Carbon steel	Nickel plating
	Trunnion nut	Carbon steel	Nickel plating
	Clevis pivot bracket	Carbon steel	Nickel plating
	Clevis pivot bracket pin	Carbon steel	(None)
Accessories	Single knuckle joint	Carbon steel ø 40: Free-cutting steel	Electroless nickel plating
	Double knuckle joint	Carbon steel ø 40: Cast iron	Electroless nickel plating Metallic bronze colour painting for ø 40
	Double clevis pin	Carbon steel	(None)
	Double knuckle joint pin	Carbon steel	(None)
	Pivot bracket	Carbon steel	Nickel plating
	Pivot bracket pin	Carbon steel	(None)

#### Weights

					[kg]
	20	25	32	40	
	Basic (Double-side bossed)	0.14	0.21	0.28	0.56
	Axial foot	0.29	0.37	0.44	0.83
	Flange	0.20	0.30	0.37	0.68
	Integral clevis	0.12	0.19	0.27	0.52
Basic	Single clevis	0.18	0.25	0.32	0.65
weight	Double clevis	0.19	0.27	0.33	0.69
	Trunnion	0.18	0.28	0.34	0.66
	Boss-cut/Basic	0.13	0.19	0.26	0.53
	Boss-cut/Flange	0.19	0.28	0.35	0.65
	Boss-cut/Trunnion	0.17	0.26	0.32	0.63
Additional	weight per 50 mm of stroke	0.04	0.06	0.08	0.13
	Clevis pivot bracket (with pin)	0.07	0.07	0.14	0.14
	Single knuckle joint	0.06	0.06	0.06	0.23
Option bracket	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20
	Pivot bracket	0.06	0.06	0.06	0.06
	Pivot bracket pin	0.02	0.02	0.02	0.03

Calculation: (Example) CM2L32-100Z

- Basic weight------0.44 (Foot, ø 32)
- Additional weight ----- 0.08/50 stroke
- Cylinder stroke .....100 stroke
  - $0.44 + 0.08 \times 100/50 = 0.60 \text{ kg}$

■ Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, ■ refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

# Handling

# 🗥 Warning

1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

- 2. Operate the cylinder within the specified cylinder speed, kinetic energy and lateral load at the rod end.
- 3. The allowable kinetic energy is different between the cylinders with male rod end and with female rod end due to the different thread sizes.
- 4. When female rod end is used, use a washer, etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.
- 5. Do not apply excessive lateral load to the piston rod. Easy checking method

Minimum operating pressure after the cylinder is mounted to the equipment [MPa] = Minimum operating pressure of cylinder [MPa] + {Load weight [kg] x Friction coefficient of guide/Sectional area of cylinder (mm<sup>2</sup>)}

If smooth operation is confirmed within the above value, the load on the cylinder is the resistance of the thrust only and it can be judged as having no lateral load.

6. Do not operate with the cushion needle in a fully closed condition.

Using it in the fully closed state will cause the cushion seal to be damaged. When adjusting the cushion needle, use the "Hexagon wrench key: nominal size 1.5".

7. Do not open the cushion needle wide excessively.

If the cushion needle were set to be completely wide (more than 3 turns from fully closed), it would be equivalent to the cylinder with no cushion, thus making the impacts extremely high. Do not use it in such a way. Besides, using with fully open could give damage to the piston or cover.

# Caution

1. Not able to disassemble.

Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

2. Use caution to the popping of a retaining ring.

When replacing rod seals and removing and mounting a retaining ring, use a proper tool (retaining ring plier: tool for installing a type C retaining ring). Even if a proper tool is used, it is likely to inflict damage to a human body or peripheral equipment, as a retaining ring may be flown out of the tip of a plier. Be much careful with the popping of a retaining ring. Besides, be certain that a retaining ring is placed firmly into the groove of rod cover before supplying air at the time of installment.

3. Do not touch the cylinder during operation.

Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

- 4. Do not use the air cylinder as an air-hydro cylinder. If it uses turbine oil in place of fluids for cylinder, it may result in oil leak.
- 5. The oil stuck to the cylinder is grease.
- 6. The base oil of grease may seep out.

The base oil of grease in the cylinder may seep out of the tube, cover, crimped part or rod bushing depending on the operating conditions (ambient temperature 40 °C or more, pressurised condition, low frequency operation).

- 7. When rod end female thread is used, use a thin wrench when tightening the piston rod.
- 8. Combine the rod end section, so that a rod boot might not be twisted.

If a rod boot is installed with being twisted when installing a cylinder, it will cause a rod boot to fail during operation.

9. When using a rod end bracket and/or pivot bracket, make sure they do not interfere with other brackets, workpieces and rod section, etc.



# Built-in One-touch Fittings (The shape is the same as the existing product.)

CM2 Mounting style Bore size Built-in One-touch fittings

This type has the One-touch fitting integrated in a cylinder, which enables to reduce the piping labor and installing space dramatically.



Specifications

Action	Double acting, Single rod		
Bore size [mm]	ø 20, ø 25, ø 32, ø 40		
Max. operating pressure	1.0 MPa		
Min. operating pressure 0.05 MPa			
Cushion	Rubber bumper		
Piping	One-touch fittings		
Piston speed	50 to 750 mm/s		
Mounting	Basic, Axial foot, Rod flange, Head flange, Single clevis, Double clevis, Rod trunnion, Head trunnion, Integral clevis, Boss-cut		

<sup>\*</sup> Auto switch can be mounted.

Applicable Tubing O.D./I.D.

Bore size [mm]	20	25	32	40
Applicable tubing O.D./I.D. [mm]	6/4	6/4	6/4	8/6
Applicable tubing material		used for eithe thane tubing.	er nylon, soft	nylon or

# ⚠ Caution

- 1. One-touch fitting cannot be replaced.
- One-touch fitting is press-fit into the cover, thus cannot be replaced.
  Refer to Fittings and Tubing Precautions for handling One-touch fittings.

# Air-hydro

CM2H | Mounting style | Bore size | Stroke | Rod boot | Z - | Made to Order Air-hydro

A low hydraulic pressure cylinder used at a pressures of 1.0 MPa or below.

Through the concurrent use of the CC series air-hydro unit, it is possible to operate at a constant or low speeds or to effect an intermediate stop, just like a hydraulic unit, while using pneumatic equipment such as a valve.



- For construction, refer to page 12.
- Since the dimensions of mounting style are the same as pages 14 to 21, refer to those pages.

# **Specifications**

Turne	Air budro		
Туре	Air-hydro		
Fluid	Turbine oil		
Action	Double acting, Single rod		
Bore size [mm]		ø 20, ø 25, ø 32, ø 40	
Proof pressure		1.5 MPa	
Max. operating pressure		1.0 MPa	
Min. operating pressure		0.18 MPa	
Piston speed	15 to 300 mm/s		
Ambient and fluid temperature	+5 to +60 °C		
Stroke length tolerance	+1.4 0 mm		
Cushion	Rubb	er bumper (Standard equipment)	
Mounting	Basic, Axial foot, Rod flange, Head flange, Single clevis, Double clevis, Rod trunnion, Head trunnion, Integral clevis, Integral clevis (90°), Boss-cut		
Made to Order**	-XA□	Change of rod end shape	
wade to Order	-XC3	Special port location	

- \* Auto switch can be mounted. Dimensions are the same as the standard type.
- \*\* For details, refer to pages 101 to 117.



# **Clean Series**



The type which is applicable for using inside the clean room graded Class 100 by making an actuator's rod section a double seal construction and discharging by relief port directly to the outside of clean room.




For detailed specifications about the clean series, consult SMC.

# Specifications

-poomounomo	
Action	Double acting, Single rod
Bore size [mm]	ø 20, ø 25, ø 32, ø 40
Max. operating pressure	1.0 MPa
Min. operating pressure 0.05 MPa	
Cushion Rubber bumper, Air cushion	
Relief port size M5 x 0.8	
Piston speed	30 to 400 mm/s
Mounting	Basic, Axial foot, Rod flange, Head flange, Boss-cut


\* Auto switch can be mounted.

#### Construction




ø 20, ø 25

ø 32, ø 40



\* The above shows the case of rubber bumper.


# **Water Resistant**



Ideal for use in a machine tool environment exposed to coolant mist. Also, applicable for use in an environment with water splashing such as food processing and car wash equipment, etc.



**Dimensions** (Dimensions other than below are the same as standard type.)



Bore size [mm]	E <sub>1</sub>	<b>E</b> <sub>2</sub> *	NN <sub>1</sub>	NN <sub>2</sub> *
20	22_0.033	20_0.033	M22 x 1.5	M20 x 1.5

<sup>\*:</sup> Same as the standard type.

#### **Specifications**

Action	Double acting, Single rod
Bore size [mm] ø 20, ø 25, ø 32, ø 40	
Cushion Rubber bumper, Air cushion	
Auto switch mounting Band mounting type	
Made to Order	XC6: Made of stainless steel

- \* Specifications other than the above are the same as the standard type. \* D-A3 $\square$ A/A44A/G39A/K39A/B54/B64 cannot be mounted on bore sizes ø
- 20 and ø 25 cylinder with air cushion.

#### Mounting Brackets/Part No.

Marrian a brankat	Min.	Bore size [mm]	Contents
Mounting bracket	order q'ty	20	(for minimum order quantity)
Axial foot**	2	CM-L020C	2 foots, 1 mounting nut
Flange	1	CM-F020C	1 flange
Trunnion (with nut)	1	CM-T020C	1 trunnion, 1 trunnion nut

- \* ø 25 to ø 40: Same as the standard type.
- \*\* Order 2 foots per cylinder.

# **△** Caution

Rod seal and scraper are not replaceable.

• Scraper is press-fit into the rod cover, thus cannot be replaced.

For details, consult SMC.



# Low Speed Cylinder

# CM2 X Mounting style Bore size - Stroke Z Low Speed Cylinder

Smooth operation with a little sticking and slipping at low speed. Can start smoothly with a little ejection even after being rendered for hours.



**Dimensions: Same as standard type** 


### **Specifications**

Bore size [mm]	20, 25, 32, 40	
Туре	Pneumatic	
Action	Double acting, Single rod	
Fluid	Air	
Proof pressure	1.5 MPa	
Max. operating pressure	1.0 MPa	
Min. operating pressure	0.025 MPa	
Ambient and fluid temperature	Without auto switch: -10 to 70 °C (No freezing) With auto switch: -10 to 60 °C	
Cushion	Rubber bumper	

#### **Piston Speed**

Bore size [mm]		20	25	32	40
Piston speed (mm/s)		0.5 to 300			
Allowable kinetic Male thread		0.27	0.4	0.65	1.2
energy (J)	Female thread	0.11	0.18	0.29	0.52

# Cylinder with Stable Lubrication Function (Lube-retainer)





# **Specifications**


Bore size [mm]	20, 25, 32, 40			
Action	Double acting, Single rod			
Min. operating pressure	0.1 MPa			
Piston speed	50 to 750 mm/s			
Cushion	Rubber bumper			

<sup>\*</sup> Specifications other than the above are the same as the standard type.


Dimensions: Same as standard type


# Construction

# Rubber bumper











## **Component Parts**

No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2A	Head cover A	Aluminium alloy	Anodised
2B	Head cover B	Aluminium alloy	Anodised
2C	Head cover C	Aluminium alloy	Anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	
5	Piston rod	Carbon steel	Hard chrome plating
6	Bushing	Bearing alloy	
7	Seal retainer	Stainless steel	
8	Retaining ring	Carbon steel	Phosphate coating
9	Bumper	Resin	ø 25 or larger is
10	Bumper	Resin	common.
11	Piston seal	NBR	

No.	Description	Material	Note
12	Wear ring	Resin	
13	Clevis bushing	Bearing alloy	
14	Mounting nut	Carbon steel	Nickel plating
15	Rod end nut	Carbon steel	Zinc chromated
16	Magnet	_	CDM2□20 to 40-□Z
17	Rod seal	NBR	

# **Replacement Part: Seal**

With F	Rubber	Bumper/With	Air	Cushion
--------	--------	-------------	-----	---------

No	Description	Motorial		Parl	no.	
INO.	Description	Malenai	20	25	32	40
17	Rod seal	NBR	CM20Z-PS	CM25Z-PS	CM32Z-PS	CM40Z-PS
ΔΛi	r-bydro					


#### ●Air-hydro


17	Rod seal	NBR	CM2H20-PS	CM2H25-PS	CM2H32-PS	CM2H40-PS
----	----------	-----	-----------	-----------	-----------	-----------


<sup>\*</sup> Since the seal does not include a grease pack, order it separately. Grease pack part number: GR-S-010 (10 g)




# Basic (Double-side Bossed) (B)









#### **Boss-cut**







																[mm]					
Bore size	Α	AL	Bı	B <sub>2</sub>	D	Е	F	FL	G	Н	H₁	H <sub>2</sub>	_	K	KA	MM	NA	NN	Р	S	ZZ
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	8	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	62	116
25	22	19.5	17	32	10	26_0.033	13	10.5	8	45	6	8	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	62	120
32	22	19.5	17	32	12	26_0.033	13	10.5	8	45	6	8	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	64	122
40	24	21	22	41	14	32_0.039	16	13.5	11	50	8	10	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	88	154

With Rod Boot [mm] h ZZ

Bore size	<b>D</b> 3	υ	I	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	30	36	18	68	81	93	106	131	156	181	12.5	25	37.5	50	75	100	125	143	156	168	181	206	231	256
25	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	147	160	172	185	210	235	260
32	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	149	162	174	187	212	237	262
40	41	46	20	77	90	102	115	140	165	190	12.5	25	37.5	50	75	100	125	181	194	206	219	244	269	294
With Roo	With Rod Boot [mm] Boss-cut [mm] Female Rod End [mm]																							

With Rod Bo	oot	[mm]			
Bore size	JH	JW			
20	23.5	10.5			
25	23.5	10.5			
32	23.5	10.5			
40	27	10.5			

With Air Cush	nion [mm]
Bore size	WA
20	12
25	12
32	11
40	16

D033-Cut								[HIIIII]
				ZZ				
Bore size	Without			Witl	n rod l	ooot		
	rod boot	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	103	130	143	155	168	193	218	243
25	107	134	147	159	172	197	222	247
32	109	136	149	161	174	199	224	249
40	138	165	178	190	203	228	253	278


Female Ro	d End	k		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	95
25	8	20	M5 x 0.8	95
32	12	20	M6 x 1	97
40	13	21	M8 x 1.25	125


- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

Centralised Piping

With End Lock

# Axial Foot (L)





																													[mm]
Bore size	Α	AL	В	B <sub>1</sub>	B <sub>2</sub>	D	F	G	Н	Ηí	H <sub>2</sub>	Ι	K	KA	LC	LD	LH	LS	LT	LX	LZ	MM	NA	Р	S	X	Υ	Z	ZZ
20	18	15.5	40	13	26	8	13	8	41	5	8	28	5	6	4	6.8	25	102	3.2	40	55	M8 x 1.25	24	1/8	62	20	8	21	131
25	22	19.5	47	17	32	10	13	8	45	6	8	33.5	5.5	8	4	6.8	28	102	3.2	40	55	M10 x 1.25	30	1/8	62	20	8	25	135
32	22	19.5	47	17	32	12	13	8	45	6	8	37.5	5.5	10	4	6.8	28	104	3.2	40	55	M10 x 1.25	34.5	1/8	64	20	8	25	137
40	24	21	54	22	41	14	16	11	50	8	10	46.5	7	12	4	7	30	134	3.2	55	75	M14 x 1.5	42.5	1/4	88	23	10	27	171

With Rod Boot [mm] Z h **B**<sub>3</sub> е 151 to 200 151 to 200 401 to 500 151 to 200 401 to 500 1 to 50 51 to 100 101 to 150 201 to 300 301 to 400 401 to 500 1 to 50 51 to 100 101 to 150 201 to 300 301 to 400 1 to 50 51 to 100 101 to 150 201 to 300 301 to 400 12.5 37.5 12.5 37.5 12.5 37.5 12.5 37.5 

	With Ro	d Bo	ot							[mm]
	Symbol				ZZ				JH	JW
	Bore size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	JH	JW
•	20	158	171	183	196	221	246	271	23.5	10.5
Ì	25	162	175	187	200	225	250	275	23.5	10.5
	32	164	177	189	202	227	252	277	23.5	10.5
	40	198	211	223	236	261	286	311	27	10.5

With Air Cus	shion [mm]
Bore size	WA
20	12
25	12
32	11
40	16

Female Re	od Er	nd		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	110
25	8	20	M5 x 0.8	110
32	12	20	M6 x 1	112
40	13	21	M8 x 1.25	142


<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston rod.





<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


 $<sup>\</sup>ast$  The bracket is shipped together.

# Rod Flange (F)











#### With air cushion







																[	[mm]												
Bore size	Α	AL	В	Bı	<b>B</b> <sub>2</sub>	C <sub>2</sub>	D	Е	F	FL	FD	FT	FX	FY	FZ	G	Н	H1	H <sub>2</sub>	I	K	KA	MM	NA	NN	Р	S	Z	ZZ
20	18	15.5	34	13	26	30	8	20_0.033	13	10.5	7	4	60	_	75	8	41	5	8	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	62	37	116
25	22	19.5	40	17	32	37	10	26-0.033	13	10.5	7	4	60	_	75	8	45	6	8	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	62	41	120
32	22	19.5	40	17	32	37	12	26-0.033	13	10.5	7	4	60	_	75	8	45	6	8	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	64	41	122
40	24	21	52	22	41	47.3	14	32_0.039	16	13.5	7	5	66	36	82	11	50	8	10	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	88	45	154

With Ro	d Bo	oot																					[mm]
Symbol	Вз					h							e							ZZ			
Bore size	<b>D</b> 3	е	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	30	36	68	81	93	106	131	156	181	12.5	25	37.5	50	75	100	125	143	156	168	181	206	231	256
25	32	36	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	147	160	172	185	210	235	260
32	32	36	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	149	162	174	187	212	237	262
40	41	46	77	90	102	115	140	165	190	12.5	25	37.5	50	75	100	125	181	194	206	219	244	269	294

With Rod E	3oot	[mm
Bore size	JH	JW
20	23.5	10.5
25	23.5	10.5
32	23.5	10.5
40	27	10.5

With Air Cush	ion [mm
Bore size	WA
20	12
25	12
32	11
40	16
4 -	

<b>Boss-cut</b>								[mm]
				ZZ	<u>'</u>			
Bore size	Without			With	h rod l	oot		
	rod boot	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	103	130	143	155	168	193	218	243
25	107	134	147	159	172	197	222	247
32	109	136	149	161	174	199	224	249
40	138	165	178	190	203	228	253	278

<sup>\*</sup> The bracket is shipped together.

Female Re	od Er	nd		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	95
25	8	20	M5 x 0.8	95
32	12	20	M6 x 1	97
40	13	21	M8 x 1.25	125

<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston rod.

\* When female thread is used, use a washer etc. to


<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

3.5

Ή

ZZ + Stroke

# Head Flange (G)



																					[mm]
Ī	Bore size	Α	AL	В	B <sub>1</sub>	B <sub>2</sub>	C <sub>2</sub>	D	E	F	FL	FD	FT	FX	FY	FZ	G	Н	H₁	H <sub>2</sub>	1
	20	18	15.5	34	13	26	30	8	20-0.033	13	10.5	7	4	60	_	75	8	41	5	8	28
Ī	25	22	19.5	40	17	32	37	10	26-0.033	13	10.5	7	4	60	_	75	8	45	6	8	33.5
	32	22	19.5	40	17	32	37	12	26-0.033	13	10.5	7	4	60	_	75	8	45	6	8	37.5
Ī	40	24	21	52	22	41	47.3	14	32_0,039	16	13.5	7	5	66	36	82	11	50	8	10	46.5

									[mm]
Bore size	K	KA	MM	NA	NN	Р	S	Z	ZZ
20	5	6	M8 x 1.25	24	M20 x 1.5	1/8	62	107	116
25	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	62	111	120
32	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	64	113	122
40	7	12	M14 x 1.5	42.5	M32 x 2	1/4	88	143	154

With	Rod	<b>Boot</b>

· · · · · · · · · · · · · · · · · · ·														[111111]											
_	Symbol	_		f				h							l							ZZ			
В	ore size	Do	Φ	•	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
	20	30	36	18	68	81	93	106	131	156	181	12.5	25	37.5	50	75	100	125	143	156	168	181	206	231	256
	25	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	147	160	172	185	210	235	260
	32	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	149	162	174	187	212	237	262
	40	41	46	20	77	90	102	115	140	165	190	12.5	25	37.5	50	75	100	125	181	194	206	219	244	269	294

With Rod E	With Rod Boot [mm]											
Bore size	JH	JW										
20	23.5	10.5										
25	23.5	10.5										
32	23.5	10.5										
40	27	10.5										

\* The bracket is shipped together.

With Air Cushion [mm]									
Bore size	WA								
20	12								
25	12								
32	11								
40	16								

Female Ro	d En	d		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	95
25	8	20	M5 x 0.8	95
32	12	20	M6 x 1	97
40	13	21	M8 x 1.25	125


<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston rod.


<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.




# Single Clevis (C)







### Female rod end



																										[mm]
Bore size	Α	AL	B <sub>1</sub>	CI	CD	СХ	D	E	F	FL	G	Н	Ηı	I	K	KA	L	MM	NA	NN	Р	RR	S	U	Z	ZZ
20	18	15.5	13	24	9	10	8	20_0.033	13	10.5	8	41	5	28	5	6	30	M8 x 1.25	24	M20 x 1.5	1/8	9	62	14	133	142
25	22	19.5	17	30	9	10	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	30	M10 x 1.25	30	M26 x 1.5	1/8	9	62	14	137	146
32	22	19.5	17	30	9	10	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	30	M10 x 1.25	34.5	M26 x 1.5	1/8	9	64	14	139	148
40	24	21	22	38	10	15	14	32_0,039	16	13.5	11	50	8	46.5	7	12	39	M14 x 1.5	42.5	M32 x 2	1/4	11	88	18	177	188

With Rod Boot [mm] Z h  $\ell$ Вз е 1 to 50 51 to 100 101 to 150 1 to 50 | 51 to 100 | 101 to 150 | 151 to 200 | 201 to 300 | 301 to 400 | 401 to 500 | 1 to 50 | 51 to 100 | 101 to 150 | 151 to 200 201 to 300 | 301 to 400 | 401 to 500 151 to 200 201 to 300 301 to 400 401 to 500 12.5 37.5 12.5 37.5 12.5 37.5 12.5 37.5 

With Ro	With Rod Boot													
Symbol				ZZ				JH	JW					
Bore size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	JII	JW					
20	169	182	194	207	232	257	282	23.5	10.5					
25	173	186	198	211	236	261	286	23.5	10.5					
32	175	188	200	213	238	263	288	23.5	10.5					
40	215	228	240	253	278	303	328	27	10.5					


With Air Cusl	nion [mm]
Bore size	WA
20	12
25	12
32	11
40	16


Female R	Female Rod End [mm]													
Bore size	<b>A</b> 1	Н	MM	ZZ										
20	8	20	M4 x 0.7	121										
25	8	20	M5 x 0.8	121										
32	12	20	M6 x 1	123										
40	13	21	M8 x 1.25	159										


 $<sup>\</sup>ast$  When female thread is used, use a thin wrench when tightening the piston rod.

<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

# **Double Clevis (D)**







																												mmj
Bore size	Α	AL	Bı	CD	CI	CL	СХ	CZ	D	Е	F	FL	G	Н	H1	- 1	K	KA	L	MM	NA	NN	Р	RR	S	U	Z	ZZ
20	18	15.5	13	9	24	25	10	19	8	20_0.033	13	10.5	8	41	5	28	5	6	30	M8 x 1.25	24	M20 x 1.5	1/8	9	62	14	133	142
25	22	19.5	17	9	30	25	10	19	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	30	M10 x 1.25	30	M26 x 1.5	1/8	9	62	14	137	146
32	22	19.5	17	9	30	25	10	19	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	30	M10 x 1.25	34.5	M26 x 1.5	1/8	9	64	14	139	148
40	24	21	22	10	38	41.2	15	30	14	32-0.039	16	13.5	11	50	8	46.5	7	12	39	M14 x 1.5	42.5	M32 x 2	1/4	11	88	18	177	188

\* A clevis pin and retaining ring (split pins for ø 40) are shipped together.

Sym		,		£	h					e							Z								
Bore size	oke -	93	е	'	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	3	80	36	18	68	81	93	106	131	156	181	12.5	25	37.5	50	75	100	125	160	173	185	198	223	248	273
25	3	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	164	177	189	202	227	252	277
32	3	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125	166	179	191	204	229	254	279
40	4	1	46	20	77	90	102	115	140	165	190	12.5	25	37.5	50	75	100	125	204	217	229	242	267	292	317

With Ro	With Rod Boot													
Symbol				ZZ				JH	JW					
Bore size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	זכ	3 44					
20	169	182	194	207	232	257	282	23.5	10.5					
25	173	186	198	211	236	261	286	23.5	10.5					
32	175	188	200	213	238	263	288	23.5	10.5					
40	215	228	240	253	278	303	328	27	10.5					

With Rod Boot

With Air Cust	<b>1101</b> [mm]
Bore size	WA
20	12
25	12
32	11
40	16


Female Rod End [mm]													
Bore size	<b>A</b> 1	Н	MM	ZZ									
20	8	20	M4 x 0.7	121									
25	8	20	M5 x 0.8	121									
32	12	20	M6 x 1	123									
40	13	21	M8 x 1.25	159									


- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.




# **Rod Trunnion (U)**

#### CM2U Bore size Stroke






### With air cushion



# Female rod end



																		[mm]
Bore size	Α	AL	B <sub>1</sub>	B <sub>2</sub>	D	Е	F	FL	G	Н	H₁	I	K	KA	MM	NA	NN	Р
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8
40	24	21	22	41	14	32_0.039	16	13.5	11	50	8	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4

								[mm]
Bore size	S	TD	TT	TX	TY	TZ	Z	ZZ
20	62	8	10	32	32	52	36	116
25	62	9	10	40	40	60	40	120
32	64	9	10	40	40	60	40	122
40	88	10	11	53	53	77	44 5	154

With Roo	d Bo	ot							[mm]
Symbol	Вз					h			
Bore size Stroke	<b>D</b> 3	е	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	30	36	68	81	93	106	131	156	181
25	32	36	72	85	97	110	135	160	185
32	32	36	72	85	97	110	135	160	185
40	41	46	77	90	102	115	140	165	190

# With Rod Boot

WILLIAM	a bo	ΟL																					[mm]
Symbol				e							Z							ZZ				ш	JW
Bore size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	311	3 44
20	12.5	25	37.5	50	75	100	125	63	76	88	101	126	151	176	143	156	168	181	206	231	256	23.5	10.5
25	12.5	25	37.5	50	75	100	125	67	80	92	105	130	155	180	147	160	172	185	210	235	260	23.5	10.5
32	12.5	25	37.5	50	75	100	125	67	80	92	105	130	155	180	149	162	174	187	212	237	262	23.5	10.5
40	12.5	25	37.5	50	75	100	125	71.5	84.5	96.5	109.5	134.5	159.5	184.5	181	194	206	219	244	269	294	27	10.5

Boss-cut								[mm]
				ZZ				
Bore size	Without			Wit	h rod b	oot		
	rod boot	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	103	130	143	155	168	193	218	243
25	107	134	147	159	172	197	222	247
32	109	136	149	161	174	199	224	249
40	138	165	178	190	203	228	253	278

With Air Cusl	hion [mm]
Bore size	WA
20	12
25	12
32	11
40	16
40	16

Female R	od E	nd		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	95
25	8	20	M5 x 0.8	95
32	12	20	M6 x 1	97
40	13	21	M8 x 1.25	125





When female thread is used, use a thin wrench when tightening the piston rod.


 When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


<sup>\*</sup> The bracket is shipped together.












#### With air cushion

# Female rod end



																		[mm]	
Bore size	Α	AL	B₁	B <sub>2</sub>	D	E	F	FL	G	Н	H₁	I	K	KA	MM	NA	NN	Р	
20	18	15.5	13	26	8	20-0.033	13	10.5	8	41	5	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	ſ
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	
40	24	21	22	41	14	32_0.039	16	13.5	11	50	8	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	1

								[mm]
Bore size	S	TD	TT	TX	TY	TZ	Z	ZZ
20	62	8	10	32	32	52	108	118
25	62	9	10	40	40	60	112	122
32	64	9	10	40	40	60	114	124
40	88	10	11	53	53	77	143.5	154

with Ro	a Bo	στ								[mm]
Symbol	Вз		£				h			
Bore size	<b>D</b> 3	е	'	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	30	36	18	68	81	93	106	131	156	181
25	32	36	18	72	85	97	110	135	160	185
32	32	36	18	72	85	97	110	135	160	185
40	41	46	20	77	90	102	115	140	165	190

With Ro	Vith Rod Boot [mm]																						
Symbol				e							Z							ZZ				Ē	JW
Bore size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	J	JVV
20	12.5	25	37.5	50	75	100	125	135	148	160	173	198	223	248	145	158	170	183	208	233	258	23.5	10.5
25	12.5	25	37.5	50	75	100	125	139	152	164	177	202	227	252	149	162	174	187	212	237	262	23.5	10.5
32	12.5	25	37.5	50	75	100	125	141	154	166	179	204	229	254	151	164	176	189	214	239	264	23.5	10.5
40	12.5	25	37.5	50	75	100	125	170.5	183.5	195.5	208.5	233.5	258.5	283.5	181	194	206	219	244	269	294	27	10.5

With	Air	Cı	ushion	[mm]

Bore size	WA
20	12
25	12
32	11
40	16

Female Rod End [mm												
Bore size	<b>A</b> 1	Н	MM	ZZ								
20	8	20	M4 x 0.7	97								
25	8	20	M5 x 0.8	97								
32	12	20	M6 x 1	99								
40	13	21	M8 x 1.25	125								

<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston


Direct Mount, Non-rotating Rod


Made to Order

\* The bracket is shipped together.

<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

# Integral Clevis (E)





Bore size	Α	AL	Bı	CD	CI	СХ	D	E	F	FL	G	Н	Нı	I	K	KA	L	MM	NA	NN
20	18	15.5	13	8	20	12	8	20_0.033	13	10.5	8	41	5	28	5	6	12	M8 x 1.25	24	M20 x 1.5
25	22	19.5	17	8	22	12	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	12	M10 x 1.25	30	M26 x 1.5
32	22	19.5	17	10	27	20	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	15	M10 x 1.25	34.5	M26 x 1.5
40	24	21	22	10	33	20	14	32_0.039	16	13.5	11	50	8	46.5	7	12	15	M14 x 1.5	42.5	M32 x 2

						[mm]
Bore size	Р	RR	S	U	Z	ZZ
20	1/8	9	62	11.5	115	124
25	1/8	9	62	11.5	119	128
32	1/8	12	64	14.5	124	136
40	1/4	12	88	14.5	153	165

With Air Cush	<b>ion</b> [mm]
Bore size	WA
20	12
25	12
32	11
40	16

With Ro	d Bo	oot								[mm]
Symbol	Вз	е	4				h			
Bore size	۵	υ	•	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	30	36	18	68	81	93	106	131	156	181
25	32	36	18	72	85	97	110	135	160	185
32	32	36	18	72	85	97	110	135	160	185
40	41	46	20	77	90	102	115	140	165	190

# With Rod Boot

With Ro	d Bo	ot																					[mm]
Symbol	8.							Z									ZZ				JH	JW	
Bore size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	ЭΠ	3 44
20	12.5	25	37.5	50	75	100	125	142	155	167	180	205	230	255	151	164	176	189	214	239	264	23.5	10.5
25	12.5	25	37.5	50	75	100	125	146	159	171	184	209	234	259	155	168	180	193	218	243	268	23.5	10.5
32	12.5	25	37.5	50	75	100	125	151	164	176	189	214	239	264	163	176	188	201	226	251	276	23.5	10.5
40	12.5	25	37.5	50	75	100	125	180	193	205	218	243	268	293	192	205	217	230	255	280	305	27	10.5

Female Rod End [m											
Bore size	<b>A</b> 1	Н	MM	ZZ							
20	8	20	M4 x 0.7	103							
25	8	20	M5 x 0.8	103							
32	12	20	M6 x 1	111							
40	13	21	M8 x 1.25	136							

Clevis Pivot Bracket											
	Bore size	LD	LF	LG	H	LP	L	LV	LY	LZ	
	20	6.8	15	30	30	37	3.2	18.4	59	152	
	25	6.8	15	30	30	37	3.2	18.4	59	156	
	32	9	15	40	40	50	4	28	75	174	
	40	9	15	40	40	50	4	28	75	203	


<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston rod.

\* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

# **Dimensions of Accessories**


# With Single Knuckle Joint





Bore size	Α	Н	MM	ND <sub>H10</sub>	NX <sub>1</sub>	U <sub>1</sub>	R <sub>2</sub>	Υ	Z
20	18	41	M8 x 1.25	9+0.058	9-0.1	14	10	11	66
25, 32	22	45	M10 x 1.25	9+0.058	9-0.1	14	10	14	69
40	24	50	M14 x 1.5	12+0.070	16-0.1	20	14	13	92


# Single Knuckle Joint



Part no.	Applicable bore size	Α	<b>A</b> 1	E <sub>1</sub>	LB	MM	ND <sub>H10</sub>	NX	Rı	U <sub>1</sub>
I-020B	20	46	16	20	36	M8 x 1.25	9+0.058	9-0.1	10	14
I-032B	25, 32	48	18	20	38	M10 x 1.25	9+0.058	9-0.1	10	14
I-040B	40	69	22	24	55	M14 x 1.5	12+0.070	16-0.1	15.5	20

# With Double Knuckle Joint

[mm]




Bore size	Α	Н	L	MM	ND	NX <sub>2</sub>	R <sub>2</sub>	U <sub>2</sub>	Υ	Z
20	18	41	25	M8 x 1.25	9	9+0.2	10	14	11	66
25, 32	22	45	25	M10 x 1.25	9	9+0.2	10	14	14	69
40	24	50	49.7	M14 x 1.5	12	16+0.3	13	25	13	92

# **Double Knuckle Joint**

[mm]

# Y-020B/032B Material: Carbon steel

Y-040B Material: Cast iron




Part no.	Applicable bore size	Α	<b>A</b> 1	E <sub>1</sub>	LA	LB	MM	ND	NX	NZ	Rı	U <sub>1</sub>	Included pin part number	Retaining ring Split pin Size
Y-020B	20	46	16	20	25	36	M8 x 1.25	9	9+0.2	18	5	14	CDP-1	Type C 9 for axis
Y-032B	25, 32	48	18	20	25	38	M10 x 1.25	9	9+0.2	18	5	14	CDP-1	Type C 9 for axis
Y-040B	40	68	22	24	49.7	55	M14 x 1.5	12	16+0.3	38	13	25	CDP-3	ø 3 x 18 L

[mm]

## Double Clevis Pin/Material: Carbon steel


Bore size: Ø 40 CDP-2



Bore size: Ø 20, Ø 25, Ø 32

2 x ø 3 Through hole 41.2 Retaining ring: Type C9 for axis Split pin: ø 3 x 18 L

Bore size: Ø 20, Ø 25, Ø 32 CDP-1 Retaining ring: Type C9 for axis



<sup>\*</sup> Retaining rings (split pins for ø 40) are included.

Double Knuckle Pin/Material: Carbon steel

\* Retaining rings (split pins for ø 40) are included.

SMC

<sup>\*</sup> A knuckle pin and retaining rings (split pins for ø 40) are included.


# Rod End Nut/Material: Carbon steel

[mm]


# Clevis Pivot Bracket (For CM2E(V))

[mm]

Material: Carbon steel



Part no.	Applicable bore size	В	С	D	d	Н
NT-02	20	13	15.0	12.5	M8 x 1.25	5
NT-03	25, 32	17	19.6	16.5	M10 x 1.25	6
NT-04	40	22	25.4	21.0	M14 x 1.5	8



Part no.	Applicable bore size	L	LC	LD	LE	LF	LG	LH	LR
CM-E020B	20, 25	24.5	8	6.8	22	15	30	30	10
CM-E032B	32, 40	34	10	9	25	15	40	40	13


Part no.	Applicable bore size	LT	LX	LY	LV	Included pin part no.
CM-E020B	20, 25	3.2	12	59	18.4	CD-S02
CM-E032B	32, 40	4	20	75	28	CD-S03

Note 1) A clevis pivot bracket pin and retaining rings are included.

Note 2) It cannot be used for the single clevis (CM2C) and the double clevis (CM2D).

# Mounting Nut/Material: Carbon steel


[mm]



Part no.	Applicable bore size	В	С	D	d	Н
SN-020B	20	26	30	25.5	M20 x 1.5	8
SN-032B	25, 32	32	37	31.5	M26 x 1.5	8
SN-040B	40	41	47.3	40.5	M32 x 2.0	10

# Trunnion Nut/Material: Carbon steel


[mm]



Part no.	Applicable bore size	В	С	D	d	Н
TN-020B	20	26	28	25.5	M20 x 1.5	10
TN-032B	25, 32	32	34	31.5	M26 x 1.5	10
TN-040B	40	41	45	40.5	M32 x 2	10

# Clevis Pivot Bracket Pin (For CM2E(V))

Material: Carbon steel



Part no.	Applicable bore size	D <sub>d9</sub>	d	L <sub>1</sub>	L2	m	t	Included retaining ring
CD-S02	20, 25	8-0.040	7.6	24.5	19.5	1.6	0.9	Type C 8 for axis
CD-S03	32, 40	10-0.040	9.6	34	29	1.35	1.15	Type C 10 for axis

Note) Retaining rings are included.

Standard buble Acting, Double Roc

ige Acting, Spring Return/Extend

Souble Acting, Single F

Non-rotating Roc

Double Acting, Double Rod

CMOKW


Single Acting, Spring PetumExit


Double Acting, Single Ro


Direct Mount, Non-rotating Rod Double Acting, Single Rod CM2RK

Centralised Piping
Double Acting, Single Rod
CM2 P

# With Single Clevis








**Rotation Angle** 

Bore size [mm]	Α°	В°	$\mathbf{A}^{\circ} + \mathbf{B}^{\circ} + 90^{\circ}$
20	25	85	200
25, 32	21	81	192
40	26	86	202


							[mm]			
Mounting	Part no.	Applicable bore size	СХ	Z + Stroke	CD	LX	LZ			
		20		133						
CM2C	CM-B032	25	10	137	9	44	60			
(Single clevis)		32		139						
	CM-B040	40	15	177	10	49	65			

Note) A pivot bracket pin and retaining rings are not included with the pivot bracket.

# With Rod Trunnion








								[mm]
Mounting	Part no.	Applicable bore size	TX	Rod trunnion	Head trunnion	CD	LX	LZ
Mounting	Part no.	Applicable bole size	1^	Z + Stroke	Z + Stroke	CD	LA	LZ
	CM-B020	20	32	36	108	8	66	82
CM2U/CM2T	CM-B032	25	40	40	112	9	74	00
(Rod/Head trunnion)	CIVI-BU32	32	40	40	114	9		90
	CM-B040	40	53	44.5	143.5	10	87	103

Note) A pivot bracket pin and retaining rings are not included with the pivot bracket.

## **Pivot Bracket**


#### \* Pivot brackets consists of a set of two brackets.



i ait iio.	CD	
CM-B020 Note 2)	8	
CM-B032	9	N
CM-B040	10	

Note 1) A pivot bracket pin and retaining rings are not included with the pivot bracket. Note 2) Only for the trunnion

# **Pivot Bracket Pin (For CM2C)**



	los alcorda al
bore size Part no. Dd9 d L1 L2 m t	Included retaining ring
<b>20 to 32 CDP-1</b> 9 <sup>-0.040</sup> 8.6 25 19.2 1.75 1.15 T	Type C 9 for axis
<b>40 CD-S03</b> 10 <sup>-0.040</sup> 9.6 34 29 1.35 1.15 Ty	Type C 10 for axis

Note) Retaining rings are included with the pivot bracket pin.


# Air Cylinder: Standard Type **Double Acting, Double Rod**

# Series CM2W

ø 20, ø 25, ø 32, ø 40



#### **How to Order**



Annicable Auto Cuitobe

App	plicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.							_   5										
Туре	Special function	Electrical entry	ndicator	Wiring (Output)		Load vol		Auto swit	ch model	Lea 0.5	ad wi	e ler	igth [	m] None	Pre-wired		cable	Direct
		entry	Ind	(Output)		DC	AC	Perpendicular	In-line	(—)	(M)	(L)	(Z)	(N)	connector	108	ad	Direct Mount, Non-rotating Rod
				3-wire (NPN)		5 V, 12 V		M9NV	M9N	•	•		0	_	0	IC circuit		patino
		Grommet		3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	_	0	10 circuit		Non
r,				2-wire		12 V		M9BV	M9B	•	•	•	0	_	0	_		ount.
switch		Connector					1	_	H7C	•	_	•	•	•	_			rect M
S C		Terminal		3-wire (NPN)		5 V, 12 V			G39A	_	<u> </u>	_	_	•	_	IC circuit		
auto		conduit	S	2-wire		12 V			K39A	_	<u> </u>	_	_	•	_	_	Relay,	Centralised Pining
ie a	Diagnostic indication		Ϋ́e	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	•	0	_	0	IC circuit	PLC	ļ į
state	(2-colour indication)			3-wire (PNP)		1011	-	M9PWV	M9PW	•	•	•	0	_	0			٥
id		0		2-wire		12 V	-	M9BWV	M9BW	0	0	•	0	_	0			101
Solid	Water resistant	Grommet		3-wire (NPN)		5 V, 12 V	1	M9NAV*** M9PAV***	M9NA*** M9PA***	0	0	•	0	_	0	IC circuit		ام
٠,	(2-colour indication)			3-wire (PNP) 2-wire	ł	12 V	-	M9BAV***	M9BA***	0	0	-	0	_	0			
	With diagnostic output (2-colour indication)			4-wire (NPN)	1	5 V, 12 V	-	IVISDAV	H7NF				0		0	IC circuit		1 2
	min dagnosic cuput (2 colodi indicatori)		$\vdash$	3-wire		<u> </u>					H	•	0	F	0	10 circuit		
			Yes	(NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	_	-	_	IC circuit	_	With End Lock
_		Grommet					100 V	A93V	A93	•	-	•	•	_	_	_		]  €
switch		Grommet	No Yes No				100 V or less	A90V	A90	•	_		_	_	_	IC circuit		>
š			Yes				100 V, 200 V	_	B54	•	_			_	_		Relay,	
9			2	]			200 V or less	_	B64		<u> </u>	•	_	_		_	PLC	
anto		Connector	No Yes	2-wire	24 V	12 V		_	C73C	•	<u> </u>	•	•	•	_			
Reed		00111100101	ž	2 ******	,		24 V or less	_	C80C	•	_	•		•	_	IC circuit		1
Re		Terminal						_	A33A	_	<u> </u>	_	_	•			PLC	1
		conduit	es				100 V,		A34A	_	<u> </u>	_	_	•	_	_	Relay,	
		DIN terminal					200 V	_	A44A	_	<u> </u>	_	_	•	_		PLC	
	Diagnostic indication (2-colour indication)	Grommet	1			I —	_	_	B59W		1 —		—	l —	_	l		1

<sup>\*\*\*</sup> Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers.

- (Example) M9NW (Example) M9NWM
- (Example) M9NWL 3 m ..... L
- (Example) M9NWZ None ······ N (Example) H7CN
- · Solid state auto switches marked with "O" are produced upon receipt of order
- \* Do not indicate suffix "N" for no lead wire on D-A3 A/A44A/G39A/K39A models
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 \( \to \)-\( \t



Switch


Made to Order

# Series CM2W




### **Symbol**

#### Rubber bumper



#### Air cushion





#### Made to Order (For details, refer to pages 101 to 117.)

Symbol	Specifications				
-ХА□	Change of rod end shape				
-XB6	Heat resistant cylinder (-10 to 150 °C)				
-XB7	Cold resistant cylinder (-40 to 70 °C)*1				
-XB12	External stainless steel cylinder*2				
-XC3	Special port location				
-XC4	With heavy duty scraper				
-XC5	Heat resistant cylinder (-10 to 110 °C)				
-XC6	Made of stainless steel				
-XC13	Auto switch rail mounting				
-XC22	Fluororubber seal				
-XC25	No fixed throttle of connection port*1				
-XC29	Double knuckle joint with spring pin				
-XC35	With coil scraper*1				
-XC38	Vacuum (Rod through-hole)				
-XC52	Mounting nut with set screw				
-XC85	Grease for food processing equipment				
-X446	PTFE grease				

<sup>\*1</sup> Rubber bumper only.

# **Specifications**

-	Bore size [mm]		20	25	32	40		
Action			Double acting, Double rod					
Fluid				А	ir			
Proof pres	ssure			1.5	MPa			
Maximum	operating pre	ssure		1.0	MPa			
Minimum operating pressure				0.08	MPa			
Ambient and fluid temperature			Without auto switch: -10 °C to 70 °C (No freezing) With auto switch: -10 °C to 60 °C					
Lubricatio	Lubrication			Not required (Non-lube)				
Stroke ler	gth tolerance		*1.4 0 mm					
Piston sp	eed		Rubber bumper: 50 to 750 mm/s, Air cushion: 50 to 1000 mm/s					
Cushion			Rubber bumper, Air cushion					
	Rubber	Male thread	0.27 J	0.4 J	0.65 J	1.2 J		
Allowable	bumper	Female thread	0.11 J	0.18 J	0.29 J	0.52 J		
kinetic energy	Air cushion (Effective cushion	Male thread	0.54 J (11.0)	0.78 J (11.0)	1.27 J (11.0)	2.35 J (11.8)		
	length [mm])	Female thread	0.11 J	0.18 J	0.29 J	0.52 J		

# **Standard Strokes**

Bore size [mm]	Standard stroke Note 1) [mm]	Maximum manufacturable stroke [mm]
20		
25	25 50 75 100 125 150 200 250 200	500
32	25, 50, 75, 100, 125, 150, 200, 250, 300	500
40		

Note 1) Other intermediate strokes can be manufactured upon receipt of order.

Manufacture of intermediate strokes at 1 mm intervals is possible.

(Spacers are not used.)

Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.

# **Accessories**

Refer to pages 22 and 23 for accessories, since it is the same as standard type, double acting, single rod.

# **Rod Boot Material**

Syn	nbol	Rod boot material	Maximum ambient	
One side	Both sides	nou boot material	temperature	
J	JJ	Nylon tarpaulin	70 °C	
K	KK	Heat resistant tarpaulin	110 °C*	

<sup>\*</sup> Maximum ambient temperature for the rod boot itself.

# Mounting Brackets/Part No.

Mounting brookst	Min.	В	ore siz	ze [mn	n]	Contents		
Mounting bracket	order q'ty	20	25	32	40	(for minimum order quantity)		
Axial foot*	2	CM-L020B	CM-L032B		CM-L040B	2 foots, 1 mounting nut		
Flange	1	CM-F020B	CM-F032B		CM-F032B (		CM-F040B	1 flange
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut		

<sup>\*</sup> Order 2 foots per cylinder.

#### Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.



<sup>\*2</sup> The shape is the same as the existing product.

# **Mounting and Accessories**

Accessories	Stan	dard	Option				
Mounting	Mounting nut	Rod end nut	Single knuckle joint	Double Note 2) knuckle joint	Rod boot	Pivot bracket	
Basic (Double- side bossed)	• (1 pc.)	● (2 pcs.)	•	•	•		
Axial foot	• (2 pcs.)	• (2 pcs.)	•	•	•	_	
Flange	● (1 pc.)	• (2 pcs.)	•	•	•		
Trunnion	(1 pc.) Note 1)	• (2 pcs.)	•	•	•	•	
Note					One/Both side(s)		

Note 1) Trunnion nut is attached to the trunnion.

Note 2) A pin and retaining rings (split pins for ø 40) are shipped together with double knuckle joint.

# Weights

					[rg]
	Bore size [mm]			32	40
	Basic (Double-side bossed)	0.16	0.25	0.32	0.65
Basic	Axial foot	0.31	0.41	0.48	0.92
weight	Flange	0.22	0.34	0.41	0.77
	Trunnion	0.20	0.32	0.38	0.75
Additiona	Additional weight per 50 mm of stroke		0.09	0.13	0.19
Option	Single knuckle joint	0.06	0.06	0.06	0.23
bracket	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20

Calculation: (Example) CM2WL32-100Z

- Basic weight------0.48 (Foot, Ø 32)
- Additional weight ...... 0.13/50 stroke

 $0.48 + 0.13 \times 100/50 = 0.74 \text{ kg}$ 

# **Precautions**

Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

# Handling

# **∕** Warning

1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

2. Do not operate with the cushion needle in a fully closed condition.

Using it in the fully closed state will cause the cushion seal to be damaged. When adjusting the cushion needle, use the "Hexagon wrench key: nominal size 1.5".

3. Do not open the cushion needle wide excessively.

If the cushion needle were set to be completely wide (more than 3 turns from fully closed), it would be equivalent to the cylinder with no cushion, thus making the impacts extremely high. Do not use it in such a way. Besides, using with fully open could give damage to the piston or cover.

- 4. Operate the cylinder within the specified cylinder speed, kinetic energy and lateral load at the rod end.
- 5. The allowable kinetic energy is different between the cylinders with male rod end and with female rod end due to the different thread sizes.
- 6. When female rod end is used, use a washer, etc. to prevent the contact part at the rod end from being deformed depending on the material of the work piece.
- 7. Do not apply excessive lateral load to the piston rod. Easy checking method

Minimum operating pressure after the cylinder is mounted to the equipment [MPa] = Minimum operating pressure of cylinder [MPa] + {Load weight [kg] x Friction coefficient of guide/Sectional area of

If smooth operation is confirmed within the above value, the load on the cylinder is the resistance of the thrust only and it can be judged as having no lateral load.

# **⚠** Caution

1. Not able to disassemble.

Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

2. Use caution to the popping of a retaining ring.

When replacing rod seals and removing and mounting a retaining ring, use a proper tool (retaining ring plier: tool for installing a type C retaining ring). Even if a proper tool is used, it is likely to inflict damage to a human body or peripheral equipment, as a retaining ring may be flown out of the tip of a plier. Be much careful with the popping of a retaining ring. Be-sides, be certain that a retaining ring is placed firmly into the groove of rod cover before supplying air at the time of installment.

3. Do not touch the cylinder during operation.

Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

- 4. Do not use the air cylinder as an air-hydro cylinder. If it uses turbine oil in place of fluids for cylinder, it may result in oil leak.
- 5. Combine the rod end section, so that a rod boot might not be twisted.

If a rod boot is installed with being twisted when installing a cylinder, it will cause a rod boot to fail during operation.

6. The base oil of grease may seep out.

The base oil of grease in the cylinder may seep out of the tube, cover, or crimped part depending on the operating conditions (ambient temperature 40 °C or more, pressurised condition, low frequency operation).

- 7. The oil stuck to the cylinder is grease.
- 8. When rod end female thread is used, use a thin wrench when tightening the piston rod.
- 9. When using a rod end bracket, make sure it does not interfere with other brackets, workpieces and rod section, etc.

# Built-in One-touch Fittings (The shape is the same as the existing product.)



This type has the One-touch fitting integrated in a cylinder, which enables to reduce the piping labor and installing space dramatically.



#### **Specifications**

Action	Double acting, Double rod
Bore size [mm]	ø 20, ø 25, ø 32, ø 40
Max. operating pressure	1.0 MPa
Min. operating pressure	0.08 MPa
Cushion	Rubber bumper
Piping	One-touch fittings
Piston speed	50 to 750 mm/s
Mounting	Basic, Axial foot, Flange, Trunnion

<sup>\*</sup> Auto switch can be mounted.


# Applicable Tubing O.D./I.D.

Bore size [mm]	20	25	32	40
Applicable tubing O.D./I.D. [mm]	6/4	6/4	6/4	8/6
Applicable tubing material		used for eithe hane tubing.	er nylon, soft	nylon or

# **⚠** Caution

- 1. One-touch fitting cannot be replaced.
  - One-touch fitting is press-fit into the cover, thus cannot be replaced.
- 2. Refer to Fittings and Tubing Precautions for handling One-touch fittings.

# Air-hydro



A low hydraulic pressure cylinder used at a pressures of 1.0 MPa or below.

Through the concurrent use of the CC series air-hydro unit, it is possible to operate at a constant or low speeds or to effect an intermediate stop, just like a hydraulic unit, while using pneumatic equipment such as a valve.



- For construction, refer to page 31.
- Since the dimensions of mounting style are the same as pages 33 to 35, refer to those pages.

#### **Specifications**

Туре		Air-hydro type		
Fluid	Turbine oil			
Action	Do	uble acting, Double rod		
Bore size [mm]	Q	g 20, ø 25, ø 32, ø 40		
Proof pressure		1.5 MPa		
Max. operating pressure	1.0 MPa			
Min. operating pressure	0.18 MPa			
Piston speed	15 to 300 mm/s			
Ambient and fluid temperature	+5 to +60 °C			
Strake length televance	+1.4			
Stroke length tolerance	0 mm			
Cushion	Rubber bumper (Standard equipment)			
Mounting	Basic, Axial foot, Flange, Trunnion			
Made to Order**	-XA□	Change of rod end shape		

- \* Auto switch can be mounted.
- \*\* For details, refer to pages 101 to 117.

# **Clean Series**

10-CM2W Mounting style Bore size - Stroke Z

Clean Series (With relief port)

The type which is applicable for using inside the clean room graded Class 100 by making an actuator's rod section a double seal construction and discharging by relief port directly to the outside of clean room.




# **Specifications**

Action	Double acting, Double rod
Bore size [mm]	ø 20, ø 25, ø 32, ø 40
Max. operating pressure	1.0 MPa
Min. operating pressure	0.08 MPa
Cushion	Rubber bumper
Relief port size	M5 x 0.8
Piston speed	30 to 400 mm/s
Mounting	Basic, Axial foot, Flange

<sup>\*</sup> Auto switch can be mounted.


### Construction




# Series CM2W

# Construction


# Rubber bumper



# Air-hydro



# With air cushion



**Component Parts** 

COII	iponeni Faris		
No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2	Cylinder tube	Stainless steel	
3	Piston	Aluminium alloy	
4	Piston rod	Carbon steel	Hard chrome plating
5	Bushing	Bearing alloy	
6	Seal retainer	Stainless steel	
7	Retaining ring	Carbon steel	Phosphate coating
8	Bumper	Resin	
9	Bumper	Resin	
10	Mounting nut	Carbon steel	
11	Rod end nut	Carbon steel	
12	Piston seal	NBR	Nickel plating
13	Magnet	_	CDM2W□20 to 40-□Z
14	Rod seal	NBR	

# **Replacement Part: Seal**


 - 1						
Wi	th Rubbe	r Bur	nper/With	Air Cushi	on	
NIo	Description	Motorial		Part	no.	
INO.	Description	Waterial	20	25	32	40
14	Rod seal	NBR	CM20Z-PS	CM25Z-PS	CM32Z-PS	CM40Z-PS


• Air-hydro

No.	Description	Material		Par	no.	
INO.	Description	Malenai	20	25	32	40
14	Rod seal	NBR	CM2H20-PS	CM2H25-PS	CM2H32-PS	CM2H40-PS

<sup>\*</sup> Since the seal does not include a grease pack, order it separately. Grease pack part number: GR-S-010 (10 g)







Bore size	Α	AL	B <sub>1</sub>	B <sub>2</sub>	D	Е	F	FL	G	Н	H1	H <sub>2</sub>	ı	K	KA	MM	NA	NN	Р	S	ZZ
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	8	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	62	144
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	8	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	62	152
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	8	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	64	154
40	24	21	22	41	14	32-0.039	16	13.5	11	50	8	10	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	88	188

With Rod	Boo	ot																[mm]
Bore size	Вз					h					e				ZZ (	Both s	ides)	
Bore Size	<b>D</b> 3	Φ	•	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300
20	30	36	18	68	81	93	106	131	12.5	25	37.5	50	75	198	224	248	274	324
25	32	36	18	72	85	97	110	135	12.5	25	37.5	50	75	206	232	256	282	332
32	32	36	18	72	85	97	110	135	12.5	25	37.5	50	75	208	234	258	284	334
40	41	46	20	77	90	102	115	140	12.5	25	37.5	50	75	242	268	292	318	368

With Rod	Boo	t					[mm]
Bore size		ZZ	(One s	ide)		JH	JW
Bore Size	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	זכ	5
20	171	184	196	209	234	23.5	10.5
25	179	192	204	217	242	23.5	10.5
32	181	194	206	219	244	23.5	10.5
40	215	228	240	253	278	27	10.5

With Air Cus	hion [mm]
Bore size	WA
20	12
25	12
32	11
40	16

Female R	od E	nd		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	102
25	8	20	M5 x 0.8	102
32	12	20	M6 x 1	104
40	13	21	M8 x 1.25	130

 $<sup>\</sup>ast$  When female thread is used, use a thin wrench when tightening the piston rod.  $\ast$  When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


Direct Mount, Non-rotating Rod

Centralised Piping


# Series CM2W

# **Axial Foot (L)**


# CM2WL Bore size - Stroke Z



#### With air cushion



## Female rod end




																													[mm]
Bore size	Α	AL	В	Вı	B <sub>2</sub>	D	F	G	Н	Ηı	H <sub>2</sub>	I	K	KA	LC	LD	LH	LS	LT	LX	LZ	MM	NA	Р	S	X	Υ	Z	ZZ
20	18	15.5	40	13	26	8	13	8	41	5	8	28	5	6	4	6.8	25	102	3.2	40	55	M8 x 1.25	24	1/8	62	20	8	21	144
25	22	19.5	47	17	32	10	13	8	45	6	8	33.5	5.5	8	4	6.8	28	102	3.2	40	55	M10 x 1.25	30	1/8	62	20	8	25	152
32	22	19.5	47	17	32	12	13	8	45	6	8	37.5	5.5	10	4	6.8	28	104	3.2	40	55	M10 x 1.25	34.5	1/8	64	20	8	25	154
40	24	21	54	22	41	14	16	11	50	8	10	46.5	7	12	4	7	30	134	3.2	55	75	M14 x 1.5	42.5	1/4	88	23	10	27	188

ushion [mm
WA
12
12
11
16


Female R	od E	nd		[mm]
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	20	M4 x 0.7	102
25	8	20	M5 x 0.8	102
32	12	20	M6 x 1	104
40	13	21	M8 x 1.25	130

- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


- \* In the case of with rod boot, refer to basic type on page 32.
- \* The bracket is shipped together.



#### With air cushion



#### Female rod end



																							[mm]
Bore size	Α	AL	В	B <sub>1</sub>	B <sub>2</sub>	C <sub>2</sub>	D	E	F	FD	FL	FT	FX	FY	FZ	G	Н	H <sub>1</sub>	H <sub>2</sub>	_	K	KA	MM
20	18	15.5	34	13	26	30	8	20_0.033	13	7	10.5	4	60	-	75	8	41	5	8	28	5	6	M8 x 1.25
25	22	19.5	40	17	32	37	10	26-0.033	13	7	10.5	4	60	_	75	8	45	6	8	33.5	5.5	8	M10 x 1.25
32	22	19.5	40	17	32	37	12	26-0.033	13	7	10.5	4	60	_	75	8	45	6	8	37.5	5.5	10	M10 x 1.25
40	24	21	52	22	41	47.3	14	32_0.039	16	7	13.5	5	66	36	82	11	50	8	10	46.5	7	12	M14 x 1.5

						[mm]
Bore size	NA	NN	Р	S	Z	ZZ
20	24	M20 x 1.5	1/8	62	37	144
25	30	M26 x 1.5	1/8	62	41	152
32	34.5	M26 x 1.5	1/8	64	41	154
40	42.5	M32 x 2	1/4	88	45	188

<ul> <li>In the case of with rod boot,</li> </ul>	refer to basic type on page 32.
---	---------------------------------

<sup>\*</sup> The bracket is shipped together.

With Air Cus	hion [mm]
Bore size	WA
20	12
25	12
32	11
40	16

Female Rod End [mm]										
Bore size	<b>A</b> 1	Н	MM	ZZ						
20	8	20	M4 x 0.7	102						
25	8	20	M5 x 0.8	102						
32	12	20	M6 x 1	104						
40	13	21	M8 x 1.25	130						

<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston rod.




<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


# Series CM2W

# Trunnion (U)


# CM2WU Bore size - Stroke Z



# With air cushion



## Female rod end



																				[mm]
Bore size	Α	AL	B <sub>1</sub>	B <sub>2</sub>	D	Е	F	FL	G	Н	H1	1	K	KA	MM	NA	NN	Р	S	TD
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	62	8
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	62	9
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	64	9
40	24	21	22	41	14	32_0 039	16	13.5	11	50	8	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	88	10

						[mm]
Bore size	TT	TX	TY	TZ	Z	ZZ
20	10	32	32	52	36	144
25	10	40	40	60	40	152
32	10	40	40	60	40	154
40	11	53	53	77	44.5	188

40	- 11	53	53	//	44.5	Ξ
* In the case o	f with r	od boo	t, refer	to basi	c type	on
page 32.						

<sup>\*</sup> The bracket is shipped together.

ith Air Cu	shion [mm]	Female
Bore size	WA	Bore size
20	12	20
25	12	25
32	11	32
40	16	40

Female Rod End [m										
Bore size	<b>A</b> 1	Н	MM	ZZ						
20	8	20	M4 x 0.7	102						
25	8	20	M5 x 0.8	102						
32	12	20	M6 x 1	104						
40	13	21	M8 x 1.25	130						

<sup>\*</sup> When female thread is used, use a thin wrench when tightening the piston rod.




<sup>\*</sup> When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

# Air Cylinder: Standard Type Single Acting, Spring Return/Extend

Series CM2 ø 20, ø 25, ø 32, ø 40



#### **How to Order**



App	licable Auto	Switch	es/	Refer to the A	uto Sw	itch Guid	de for further	information	on auto sw	itches	i.							.   8
		Electrical	tor	Wiring		Load vol	tage	Auto swit	ch model	Lea	ıd wii	e ler	igth [	[m]	Pre-wired	Annli	cable	Direct
Type	Special function	entry	ndicato	(Output)			AC	Perpendicular In-line		0.5	1 (M)	3 (L)	5 (Z)	None (N)	connector		ad	
			_	3-wire (NPN)		_ , , , , , ,		M9NV	M9N			•	0	_	0			Direct Mount, Non-rotating Rod
		Grommet		3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	_	0	IC circuit		lon-rot
ج				2-wire		12 V	1	M9BV	M9B	•	•	•	0	_	0			Junt, N
switch	ję – ję	Connector		2-wire		12 V		_	H7C	•	—			•	_			ect W
		Terminal		3-wire (NPN)		5 V, 12 V		_	G39A	_	_	_	<u> </u>	•	_	IC circuit		
auto		conduit	,,	2-wire		12 V	1	_	K39A		<u> </u>	_	_	•	_	_	Relay,	lug
	Diagnostic indication >	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	•	0	<u>  — </u>	0	IC circuit	PLC	음		
state	(2-colour indication)			3-wire (PNP)		,		M9PWV	M9PW	•	•	•	0	<u>  — </u>	. 0	0	Centralised Piping	
o o	Water resistant (2-colour			2-wire		12 V		M9BWV	M9BW	•	•	•	0	_	0	_		läii
Solid		Grommet		3-wire (NPN)		5 V, 12 V		M9NAV**	M9NA**	0	0	•	0	<u> </u>	0	IC circuit		Sent
0)				3-wire (PNP)		-	-	M9PAV**	M9PA**	0	0	•	0 - 0		-	=		
	indication)			2-wire		12 V		M9BAV**	M9BA**	0		•	0	_	0	<u> </u>		송
	With diagnostic output (2-colour indication)		-	4-wire (NPN)	-	5 V, 12 V			H7NF	•	_	•	O	_	0	IC circuit		.  의
			Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	_	_	_	IC circuit	_	With End Lock
_		Grommet					100 V	A93V	A93	•	_	•	•	_	_	_		ļļ.
switch		Gionnie	9N				100 V or less	A90V	A90	•	_	•	_	_	_	IC circuit		
N.			No Yes No				100 V, 200 V		B54	•	<u> </u>	•		—			Relay,	
5			2				200 V or less	_	B64	•	<u> </u>	•	_	_	_	_	PLC	
auto		Connector	No Yes	2-wire	24 V	12 V		_	C73C	•	<u> </u>	•		•	_			
Reed		COMMODICA	ž		,		24 V or less	_	C80C	•	_	•	•	•		IC circuit		
Re		Terminal							A33A	_	<u> </u>	_	_	•	_		PLC	
		conduit	es				100 V,		A34A	_	<u>                                     </u>	_	_	•	_	_	Relay,	
		DIN terminal	~				200 V		A44A	_	_	_	_	•			PLC	
	Diagnostic indication (2-colour indication)	Grommet					_	_	B59W		-		<u> </u>	<u> </u>	_			l i

- \*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers
  - (Example) M9NW (Example) M9NWM
    - (Example) M9NWL 3 m ..... L
    - (Example) M9NWZ None ······ N (Example) H7CN
- Solid state auto switches marked with "O" are produced upon receipt of order
- \* Do not indicate suffix "N" for no lead wire on D-A3□A/A44A/G39A/K39A models
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 \( \to \)-\( \t



Switch

Made to Order



#### **Specifications**

Bore s	ize [mm]	20	25	32	40		
Action		Single acting, Spring return/Single acting, Spring extend					
Туре			Pneu	matic			
Cushion			Rubber	bumper			
Fluid			А	ir			
Proof pressure			1.5	MPa			
Maximum operating	pressure		1.0 l	MPa			
Minimum operating	Single acting, Spring return	0.18 MPa					
pressure	Single acting, Spring extend		0.23	MPa			
Ambient and fluid te	mperature	Without auto switch: -10 °C to 70 °C (No freezing With auto switch: -10 °C to 60 °C					
Lubrication		Not required (Non-lube)					
Stroke length tolerar	nce	+1.4 0 mm					
Piston speed		50 to 750 mm/s					
Allowable	Male thread	0.27 J	0.4 J	0.65 J	1.2 J		
kinetic energy	Female thread	0.11 J	0.18 J	0.29 J	0.52 J		

#### **Standard Strokes**

Bore size [mm]	Standard stroke [mm] Note 1)
20	25, 50, 75, 100, 125, 150
25	25, 50, 75, 100, 125, 150
32	25, 50, 75, 100, 125, 150, 200
40	25, 50, 75, 100, 125, 150, 200, 250


Note 1) Other intermediate strokes can be manufactured upon receipt of order. Manufacture of intermediate strokes at 1 mm intervals is possible. (Spacers are not used.)

Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc


Note 3) Please consult with SMC for strokes which exceed the standard stroke length.

#### **Symbol**

Single acting, Spring return, Rubber bumper



Single acting, Spring extend, Rubber bumper





#### Made to Order

(For details, refer to pages 101 to 117.)

	(i or dotaile, roter to pages for to fift)
Symbol	Specifications
-XA□	Change of rod end shape
-XB12	External stainless steel cylinder*
-XC3	Special port location
-XC6	Made of stainless steel
-XC13	Auto switch rail mounting
-XC20	Head cover axial port
-XC25	No fixed throttle of connection port
-XC27	Double clevis and double knuckle pins made of stainless steel
-XC29	Double knuckle joint with spring pin
-XC52	Mounting nut with set screw
-XC85	Grease for food processing equipment

\* The shape is the same as the existing product.

#### Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.


#### **Mounting Bracket**

For the mounting bracket part numbers other than basic type, refer to page 38.

#### **Accessories**

Refer to pages 22 and 23 for accessories, since it is the same as standard type, double acting, single rod.

#### **Option: Ordering Example of Cylinder Assembly**



Mounting C: Single clevis Pivot bracket N: Yes Rod end bracket V: Single knuckle joint Auto switch D-M9BW: 2 pcs.

- Pivot bracket, single knuckle joint and auto switch are shipped together with the product, but not assembled.
- \* Pivot bracket is available only for C, T, U, E, V, UZ mounting types.
- \* No bracket is provided for the female rod end.



#### **Mounting and Accessories**

	Accessories		Stan	idard (m	ounted	to the b	ody)		Sta	ındard (	packag	ed toge	ether, b	ut not a	ssembl	ed)			tion
Mo	unting	Body	Mounting nut	Rod end nut (Male thread)	Single clevis	Double clevis	Note 7)	Mounting nut	Foot	Flange	Pivot bracket	Pivot Note 5) bracket pin	Double Note 5)	Trunnion	Mounting nut (For trunnion)	Clevis pivot bracket (CM2E/CM2V)	Clevis pivot Mass) bracket pin (CM2E/CM2V)	Single knuckle joint (Male thread only)	Note 6) Double knuckle joint (Male thread only)
В	Basic (Double-side bossed)	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
L	Axial foot	●(1 pc.)	(1 pc.) <sup>Note 2)</sup>	●(1 pc.)	_	_	_	(1 pc.) <sup>Note 2)</sup>	●(2 pcs.)	_	_	_	_	_	_	_	_	•	•
F	Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_		_		●(1 pc.)	_	_	_	_	_	_	_	•	
G	Head flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
С	Single clevis	●(1 pc.)	Note 3)	●(1 pc.)	●(1 pc.)	_	<b>●</b> (Max. 3 pcs.)	Note 3)	_	_	_	_	_	_	_	_	_	•	•
D	Double clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	●(1 pc.)	<b>●</b> (Max. 3 pcs.)	Note 3)	_	_	_	_	●(1 pc.)	_	_	_	_	•	•
U	Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Т	Head trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Ε	Integral clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	_	_	•	•
٧	Integral clevis (90°)	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)		_	_	_	_		_	_	_	•	•
BZ	Boss-cut/Basic	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_		_	_	_	_	_	_	_	_	•	•
FZ	Boss-cut/ Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
UZ	Boss-cut/ Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•

Note 1) Rod end nut is not provided for the female rod end.

Note 2) Two mounting nuts are packaged together.

Note 3) Mounting nut is not packaged for the clevis.

Note 4) Trunnion nut is packaged for U, T, UZ.

Note 5) Retaining rings are included.

Note 6) A pin and retaining rings (split pins for ø 40) are included.

Note 7) This is the part(s) used to adjust the clevis angle. Mounting quantity can vary.

#### Mounting Brackets/Part No.

Marratina handrat	Min.		Bore siz	Contents (for minimum and a greatity)				
Mounting bracket	order q'ty	20 25 32		32	40	Contents (for minimum order quantity)		
Foot*	2	CM-L020B	CM-L	032B	CM-L040B	2 foots, 1 mounting nut		
Flange	1	CM-F020B	CM-F	032B	CM-F040B	1 flange		
Single clevis**	1	CM-C020B	CM-C	032B	CM-C040B	1 single clevis, 3 liners		
Double clevis (with pin)**	1	CM-D020B	CM-D032B		CM-D032B		CM-D040B 1 double clevis, 3 liners, 1 clevis pin, 2 retaining ri	
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut		
Rod end nut	1	NT-02	02 NT-03		NT-04	1 rod end nut		
Mounting nut	1	SN-020B	B SN-032B		SN-040B	1 mounting nut		
Trunnion nut	1	TN-020B	TN-032B		TN-040B	1 trunnion nut		
Single knuckle joint	1	I-020B	I-03	32B	I-040B	1 single knuckle joint		
Double knuckle joint	1	Y-020B	Y-0	32B	Y-040B	1 double knuckle joint, 1 clevis pin, 2 retaining rings		
Clevis pin (Double clevis)	1		CDP-1		CDP-2	1 clevis pin, 2 retaining rings (split pins)		
Clevis pin (Double knuckle joint)	1		CDP-1		CDP-3	1 clevis pin, 2 retaining rings (split pins)		
Pivot bracket pin	1		CDP-1		CD-S03	1 pin, 2 retaining rings		
Clevis pivot bracket pin (For CM2E/CM2V)	1	CD-	S02	CD	-S03	1 clevis pin, 2 retaining rings		
Clevis pivot bracket (For CM2E/CM2V)	1	CM-E	020B	CM-	E032B	1 clevis pivot bracket, 1 clevis pin, 2 retaining rii		
Pivot bracket (For CM2C)	1		CM-B032		CM-B040 2 pivot brackets (1 of each type)			
Pivot bracket (For CM2T) 1 CM-B020 CM-B032		3032	CM-B040	2 pivot brackets (1 of each type)				

<sup>\*</sup> Order 2 foots per cylinder.

Direct Mount, Non-rotating Rod |

Centralised Piping With End Lock



<sup>\*\*</sup> 3 liners are included with a clevis bracket for adjusting the mounting angle.

<sup>\*\*\*</sup> A clevis pin and retaining rings (split pins for ø 40) are included.

#### Mounting Brackets, Accessories/Material, Surface Treatment

Segment	Description	Material	Surface treatment		
	Foot	Carbon steel	Nickel plating		
	Flange	Carbon steel	Nickel plating		
Mounting brackets	Single clevis	Carbon steel	Nickel plating		
Didonoto	Double clevis	Carbon steel	Nickel plating		
	Trunnion	Cast iron	Electroless nickel plating		
	Rod end nut	Carbon steel	Zinc chromated		
	Mounting nut	Carbon steel	Nickel plating		
	Trunnion nut	Carbon steel	Nickel plating		
	Clevis pivot bracket	Carbon steel	Nickel plating		
	Clevis pivot bracket pin	Carbon steel	(None)		
Accessories	Single knuckle joint	Carbon steel ø 40: Free-cutting steel	Electroless nickel plating		
	Double knuckle joint	Carbon steel ø 40: Cast iron	Electroless nickel plating Metallic bronze colour painted for ø 40		
	Double clevis pin	Carbon steel	(None)		
	Double knuckle joint pin	Carbon steel	(None)		
	Pivot bracket	Carbon steel	Nickel plating		
	Pivot bracket pin	Carbon steel	(None)		

### 

Be sure to read this before handling. Refer to the back I cover for Safety Instructions. For Actuator and Auto I Switch Precautions, refer to "Handling Precautions for I SMC Products" and the Operation Manual on SMC I website, http://www.smc.eu

#### Handling

#### **△** Warning

#### 1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

#### **⚠** Caution

#### 1. Not able to disassemble.

Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

#### 2. Use caution to the popping of a retaining ring.

When replacing rod seals and removing and mounting a retaining ring, use a proper tool (retaining ring plier: tool for installing a type C retaining ring). Even if a proper tool is used, it is likely to inflict damage to a human body or peripheral equipment, as a retaining ring may be flown out of the tip of a plier. Be much careful with the popping of a retaining ring. Besides, be certain that a retaining ring is placed firmly into the groove of rod cover before supplying air at the time of installment.

#### 3. Do not touch the cylinder during operation.

Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

- 4. The oil stuck to the cylinder is grease.
- 5. The base oil of grease may seep out.
- When using a rod end bracket and/or pivot bracket, make sure they do not interfere with other brackets, workpieces and rod section, etc.

#### Weights

Spring	g Return				[kg]
	Bore size [mm]	20	25	32	40
	25 stroke	0.20	0.30	0.42	0.77
	50 stroke	0.22	0.33	0.46	0.84
	75 stroke	0.27	0.42	0.58	1.03
Basic	100 stroke	0.29	0.45	0.63	1.09
weight	125 stroke	0.35	0.54	0.76	1.29
	150 stroke	0.37	0.57	0.80	1.36
	200 stroke	_	_	0.97	1.61
	250 stroke		_	1.87	
	Foot	0.15	0.16	0.16	0.27
	Flange	0.06	0.09	0.09	0.12
	Single clevis	0.04	0.04	0.42 0.46 0.58 0.63 0.76 0.80 0.97 —	0.09
Mounting	Double clevis	0.05	0.06	0.06	0.13
bracket	Trunnion	0.04	0.07	0.07	0.10
weight	Clevis integrated	-0.02	-0.02	-0.01	-0.04
	Boss-cut/Basic	-0.01	-0.02	-0.02	-0.03
	Boss-cut/Flange	0.05	0.07	0.07	0.09
	Boss-cut/Trunnion	0.03	0.05	0.42 0.46 0.58 0.63 0.76 0.80 0.97 0.16 0.09 0.04 0.06 0.07 0.01 0.02 0.07 0.05 0.14 0.06	0.07
	Clevis pivot bracket (with pin)	0.07	0.07	0.14	0.14
Option bracket	Single knuckle joint	0.06	0.06	0.06	0.23
	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20

Calculation:

(Example) CM2L32-100SZ (Bore size ø 32, Foot, 100 stroke) 0.63 (Basic weight) + 0.16 (Mounting bracket weight) = 0.79 kg

**Spring Extend** 

FI.	1

Spring	g Extend				[kg
	Bore size [mm]	20	25	32	40
	25 stroke	0.19	0.29	0.40	0.74
	50 stroke	0.21	0.32	0.44	0.81
	75 stroke	0.25	0.39	0.54	0.97
Basic	100 stroke	0.19 0.29 0.40 0.21 0.32 0.44 0.25 0.39 0.54 0.27 0.42 0.58 0.32 0.49 0.69 0.34 0.52 0.73	0.58	1.03	
weight	125 stroke	0.32	0.49	0.69	1.20
	150 stroke	0.34	0.52	0.73	1.27
	200 stroke	0.19         0.29         0.40           0.21         0.32         0.44           0.25         0.39         0.54           0.27         0.42         0.58           0.32         0.49         0.69           0.34         0.52         0.73           —         —         0.88           —         —         —           0.15         0.16         0.16           0.06         0.09         0.09           0.04         0.04         0.04           0.05         0.06         0.06           0.04         0.07         0.07           -0.02         -0.02         -0.01           -0.01         -0.02         -0.02           0.05         0.07         0.07           0.03         0.05         0.05           0.07         0.07         0.14           0.06         0.06         0.06	1.49		
	250 stroke	_	_	_	1.72
	Foot	0.15	0.16	0.16	0.27
	Flange	0.06	0.09	0.09	0.12
	Single clevis	0.04	0.19         0.29         0.40           0.21         0.32         0.44           0.25         0.39         0.54           0.27         0.42         0.58           0.32         0.49         0.69           0.34         0.52         0.73           —         —         0.88           —         —         —           0.15         0.16         0.16           0.06         0.09         0.09           0.04         0.04         0.04           0.05         0.06         0.06           0.04         0.07         0.07           -0.02         -0.02         -0.01           -0.01         -0.02         -0.02           0.05         0.07         0.07           0.03         0.05         0.05           0.07         0.07         0.14           0.06         0.06         0.06	0.04	0.09
Mounting	Double clevis	0.05	0.06	0.06	0.13
bracket	Trunnion	0.04	0.07	0.07	0.10
weight	Clevis integrated	-0.02	-0.02	-0.01	-0.04
	Boss-cut/Basic	-0.01	-0.02	-0.02	-0.03
	Boss-cut/Flange	0.05	0.07	0.07	0.09
	Boss-cut/Trunnion	0.03	0.05	0.05	0.07
	Clevis pivot bracket (with pin)	0.07	0.07	0.14	0.14
Option bracket	Single knuckle joint	0.06	0.06	0.06	0.23
D. aonot	Double knuckle joint (with pin)	0.07	0.07	0.40 0.44 0.54 0.58 0.69 0.73 0.88 0.16 0.09 0.04 0.06 0.07 -0.01 -0.02 0.07 0.05 0.14 0.06	0.20

This type has the One-touch fitting integrated in a cylinder, which enables to reduce the piping labor and installing space dramatically.



**Specifications** 

Action	Single acting, Spring return	Single acting, Spring extend		
Bore size [mm]	ø 20, ø 25,	ø 32, ø 40		
Max. operating pressure	1.0 MPa			
Min. operating pressure	0.18 MPa	0.23 MPa		
Cushion	Rubber bumper			
Piping	One-touc	ch fittings		
Piston speed	50 to 75	50 mm/s		
Mounting  Basic, Axial foot, Rod flange, Head fla Single clevis, Double clevis, Rod trun Head trunnion, Integral clevis, Boss-c				

<sup>\*</sup> Auto switch can be mounted.

Applicable Tubing O.D./I.D.

Bore size [mm]	20	25	32	40		
Applicable tubing O.D./I.D. [mm]	6/4	6/4	6/4	8/6		
Applicable tubing material	Can be used for either nylon, soft nylon o polyurethane tubing.					

#### **⚠** Caution

- 1. One-touch fitting cannot be replaced.
- One-touch fitting is press-fit into the cover, thus cannot be replaced.
- 2. Refer to Fittings and Tubing Precautions for handling One-touch fittings.

ble Acting, Single F

Standard le Acting, Double Rod CM2W

ing ReturnExtend Double

M2K

g, Double Rod Doubl

ing Return Extend Double Act

Bod Single Acting, Spri

Durble Acting, Single R

CMORK

Double Acting, Single Rod CM2 P

With End Lock


CBM2




## Series CM2

#### Construction

#### Spring return



#### **Spring extend**



#### **Component Parts**

No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2A	Head cover A	Aluminium alloy	Anodised
2B	Head cover B	Aluminium alloy	Anodised
2C	Head cover C	Aluminium alloy	Anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	
5	Piston rod	Carbon steel	Hard chrome plating
6	Bushing	Bearing alloy	
7	Seal retainer	Stainless steel	
8	Return spring	Steel wire	Zinc chromated
9	Spring guide	Aluminium alloy	Chromated
10	Spring seat	Aluminium alloy	Chromated
11	Plug with fixed orifice	Alloy steel	Black zinc chromated
12	Retaining ring	Carbon steel	Phosphate coating

No.	Description	Material	Note
13	Bumper	Resin	ø 25 or larger is
14	Bumper	Resin	common.
15	Piston seal	NBR	
16	Wear ring	Resin	
17	Clevis bushing	Bearing alloy	
18	Mounting nut	Carbon steel	Nickel plating
19	Rod end nut	Carbon steel	Zinc chromated
20	Magnet	_	CDM2□20 to 40-□SZ
21	Rod seal	NBR	

Replacement Part: Seal

With Rubber Bumper (Spring extend only)


			I - ( - I -		- ,,	
No	Description	Motorial		Part	no.	
NO.	Description	Ivialeriai	20	25	32	40
21	Rod seal	NBR	CM20Z-PS	CM25Z-PS	CM32Z-PS	CM40Z-PS


<sup>\*</sup> Since the seal does not include a grease pack, order it separately. Grease pack part number: GR-S-010 (10 g)













#### Spring extend





#### **Boss-cut**



#### Female rod end Spring return







																			[mm]
Bore size	Α	AL	B <sub>1</sub>	<b>B</b> <sub>2</sub>	D	Е	F	FL	G	Н	H <sub>1</sub>	H <sub>2</sub>	I	K	KA	MM	NA	NN	Р
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	8	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	8	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	8	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8
40	24	21	22	41	14	32_0.039	16	13.5	11	50	8	10	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4

Dimensio	ns b	y Str	oke							[mm
Stroke	1 10	50	51 to	100	101 t	o 150	151 t	o 200	201 t	o 250
Bore size	S	ZZ	S	ZZ	S	ZZ	S	ZZ	S	ZZ
20	87	141	112	166	137	191	_	_	_	_
25	87	145	112	170	137	195	_	_	_	_
32	89	147	114	172	139	197	164	222	_	_
40	113	179	138	204	163	229	188	254	213	279

DUSS-CUL					[mm]
Stroke	1 10 50	51 to 100	101 to 150	151 to 200	201 to 250
Bore size	ZZ	ZZ	ZZ	ZZ	ZZ
20	128	153	178	_	_
25	132	157	182	_	_
32	134	159	184	209	_
40	163	188	213	238	263

Female F	od E	nd											[mm]	
Stroke		н	ММ	1 to	50	51 to	100	101 t	o 150	151 t	o 200	201 t	o 250	
Bore size	<b>A</b> 1	п	IVIIVI	S	ZZ	S	ZZ	S	ZZ	S	ZZ	S	ZZ	*
20	8	20	M4 x 0.7	87	120	112	145	137	170	_	_	_	_	
25	8	20	M5 x 0.8	87	120	112	145	137	170	_	_	_	_	*
32	12	20	M6 x 1	89	122	114	147	139	172	164	197	_	_	
40	13	21	M8 x 1.25	113	150	138	175	163	200	188	225	213	250	

- \* When female thread is used, use a thin wrench when tightening the piston rod.
- When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

Double Acting, Double Rod

Single Acting, Spring Return CM2

Non-rotating Rod

Double Acting, Double Rdring, S

CM2KW

CM2

cing, Spring Return Extend Double

Double Acting, Single Rod

1g | Direct Mount, Non-rotating Rod | Double Acting, Single Rod | Double Rod | Doub

Lock | Centralised Piping |
Double Acting, Single Rod
CM2 | P

With End Lock


CBM2

Made to Order Auto Switch


## Series CM2

#### **Axial Foot (L)**

CM2L Bore size - Stroke S Z



#### **Spring extend**




																									1	[mm]
Bore size	Α	AL	В	Bı	B <sub>2</sub>	D	F	G	Н	H₁	H <sub>2</sub>	I	K	KA	LC	LD	LH	LT	LX	LZ	MM	NA	Р	Х	Υ	Z
20	18	15.5	40	13	26	8	13	8	41	5	8	28	5	6	4	6.8	25	3.2	40	55	M8 x 1.25	24	1/8	20	8	21
25	22	19.5	47	17	32	10	13	8	45	6	8	33.5	5.5	8	4	6.8	28	3.2	40	55	M10 x 1.25	30	1/8	20	8	25
32	22	19.5	47	17	32	12	13	8	45	6	8	37.5	5.5	10	4	6.8	28	3.2	40	55	M10 x 1.25	34.5	1/8	20	8	25
40	24	21	54	22	41	14	16	11	50	8	10	46.5	7	12	4	7	30	32	55	75	M14 x 1 5	42.5	1/4	23	10	27

Dimens	ions	s by	Stı	Dimensions by Stroke [mn													
Stroke		to 5	0	51	to 1	00	10	1 to 1	50	15	1 to 2	200	20	1 to 2	250		
Symbol Bore size	LS	S	ZZ	LS	S	ZZ	LS	S	ZZ	LS	S	ZZ	LS	S	ZZ		
20	127	87	156	152	112	181	177	137	206			_		_	_		
25	127	87	160	152	112	185	177	137	210		_	_		_	_		
32	129	89	162	154	114	187	179	139	212	204	164	237	_	_			
40	159	113	196	184	138	221	209	163	246	234	188	271	259	213	296		


<sup>\*</sup> The bracket is shipped together.

<sup>\*</sup> Refer to page 42 for female thread dimensions.


#### **Spring return**



#### Spring extend



#### **Boss-cut**



																											[mm]
Bore size	Α	AL	В	B <sub>1</sub>	B <sub>2</sub>	C <sub>2</sub>	D	Е	F	FD	FL	FT	FX	FY	FZ	G	Н	Ηı	H <sub>2</sub>	_	K	KA	MM	NA	NN	Р	Z
20	18	15.5	34	13	26	30	8	20_0.033	13	7	10.5	4	60	_	75	8	41	5	8	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	37
25	22	19.5	40	17	32	37	10	26_0.033	13	7	10.5	4	60	_	75	8	45	6	8	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	41
32	22	19.5	40	17	32	37	12	26_0.033	13	7	10.5	4	60	_	75	8	45	6	8	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	41
40	24	21	52	22	41	47.3	14	32_0,039	16	7	13.5	5	66	36	82	11	50	8	10	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	45

Dimens	ions	s by	Str	oke						[mm]
Stroke		50	51 to	100	101 t	o 150	151 t	o 200	201 t	250
Symbol Bore size	S	ZZ	S	ZZ	S	ZZ	S	ZZ	S	ZZ
20	87	141	112	166	137	191	_	-		_
25	87	145	112	170	137	195		1	1	_
32	89	147	114	172	139	197	164	222		_
40	113	179	138	204	163	229	188	254	213	279

ıt				[mm]
1 to 50	51 to 100	101 to 150	151 to 200	201 to 250
ZZ	ZZ	ZZ	ZZ	ZZ
128	153	178		_
132	157	182	_	_
134	159	184	209	_
163	188	213	238	263
	1 to 50 <b>ZZ</b> 128 132 134	1 to 50 51 to 100 <b>ZZ ZZ</b> 128 153  132 157  134 159	1 to 50         51 to 100         101 to 150           ZZ         ZZ         ZZ           128         153         178           132         157         182           134         159         184	1 to 50         51 to 100         101 to 150         151 to 200           ZZ         ZZ         ZZ         ZZ           128         153         178         —           132         157         182         —           134         159         184         209

Made to Order

<sup>\*</sup> The bracket is shipped together.


<sup>\*</sup> Refer to page 42 for female thread dimensions.

## Series CM2


#### Head Flange (G)

CM2G Bore size - Stroke STZ

#### Spring return



#### Spring extend



																										[mm]
Bore size	Α	AL	В	Bı	B <sub>2</sub>	C <sub>2</sub>	D	E	F	FD	FL	FT	FX	FY	FZ	G	Н	H₁	H <sub>2</sub>	ı	K	KA	MM	NA	NN	Р
20	18	15.5	34	13	26	30	8	20_0.033	13	7	10.5	4	60	_	75	8	41	5	8	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8
25	22	19.5	40	17	32	37	10	26-0.033	13	7	10.5	4	60	_	75	8	45	6	8	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8
32	22	19.5	40	17	32	37	12	26-0.033	13	7	10.5	4	60	_	75	8	45	6	8	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8
40	24	21	52	22	41	47.3	14	32_0.039	16	7	13.5	5	66	36	82	11	50	8	10	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4

Dimensio	ns l	oy S	trol	ке											[mm]
Stroke		to 5	0	51	to 10	00	10	1 to 1	50	15	1 to 2	200	20	1 to 2	250
Bore size	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ
20	87	132	141	112	157	166	137	182	191			_			_
25	87	136	145	112	161	170	137	186	195	_	_	_	_	_	_
32	89	138	147	114	163	172	139	188	197	164	213	222	_	_	_
40	113	168	179	138	193	204	163	218	229	188	243	254	213	268	279


 $<sup>\</sup>ast$  The bracket is shipped together.


<sup>\*</sup> Refer to page 42 for female thread dimensions.

### Single Clevis (C)

### CM2C Bore size - Stroke S Z

#### Spring return





																							[mm]
Bore size	Α	AL	Bı	CD	CI	СХ	D	E	F	FL	G	Н	H1	I	K	KA	L	MM	NA	NN	Р	RR	U
20	18	15.5	13	9	24	10	8	20_0.033	13	10.5	8	41	5	28	5	6	30	M8 x 1.25	24	M20 x 1.5	1/8	9	14
25	22	19.5	17	9	30	10	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	30	M10 x 1.25	30	M26 x 1.5	1/8	9	14
32	22	19.5	17	9	30	10	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	30	M10 x 1.25	34.5	M26 x 1.5	1/8	9	14
40	24	21	22	10	38	15	14	32_0,039	16	13.5	11	50	8	46.5	7	12	39	M14 x 1.5	42.5	M32 x 2	1/4	11	18

<b>Dimensions by Stroke</b>
-----------------------------

nensions b	y St	roke	•											[mm]	
	Stroke         1 to 50         51 to 100         101 to 150         151 to 200           Symbol         S         7         77         S         7         77         S         7         77         77         S         7         77														
Bore size	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ
20	87	158	167	112	183	192	137	208	217	_	_	_	_	_	_
25	87	162	171	112	187	196	137	212	221	_	_	_	_	_	_
32	89	164	173	114	189	198	139	214	223	164	239	248	_	_	
40	113	202	213	138	227	238	163	252	263	188	277	288	213	302	313

<sup>\*</sup> Refer to page 42 for female thread dimensions.

Double Acting, Double Rod CM2KW Non-rotating Rod

Direct Mount, Non-rotating Rod

Centralised Piping


With End Lock CBM2


## Series CM2

#### **Double Clevis (D)**


CM2D Bore size - Stroke S Z


#### Spring return





#### Spring extend






																									[mm]
Bore size	Α	AL	Bı	CD	С	CL	CX	CZ	D	E	F	FL	G	Н	Нı	Т	K	KA	L	MM	NA	NN	Р	RR	U
20	18	15.5	13	9	24	25	10	19	8	20_0.033	13	10.5	8	41	5	28	5	6	30	M8 x 1.25	24	M20 x 1.5	1/8	9	14
25	22	19.5	17	9	30	25	10	19	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	30	M10 x 1.25	30	M26 x 1.5	1/8	9	14
32	22	19.5	17	9	30	25	10	19	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	30	M10 x 1.25	34.5	M26 x 1.5	1/8	9	14
40	24	21	22	10	38	41.2	15	30	14	32_0.039	16	13.5	11	50	8	46.5	7	12	39	M14 x 1.5	42.5	M32 x 2	1/4	11	18

Dimensio	ns b	y St	troke	Э											[mm]	
Stroke		1 to 50 51 to 100 101 to 150 151 to 200 201 to 250														
Symbol Bore size	ഗ	Z	ZZ	ഗ	Z	ZZ	S	Z	ZZ	ഗ	Z	ZZ	ഗ	Z	ZZ	
20	87	158	167	112	183	192	137	208	217	-	-	_	-	_	_	
25	87	162	171	112	187	196	137	212	221	1	1	_	1	_	_	
32	89	164	173	114	189	198	139	214	223	164	239	248	_		_	
40	113	202	213	138	227	238	163	252	263	188	277	288	213	302	313	


<sup>\*</sup> Refer to page 42 for female thread dimensions.




#### Spring return



#### Spring extend



#### **Boss-cut**



																								[mm]
Bore size	Α	AL	B <sub>1</sub>	B <sub>2</sub>	D	E	F	FL	G	Н	H₁	1	K	KA	MM	NA	NN	Р	TD	TT	TX	TY	TZ	Z
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	8	10	32	32	52	36
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	9	10	40	40	60	40
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	9	10	40	40	60	40
40	24	21	22	41	14	32_0.039	16	13.5	11	50	8	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	10	11	53	53	77	44.5

Dimensio	ns b	y St	trok	е						[mm]
Stroke	1 1 10	50	51 to	100	101 t	o 150	151 t	o 200	201 t	o 250
Bore size	S	ZZ	S	ZZ	S	ZZ	S	ZZ	S	ZZ
20	87	141	112	166	137	191	_	_	_	_
25	87	145	112	170	137	195	_	_	_	_
32	89	147	114	172	139	197	164	222	_	_
40	113	179	138	204	163	229	188	254	213	279

DOSS-Cut					[mm]
Stroke	1 10 50	51 to 100	101 to 150	151 to 200	201 to 250
Bore size	ZZ	ZZ	ZZ	ZZ	ZZ
20	128	153	178	_	_
25	132	157	182	_	_
32	134	159	184	209	_
40	163	188	213	238	263

MExitend Double Acting, Double F

Souble Acting, Single Rod S

Direct Mount, Non-rotating Rod

Double Acting, Single Rod

<sup>\*</sup> The bracket is shipped together.


<sup>\*</sup> Refer to page 42 for female thread dimensions.

## Series CM2


#### **Head Trunnion (T)**

## CM2T Bore size - Stroke S Z

**Spring return** 



#### **Spring extend**



																							[mm]
Bore size	Α	AL	B <sub>1</sub>	B <sub>2</sub>	D	Е	F	FL	G	Н	Ηı	-	K	KA	MM	NA	NN	Р	TD	TT	TX	TY	TZ
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	28	5	6	M8 x 1.25	24	M20 x 1.5	1/8	8	10	32	32	52
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	M10 x 1.25	30	M26 x 1.5	1/8	9	10	40	40	60
32	22	19.5	17	32	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	M10 x 1.25	34.5	M26 x 1.5	1/8	9	10	40	40	60
40	24	21	22	41	14	32_0.039	16	13.5	11	50	8	46.5	7	12	M14 x 1.5	42.5	M32 x 2	1/4	10	11	53	53	77

	Dimensi	ons	by S	trok	æ											[mm]
	Stroke	1 10 50 51 10 100 101 10 150 151 10 200 201 10														
В	ore size Symbol	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ
_	20	87	133	143	112	158	168	137	183	193	_	_	_	_	_	_
Ī	25	87	137	147	112	162	172	137	187	197	_	_	_	_	_	_
_	32	89	139	149	114	164	174	139	189	199	164	214	224	_	_	_
	40	113	168.5	179	138	193.5	204	163	218.5	229	188	243.5	254	213	268.5	279

<sup>\*</sup> The bracket is shipped together.


<sup>\*</sup> Refer to page 42 for female thread dimensions.


Direct Mount, Non-rotating Rod

Centralised Piping

With End Lock

#### **Integral Clevis (E)**





																							[mm]
Bore size	Α	AL	Вı	CD	CI	СХ	D	E	F	FL	G	Н	Ηı	ı	K	KA	L	MM	NA	NN	Р	RR	U
20	18	15.5	13	8	20	12	8	20_0.033	13	10.5	8	41	5	28	5	6	12	M8 x 1.25	24	M20 x 1.5	1/8	9	11.5
25	22	19.5	17	8	22	12	10	26-0.033	13	10.5	8	45	6	33.5	5.5	8	12	M10 x 1.25	30	M26 x 1.5	1/8	9	11.5
32	22	19.5	17	10	27	20	12	26-0.033	13	10.5	8	45	6	37.5	5.5	10	15	M10 x 1.25	34.5	M26 x 1.5	1/8	12	14.5
40	24	21	22	10	33	20	14	32_0.039	16	13.5	11	50	8	46.5	7	12	15	M14 x 1.5	42.5	M32 x 2	1/4	12	14.5

Dimensions by Stroke [mm]															
Stroke	·	1 to 50	)	5	1 to 10	00	10	1 to 1	50	15	1 to 2	00	20	1 to 2	50
Bore size Symbol	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ	S	Z	ZZ
20	87	140	149	112	165	174	137	190	199	_	_	_	_	_	_
25	87	144	153	112	169	178	137	194	203	_	_	_	_	_	_
32	89	149	161	114	174	186	139	199	211	164	224	236	_		_
40	113	178	190	138	203	215	163	228	240	188	253	265	213	278	290

Clevis P	Clevis Pivot Bracket [mi											[mm]	
Bore size	e LD	LF	LG	LH	LP	LT	LV	LY	1 to 50	51 to 100	101 to 150	151 to 200	201 to 250
Dore Size		LF	LG	LII	LP	LI	LV	Lī	LZ	LZ	LZ	LZ	LZ
20	6.8	15	30	30	37	3.2	18.4	59	177	202	227	_	_
25	6.8	15	30	30	37	3.2	18.4	59	181	206	231	_	_
32	9	15	40	40	50	4	28	75	199	224	249	274	_
40	9	15	40	40	50	4	28	75	228	253	278	303	328

<sup>\*</sup> Refer to page 42 for female thread dimensions.




# Air Cylinder: Non-rotating Rod Type **Double Acting, Single Rod**

Series CM2K



ø 20, ø 25, ø 32, ø 40



#### \* For female rod end, no rod boot is provided

#### Applicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.

		Electrical	itor	Wiring		Load volt	age	Auto swit	ch model	Lea	d wii	e len	igth [	[m]	Pre-wired	Appli	cable
Type	Special function	entry	ndicator light	(Output)		DC	AC			0.5	1	3		None	connector		ad
		0,	Ľ				7.0	Perpendicular	In-line		(M)	(L)	(Z)	(N)			
				3-wire (NPN)		5 V, 12 V		M9NV	M9N	•	•	•	0	_	0	IC circuit	
		Grommet		3-wire (PNP)		- 1, 12 1		M9PV	M9P	•	•	•	0	<u>  — </u>	0	- O on ount	
능				2-wire		12 V		M9BV	M9B	•	•	•	0	_	0	_	
switch		Connector		_					H7C	•	_	•	•	•	_		
S		Terminal		3-wire (NPN)		5 V, 12 V			G39A**	_	_	_	_	•		IC circuit	
auto		conduit	S	2-wire		12 V			K39A**		_	_	_	•		_	Relay,
e e	Diagnostic indication		Yes	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	•	0	_	0	IC circuit	PLC
state	(2-colour indication)			3-wire (PNP)				M9PWV	M9PW	•	•	•	0	<u> </u>	0	TO OHOUN	
o o	,			2-wire		12 V		M9BWV	M9BW	•	•	•	0	_	0	_	
Solid	Water resistant	Grommet		3-wire (NPN)		5 V, 12 V			M9NA***	0	0	•	0	_	0	IC circuit	
S	(2-colour			3-wire (PNP)				M9PAV***	M9PA***	0	0	•	0	<u> </u>	0	TO OHOUN	
	indication)			2-wire		12 V			M9BA***	0	0	•	0	_	0	_	
	With diagnostic output (2-colour indication)			4-wire (NPN)		5 V, 12 V		_	H7NF	•		•	0	<u> </u>	0	IC circuit	
			Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	_	•	_	_	_	IC circuit	_
_		Grommet					100 V	A93V	A93	•	—	•	•	<u> </u>	_	_	
switch		Gioiiiiiet	No Yes No Yes No				100 V or less	A90V	A90	•	_	•	—	<u> </u>	_	IC circuit	
Ν̈́			Yes				100 V, 200 V	_	B54**	•	_	•	•	<u> </u>	_		Relay,
8			2				200 V or less	_	B64**	•	_	•	_	_	_	_	PLC
auto		Connector	Yes	2-wire	24 V	12 V		_	C73C	•	_	•	•	•	_		
9		Connection	å	Z WIIC	Z-T V		24 V or less	_	C80C	•	_	•	•	•	_	IC circuit	
Reed		Terminal					_	_	A33A**	_	_	_	_	•	_		PLC
		conduit	es				100 V,	_	A34A**		_	_	_	•	_	_	Relay,
		DIN terminal	>				200 V	_	A44A**	_	_	<u> </u>	_	•	_		PLC
	Diagnostic indication (2-colour indication)	Grommet				_	_	_	B59W		_	•	_	_	_		. 20

- \*\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers.
- \* Lead wire length symbols: 0.5 m ·· (Example) M9NW
  - 1 m ..... M (Example) M9NWM (Example) M9NWL 3 m ..... L
  - (Example) M9NWZ None ······ N (Example) H7CN
- \* Solid state auto switches marked with "O" are produced upon receipt of order.
- \* Do not indicate suffix "N" for no lead wire on the D-A3□A/A44A/G39A/K39A models
- \*\* D-A3 A/A44A/G39A/K39A/B54/B64 cannot be mounted on bore sizes ø 20 and ø 25 cylinder with air cushion
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 \( \Box \) M9 \( \Box \) auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)

#### A cylinder which rod does not rotate because of the hexagonal rod shape.

Non-rotating accuracy ø 20, ø 25 —±0.7° ø 32, ø 40 —±0.5°


Can operate without lubrication.

The same installation dimensions as the standard cylinder.

#### Auto switches can also be mounted.

It can be installed with auto switches to simplify the detection of the stroke position of the cylinder.

#### **Symbol**





#### Made to Order (For details, refer to pages 101 to 117.)

Symbol	Specifications
-XA□	Change of rod end shape
-XB6	Heat resistant cylinder (-10 to 150 °C)
-XB12	External stainless steel cylinder*2
-XC3	Special port location
-XC6	Made of stainless steel
-XC8	Adjustable stroke cylinder/Adjustable extension type
-XC9	Adjustable stroke cylinder/Adjustable retraction type*1
-XC10	Dual stroke cylinder/Double rod type*1
-XC11	Dual stroke cylinder/Single rod type*1
-XC13	Auto switch rail mounting
-XC20	Head cover axial port
-XC22	Fluororubber seal
-XC25	No fixed throttle of connection port*1
-XC27	Double clevis and double knuckle pins made of stainless steel
-XC52	Mounting nut with set screw
-XC85	Grease for food processing equipment
-X446	PTFE grease

- \*1 Rubber bumper only.
- \*2 The shape is the same as the existing product.

#### Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- · Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.

#### Specifications

Во	ore size [mm]		20	25	32	40					
Rod non-ro	tating accu	racy	±0	.7°	±0	.5°					
Туре				Pneu	matic						
Action				Double actin	g, Single rod						
Fluid			Air								
Proof press	sure		1.5 MPa								
Maximum o	perating pr	essure		1.0	MPa						
Minimum o	m operating pressure 1.0 MPa 0.05 MPa										
Ambient an	d fluid tempe	erature	Without aเ With aเ	uto switch: -10 uto switch: -10	°C to 70 °C °C to 60 °C	No freezing)					
Lubrication	ı		Not required (Non-lube)								
Stroke leng	th tolerance	е	+1.4 0 mm								
Piston spe	ed			50 to 50	00 mm/s						
Cushion				Rubber bump	er, Air cushion						
	Rubber	Male thread	0.27 J	0.4 J	0.65 J	1.2 J					
Allowable	bumper	Female thread	0.11 J	0.18 J	0.29 J	0.52 J					
kinetic energy	Air cushion (Effective cushion	Male thread	0.54 J (11.0)	0.78 J (11.0)	1.27 J (11.0)	2.35 J (11.8)					
	length [mm])	Female thread	0.11 J	0.18 J	0.29 J	0.52 J					

#### **Standard Strokes**

Bore size [mm]	Standard stroke [mm] Note 1)	Maximum manufacturable stroke [mm]
20		
25	25 50 75 100 125 150 200 250 200	1000
32	25, 50, 75, 100, 125, 150, 200, 250, 300	1000
40		

Note 1) Intermediate strokes not listed above are produced upon receipt of order. Manufacture of intermediate strokes in 1 mm intervals is possible. (Spacers are not used.)

Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.

#### Option: Ordering Example of Cylinder Assembly

# Cylinder model: CDM2KC40-150Z-NV-M9BW Single clevis Single knuckle joint Pivot bracket / Auto switch

Mounting C: Single clevis Pivot bracket N: Yes Rod end bracket V: Single knuckle joint Auto switch D-M9BW: 2 pcs.

Pivot bracket, single knuckle joint and auto switch are shipped together with the product, but not assembled.

- \* Pivot bracket is available only for C, T, U, E, V, UZ mounting types.
- \* No bracket is provided for the female rod end.



## Series CM2K

## **Mounting and Accessories**

	Accessories		Stan	dard (m	ounted	to the b	ody)		Sta	ındard (	(packag	jed toge	ether, b	ut not a	ssembl	ed)		Op	tion
Мо	unting	Body	Mounting nut	Rod end nut (Male thread)	Single clevis	Double clevis	Note 7)	Mounting nut	Foot	Flange	Pivot bracket	Pivot Note 5) bracket pin	Double Note 5)	Trunnion	Mounting nut (For trunnion)	Clevis pivot bracket (CM2E/CM2V)	Clevis pivot Massil bracket pin (CM2E/CM2V)	Single knuckle joint (Male thread only)	Note 6) Double knuckle joint (Male thread only)
В	Basic (Double-side bossed)	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
L	Axial foot	●(1 pc.)	(1 pc.) <sup>Note 2)</sup>	●(1 pc.)	_	_	_	●(1 pc.) <sup>Note 2)</sup>	●(2 pcs.)	_	_	_	_	_	_	_	_	•	•
F	Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
G	Head flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
С	Single clevis	●(1 pc.)	Note 3)	●(1 pc.)	●(1 pc.)	_	●(Max. 3 pcs.)	Note 3)	_	_	_	_	_	_	_	_	_	•	•
D	Double clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	●(1 pc.)	●(Max. 3 pcs.)	Note 3)	_	_	_	_	●(1 pc.)	_	_	_	_	•	•
U	Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Т	Head trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Е	Integral clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	_	_	•	•
V	Integral clevis (90°)	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	_	_	•	•
BZ	Boss-cut/Basic	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
FZ	Boss-cut/ Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_		_	_	•	•
UZ	Boss-cut/ Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•

Note 1) Rod end nut is not provided for the female rod end.

Note 2) Two mounting nuts are packaged together.

Note 3) Mounting nut is not packaged for the clevis. Note 4) Trunnion nut is packaged for U, T, UZ.

Note 5) Retaining rings are included.

Note 6) A pin and retaining rings (split pins for ø 40) are included.

Note 7) This is the part(s) used to adjust the clevis angle. Mounting quantity can vary.

#### Mounting Brackets/Part No.

Manuskin ni kanadan	Min.		Bore siz	ze [mm]		O and a state (for a sainting and a sainting a state of
Mounting bracket	order q'ty	20	25	32	40	Contents (for minimum order quantity)
Foot*	2	CM-L020B	CM-L	032B	CM-L040B	2 foots, 1 mounting nut
Flange	1	CM-F020B	CM-F	032B	CM-F040B	1 flange
Single clevis**	1	CM-C020B	CM-C	032B	CM-C040B	1 single clevis, 3 liners
Double clevis (with pin)***	1	CM-D020B	CM-D	032B	CM-D040B	1 double clevis, 3 liners, 1 clevis pin, 2 retaining rings
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut
Rod end nut	1	NT-02	NT-	-03	NT-04	1 rod end nut
Mounting nut	1	SN-020B	SN-0	32B	SN-040B	1 mounting nut
Trunnion nut	1	TN-020B	TN-0	32B	TN-040B	1 trunnion nut
Single knuckle joint	1	I-020B	I-03	32B	I-040B	1 single knuckle joint
Double knuckle joint	1	Y-020B	Y-00	32B	Y-040B	1 double knuckle joint, 1 clevis pin, 2 retaining rings
Clevis pin (Double clevis)	1		CDP-1		CDP-2	1 clevis pin, 2 retaining rings (split pins)
Clevis pin (Double knuckle joint)	1		CDP-1		CDP-3	1 clevis pin, 2 retaining rings (split pins)
Pivot bracket pin	1		CDP-1		CD-S03	1 pin, 2 retaining rings
Clevis pivot bracket pin (For CM2E/CM2V)	1	CD-	S02	CD-	·S03	1 clevis pin, 2 retaining rings
Clevis pivot bracket (For CM2E/CM2V)	1	CM-E	020B	CM-E	032B	1 clevis pivot bracket, 1 clevis pin, 2 retaining rings
Pivot bracket (For CM2C)	1		CM-B032		CM-B040	2 pivot brackets (1 of each type)
Pivot bracket (For CM2T)	1	CM-B020	CM-E	3032	CM-B040	2 pivot brackets (1 of each type)

<sup>\*</sup> Order 2 foots per cylinder.



<sup>\*\* 3</sup> liners are included with a clevis bracket for adjusting the mounting angle.

<sup>\*\*\*</sup> A clevis pin and retaining rings (split pins for  $\emptyset$  40) are included.

#### **⚠** Warning

#### 1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

Handling

#### 2. Do not operate with the cushion needle in a fully closed condition.

Using it in the fully closed state will cause the cushion seal to be damaged. When adjusting the cushion needle, use the "Hexagon wrench key: nominal size 1.5".

3. Do not open the cushion needle wide excessively.

If the cushion needle were set to be completely wide (more than 3 turns from fully closed), it would be equivalent to the cylinder with no cushion, thus making the impacts extremely high. Do not use it in such a way. Besides, using with fully open could give damage to the piston or cover.

#### **⚠** Caution

 Avoid using the air cylinder in such a way that rotational torque would be applied to the piston rod.

If rotational torque is applied, the non-rotating guide will become deformed, thus affecting the nonrotating accuracy.

Refer to the table below for the approximate values

of the allowable range of rotational torque.

Allowable rotational torque	ø <b>20</b>	ø <b>25</b>	ø <b>32</b>	ø <b>40</b>
(N⋅m or less)	0.2	0.25	0.25	0.44

To screw a bracket or a nut onto the threaded portion at the tip of the piston rod, make sure to retract the piston rod entirely, and place a wrench over the flat portion of the rod that protrudes.

Tighten it by giving consideration to prevent the tightening torque from being applied to the nonrotating guide.



2. When replacing rod seals, please contact SMC. Air leakage may be happened, depending on the position in which a rod seal is fitted. Thus, please contact SMC when replacing them.

#### 3. Not able to disassemble.

Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

4. Do not touch the cylinder during operation.
Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

- 5. The oil stuck to the cylinder is grease.
- 6. The base oil of grease may seep out.
- 7. When using a rod end bracket and/or pivot bracket, make sure they do not interfere with other brackets, workpieces and rod section, etc.
- 8. Combine the rod end section, so that a rod boot

might not be twisted.

If a rod boot is installed with being twisted when installing a cylinder, it will cause a rod boot to fail during operation.

#### Mounting Brackets, Accessories/Material, Surface Treatment

Segment	Description	Material	Surface treatment
	Foot	Carbon steel	Nickel plating
<b>,</b> [	Flange	Carbon steel	Nickel plating
Mounting brackets	Single clevis	Carbon steel	Nickel plating
Diackets	Double clevis	Carbon steel	Nickel plating
	Trunnion	Cast iron	Electroless nickel plating
	Rod end nut	Carbon steel	Zinc chromated
	Mounting nut	Carbon steel	Nickel plating
	Trunnion nut	Carbon steel	Nickel plating
	Clevis pivot bracket	Carbon steel	Nickel plating
	Clevis pivot bracket pin	Carbon steel	(None)
Accessories	Single knuckle joint	Carbon steel ø 40: Free-cutting steel	Electroless nickel plating
	Double knuckle joint	Carbon steel	Electroless nickel plating
	Double kiluckie joilit	ø 40: Cast iron	Metallic bronze colour painted for ø 40
	Double clevis pin	Carbon steel	(None)
	Double knuckle joint pin	Carbon steel	(None)
	Pivot bracket	Carbon steel	Nickel plating
	Pivot bracket pin	Carbon steel	(None)

#### Weights

					[kg
	Bore size [mm]	20	25	32	40
	Basic	0.14	0.21	0.28	0.57
	Axial foot	0.29	0.37	0.44	0.84
	Flange	0.20	0.30	0.37	0.69
	Integral clevis	0.12	0.19	0.27	0.53
Basic	Single clevis	0.18	0.25	0.32	0.66
weight	Double clevis	0.19	0.27	0.33	0.70
	Trunnion	0.18	0.28	0.34	0.67
	Boss-cut/Basic	0.13	0.19	0.26	0.53
	Boss-cut/Flange	0.19	0.28	0.35	0.66
	Boss-cut/Trunnion	0.17	0.26	0.32	0.63
Additional v	veight per 50 mm of stroke	0.04	0.07	0.09	0.14
Ontion	Clevis pivot bracket (with pin)	0.07	0.07	0.14	0.14
Option bracket	Single knuckle joint	0.06	0.06	0.06	0.23
Diacket	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20

Calculation: (Example) CM2KL32-100Z Basic weight------0.44 (Foot, Ø 32)

• Additional weight ..... 0.09/50 stroke

• Cylinder stroke ..... 100 stroke  $0.44 + 0.09 \times 100/50 = 0.62 \text{ kg}$ 

## **Precautions**

I Be sure to read this before handling. Refer to the back cover for I I Safety Instructions. For Actuator and Auto Switch Precautions, refer I I to "Handling Precautions for SMC Products" and the Operation I I Manual on SMC website, http://www.smc.eu

Lible Acting, Double F


CM2

Switch


## Series CM2K

#### Construction

#### Rubber bumper



#### With air cushion



#### **Component Parts**

No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2A	Head cover A	Aluminium alloy	Anodised
2B	Head cover B	Aluminium alloy	Anodised
2C	Head cover C	Aluminium alloy	Anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	
5	Piston rod	Stainless steel	
6	Non-rotating guide	Bearing alloy	
7	Seal retainer	Carbon steel	Nickel plating
8	Retaining ring	Carbon steel	Phosphate coating
9	Clevis bushing	Copper oil-impregnated sintered alloy	
10	Bumper	Resin	
11	Bumper	Resin	


No.	Description	Material	Note
INO.	Description	ivialeriai	Note
12	Retaining ring	Stainless steel	
13	Piston seal	NBR	
14	Wear ring	Resin	
15	Mounting nut	Carbon steel	Nickel plating
16	Rod end nut	Carbon steel	Zinc chromated
17	Magnet	_	CDM2K□20 to 40-□Z
18	Rod seal	NBR	

#### **Replacement Part: Seal**


● Wi	● With Rubber Bumper/With Air Cushion									
No	Description	Motorial		Part	no.					
INO.	Description	Malena	20	25	32	40				
18	Rod seal	NBR	CM2K20-PS	CM2K25-PS	CM2K32-PS	CM2K40-PS				

<sup>\*</sup> Since the seal does not include a grease pack, order it separately. Grease pack part number: GR-S-010 (10 g)






With rod boot



Boss-cut





With air cushion

40

41 | 46 | 20







																			[mm]
Bore size	Α	AL	B <sub>1</sub>	B <sub>2</sub>	E	F	FL	G	Н	H₁	H <sub>2</sub>	I	KB	MM	NA	NN	Р	S	ZZ
20	18	15.5	13	26	20_0.033	13	10.5	8	41	5	8	28	8.2	M8 x 1.25	24	M20 x 1.5	1/8	62	116
25	22	19.5	17	32	26_0.033	13	10.5	8	45	6	8	33.5	10.2	M10 x 1.25	30	M26 x 1.5	1/8	62	120
32	22	19.5	17	32	26_0.033	13	10.5	8	45	6	8	37.5	12.2	M10 x 1.25	34.5	M26 x 1.5	1/8	64	122
40	24	21	22	41	32-0.039	16	13.5	11	50	8	10	46.5	14.2	M14 x 1.5	42.5	M32 x 2	1/4	88	154

With Rod Boot												[mm]								
Symbol B3			4	f h				e			ZZ					JH	JW			
Stroke Bore size	<b>D</b> 3	е	'	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	JII	JW
20	30	36	18	68	81	93	106	131	12.5	25	37.5	50	75	143	156	168	181	206	23.5	10.5
25	32	36	18	72	85	97	110	135	12.5	25	37.5	50	75	147	160	172	185	210	23.5	10.5
32	32	36	18	72	85	97	110	135	12.5	25	37.5	50	75	149	162	174	187	212	23.5	10.5

25

Boss-cut						[mm]
			ZZ			
Bore size	Without		Wit	h rod b	oot	
	rod boot	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300
20	103	130	143	155	168	193
25	107	134	147	159	172	197
32	109	136	149	161	174	199
40	138	165	178	190	203	228

**Dimensions of Each Mounting Bracket** 

90

102

77

115

140

12.5

With Air Cushion [mm]							
Bore size	WA						
20	13						
25	13						
32	13						
40	16						

37.5

50

75

181

194

206

Female R	Female Rod End [mm]								
Bore size	<b>A</b> 1	Н	MM	ZZ					
20	8	20	M4 x 0.7	95					
25	8	20	M5 x 0.8	95					
32	12	20	M6 x 1	97					
40	13	21	M8 x 1.25	125					

219

\* When female thread is used, use a thin wrench when tightening the piston rod.

244

\* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

The dimensions are the same as standard type, double acting, single rod, except the configuration of the piston rod. Refer to pages 14 to 21. Specifications for the auto switch equipped type are the same as the CDM2 series standard type.

Double Acting, Single

Double Acting, Double Rod

nge Acting, Spring Return/Extend

N CM2

Non-rotating Rod
Spring Return Extend Double Acting, Double Rod

Direct Mount

Souble Acting, Single Rod

CM2R

Direct Mount, Non-rotating Rod
Double Acting, Single Rod
CM2BK

Centralised Piping

Double Acting, Single Rod

With End Lock

CBM2

Made to Order


# Air Cylinder: Non-rotating Rod Type Double Acting, Double Rod

Series CM2KW



ø 20, ø 25, ø 32, ø 40

#### **How to Order**



refer to the table below.

#### Applicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.

		Electrical	ndicator light	Wiring		Load volt	age	Auto swit	ch model	Lea	d wii	e len	gth	[m]	Pre-wired	Annli	cable
Туре	Special function	entry	lica igh	(Output)	г	oc	AC	Auto Swit	cirinodei	0.5	1	3	5	None	connector		ad
		Citily	Inc	(Output)			AO	Perpendicular	In-line	(—)	(M)	(L)	(Z)	(N)	Connector	10	au
				3-wire (NPN)		5 V, 12 V		M9NV	M9N	•	•	•	0	<u> </u>	0	IC circuit	
		Grommet		3-wire (PNP)		J V, 12 V		M9PV	M9P	•	•	•	0	_	0	10 circuit	
년 당				2-wire		12 V		M9BV	M9B	•	•	•	0	_	0	_	
switch		Connector		_				_	H7C	•	_	•	•	•	_		
S		Terminal		3-wire (NPN)		5 V, 12 V			G39A**	_	_	_	_	•	_	IC circuit	
auto		conduit	S	2-wire		12 V		_	K39A**	_		_	_	•	_		Relay,
e	Diagnostic indication		Ye	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	•	0	_	0	IC circuit	PLC
state	(2-colour indication)			3-wire (PNP)				M9PWV	M9PW	•	•	•	0	_	0	10 000	
o p	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			2-wire		12 V		M9BWV	M9BW	•	•	•	0	<u> </u>	0		
Solid	Water resistant	Grommet		3-wire (NPN)		5 V, 12 V		M9NAV***	M9NA***	0	0	•	0	_	0	IC circuit	
0)	(2-colour			3-wire (PNP)				M9PAV***	M9PA***	0	0	•	0	_	0		
	indication)			2-wire		12 V		M9BAV***	M9BA***	0	0	•	0	_	0	<u> </u>	
	With diagnostic output (2-colour indication)			4-wire (NPN)		5 V, 12 V		_	H7NF	•	_	•	0	_	0	IC circuit	
			Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	_	_	_	IC circuit	_
_		Grommet					100 V	A93V	A93	•	_	•	•	—	_	_	
switch		Gioillillet	No Yes No Yes No				100 V or less	A90V	A90	•	_	•	_	<u> </u>	_	IC circuit	
Š			Yes				100 V, 200 V	_	B54**	•	_	•	•	<u> </u>	_		Relay,
			2				200 V or less	_	B64**	•	_	•	_	_	_	_	PLC
anto		Connector	Yes	2-wire	24 V	12 V		_	C73C	•	_	•	•	•	_		]
eq		Connector	Š	Z-WIIG	24 V		24 V or less	_	C80C	•	_	•	•	•	_	IC circuit	
Reed		Terminal						_	A33A**	_	_	_	_	•	_	]	PLC
		conduit	es				100 V,		A34A**	_	_	_	_	•	_	_	Relay.
		DIN terminal	>				200 V	_	A44A**	_	_	_	_	•	_	_	PLC
	Diagnostic indication (2-colour indication)	Grommet				-	_	_	B59W		—	•	_	<b> </b> —	_		'

- \*\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers.
- \* Lead wire length symbols: 0.5 m ······ (Example) M9NW
  - 1 m ······ M (Example) M9NWM 3 m ····· L (Example) M9NWL
  - 5 m ······ Z (Example) M9NWZ None ····· N (Example) H7CN
- \* Solid state auto switches marked with "O" are produced upon receipt of order.
- \* Do not indicate suffix "N" for no lead wire on the D-A3 $\square$ A/A44A/G39A/K39A models.
- \*\* D-A3□A/A44A/G39A/K39A/B54/B64 cannot be mounted on bore sizes ø 20 and ø 25 cylinder with air cushion.
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 UM 9 Um auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)

# A cylinder which rod does not rotate because of the hexagonal rod shape.

Non-rotating accuracy Ø 20, Ø 25 —±0.7° Ø 32, Ø 40 —±0.5°

Can operate without lubrication.


The same installation dimensions as the standard cylinder.


# Auto switches can also be mounted.

It can be installed with auto switches to simplify the detection of the stroke position of the cylinder.

#### **Symbol**

#### Rubber bumper







## Made to Order (For details, refer to pages 101 to 117.)

Symbol	Specifications
-XA□	Change of rod end shape
-XB6	Heat resistant cylinder (-10 to 150 °C)
-XC3	Special port location
-XC6	Made of stainless steel
-XC13	Auto switch rail mounting
-XC22	Fluororubber seal
-XC25	No fixed throttle of connection port*
-XC52	Mounting nut with set screw
-XC85	Grease for food processing equipment
-X446	PTFE grease

<sup>\*</sup> Rubber bumper only.

#### **Specifications**

В	ore size [mm]		20	25	32	40				
Rod non-ro	tating accura	су	±0	±0.7° ±0.5°						
Туре				Pneu	matic					
Cushion				Rubber bump	er, Air cushion					
Action				Double acting	g, Double rod					
Fluid				А	ir					
Proof press	ure			1.5	MРа					
Maximum o	perating pre	ssure		1.0	MРа					
Minimum o	perating pres	sure	0.08 MPa							
Ambient and	I fluid temper	ature		uto switch: -10 uto switch: -10		o freezing)				
Lubrication			Not required (Non-lube)							
Stroke leng	th tolerance		+1.4 0 mm							
Piston spee	ed			50 to 50	00 mm/s					
	Rubber	Male thread	0.27 J	0.4 J	0.65 J	1.2 J				
Allowable	bumper	Female thread	0.11 J	0.18 J	0.29 J	0.52 J				
kinetic energy	Air cushion (Effective cushion	Male thread	0.54 J (11.0)	0.78 J (11.0)	1.27 J (11.0)	2.35 J (11.8)				
	length [mm])	Female thread	0.11 J	0.18 J	0.29 J	0.52 J				

#### **Standard Strokes**

Bore size [mm]	Standard stroke [mm] Note 1)	Maximum manufacturable stroke [mm]			
20					
25	25 50 75 100 125 150 200 250 200	F00			
32	25, 50, 75, 100, 125, 150, 200, 250, 300	500			
40					

Note 1) Intermediate strokes not listed above are produced upon receipt of order.

Manufacture of intermediate strokes in 1 mm intervals is possible. (Spacers are not used.) Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.

#### **Accessories**

Refer to pages 22 and 23 for accessories, since it is the same as standard type, double acting, single rod.

#### **Mounting and Accessories**

Accessory	Stan	dard		Option	
Mounting	Mounting nut	Rod end nut	Single knuckle joint	Double knuckle joint	Pivot bracket
Basic	● (1 pc.)	● (2 pcs.)	•	•	
Axial foot	● (2 pcs.)	● (2 pcs.)	•	•	_
Flange	• (1 pc.)	● (2 pcs.)	•	•	
Trunnion	• (1 pc.) Note1)	● (2 pcs.)	•	•	•

Note 1) Trunnion nut is attached to the trunnion.

Note 2) A pin and retaining rings (split pins for ø 40) are shipped together with double knuckle joint.

#### Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.

## Series CM2KW

#### Weights

					[kg]
	Bore size [mm]	20	25	32	40
	Basic (Double-side bossed)	0.16	0.25	0.32	0.66
Basic weight	Axial foot	0.31	0.41	0.48	0.93
	Flange	0.22	0.34	0.41	0.78
	Trunnion	0.20	0.32	0.38	0.76
Additional	weight per 50 mm of stroke	0.06	0.1	0.14	0.20
Option	Single knuckle joint	0.06	0.06	0.06	0.23
bracket	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20

#### Calculation: (Example) CM2KWL32-100Z

- Basic weight------0.48 (Foot, ø 32)

  Additional variable
   0.14//50 attacks
- Additional weight-----0.14/50 stroke
  Cylinder stroke-----100 stroke

 $0.48 + 0.14 \times 100/50 =$ **0.76 kg** 

#### Mounting Brackets/Part No.

Mounting brookst	Min.	В	ore siz	ze [mn	n]	Contents
Mounting bracket	order q'ty	20	25	32	40	(for minimum order quantity)
Axial foot *	2	CM-L020B	CM-L032B		CM-L040B	2 foots, 1 mounting nut
Flange	1	CM-F020B	CM-F	032B	CM-F040B	1 flange
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut

<sup>\*</sup> Order 2 foots per cylinder unit.

## **⚠** Precautions

Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

#### Handling

#### ⚠ Warning

#### 1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

#### Do not operate with the cushion needle in a fully closed condition.

Using it in the fully closed state will cause the cushion seal to be damaged. When adjusting the cushion needle, use the "Hexagon wrench key: nominal size 1.5".

#### 3. Do not open the cushion needle wide excessively.

If the cushion needle were set to be completely wide (more than 3 turns from fully closed), it would be equivalent to the cylinder with no cushion, thus making the impacts extremely high. Do not use it in such a way. Besides, using with fully open could give damage to the piston or cover.

#### **⚠** Caution

## 1. Avoid using the air cylinder in such a way that rotational torque would be applied to the piston rod.

If rotational torque is applied, the non-rotating guide will become deformed, thus affecting the non-rotating accuracy. Refer to the table below for the approximate values of the allowable range of rotational torque.

Allowable rotational torque	ø <b>20</b>	ø <b>25</b>	ø <b>32</b>	ø <b>40</b>
(N⋅m or less)	0.2	0.25	0.25	0.44

To screw a bracket or a nut onto the threaded portion at the tip of the piston rod, make sure to retract the piston rod entirely, and place a wrench over the flat portion of the rod that protrudes. Tighten it by giving consideration to prevent the tightening torque from being applied to the non-rotating guide.



#### 2. When replacing rod seals, please contact SMC.

Air leakage may be happened, depending on the position in which a rod seal is fitted. Thus, please contact SMC when replacing them.

#### 3. Not able to disassemble.

Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

#### 4. Do not touch the cylinder during operation.


Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.


- 5. The oil stuck to the cylinder is grease.
- 6. The base oil of grease may seep out.
- When using a rod end bracket, make sure it does not interfere with other brackets, workpieces and rod section, etc.



#### Construction

#### Rubber bumper





#### **Component Parts**

No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2	Cylinder tube	Stainless steel	
3	Piston	Aluminium alloy	
4	Piston rod A	Carbon steel	Hard chrome plating
5	Piston rod B	Stainless steel	
6	Bushing	Bearing alloy	
7	Non-rotating guide	Bearing alloy	
8	Seal retainer A	Stainless steel	
9	Seal retainer B	Carbon steel	Nickel plating
10	Retaining ring	Carbon steel	Phosphate coating
11	Bumper	Resin	
12	Bumper	Resin	
13	Piston seal	NBR	
14	Mounting nut	Carbon steel	Zinc chromated
15	Rod end nut	Carbon steel	Nickel plating
16	Magnet	_	CDM2KW□20 to 40-□Z
17	Rod seal A	NBR	
18	Rod seal B	NBR	

**Rod section** 

#### **Replacement Parts: Seal**

#### With Rubber Bumper/With Air Cushion

	itii iitabboi	Dun	ipoi/witi	All Guolin	<b>V</b> 11							
No.	Description	Motorial	Bore size [mm]									
INO.	Description	ivialeriai	20	25	32	40						
17	Rod seal A	NBR	CM20Z-PS	CM25Z-PS	CM32Z-PS	CM40Z-PS						
18	Rod seal B	NBR	CM2K20-PS	CM2K25-PS	CM2K32-PS	CM2K40-PS						


**Rod section** 

<sup>\*</sup> Since the seal does not include a grease pack, order it separately. Grease pack part number: GR-S-010 (10 g)


## Series CM2KW

#### Basic (Double-side Bossed) (B)


#### CM2WKB Bore size - Stroke Z



#### With air cushion



#### Female rod end



																						[mm]
Bore size	Α	AL	Вı	B <sub>2</sub>	D	E	F	FL	G	Н	H₁	H <sub>2</sub>	I	K	KA	KB	MM	NA	NN	Р	S	ZZ
20	18	15.5	13	26	8	20_0.033	13	10.5	8	41	5	8	28	5	6	8.2	M8 x 1.25	24	M20 x 1.5	1/8	62	144
25	22	19.5	17	32	10	26-0.033	13	10.5	8	45	6	8	33.5	5.5	8	10.2	M10 x 1.25	30	M26 x 1.5	1/8	62	152
32	22	19.5	17	32	12	26_0.033	13	10.5	8	45	6	8	37.5	5.5	10	12.2	M10 x 1.25	34.5	M26 x 1.5	1/8	64	154
40	24	21	22	41	14	32-0.039	16	13.5	11	50	8	10	46.5	7	12	14.2	M14 x 1.5	42.5	M32 x 2	1/4	88	188

With Air Cu	shion [mm]
Bore size	WA
20	13
25	13
32	13
40	16

Female R	Female Rod End [n														
Bore size	ore size A <sub>1</sub> H MM														
20	8	20	M4 x 0.7	102											
25	8	20	M5 x 0.8	102											
32	12	20	M6 x 1	104											
40	13	21	M8 x 1.25	130											

- $\ast$  When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


#### **Dimensions of Each Mounting Bracket**

The dimensions of each mounting bracket other than basic type are the same as standard type, double acting, double rod (except KA dimension). Refer to pages 33 to 35.



Series CN2K ø 20, ø 25, ø 32, ø 40





#### Applicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches

App	ilicable Auto	Switche	es/	Refer to the A	DPIICABLE AUTO SWITCHES/Refer to the Auto Switch Guide for further information on auto switches.  Load voltage  Auto switch model Lead wire length [m] Burning Analysis by													
		Electrical	ator	Wiring		Load volt	age	Auto swit	ch model	Lea	ıd wi	re len	gth [	[m]	Pre-wired	Δnnli	cable	ı
Type	Special function	entry	ndicator light	(Output)	1	DC	AC	Perpendicular	In-line	0.5	1 (M)	3 (L)		None (NI)	connector		ad	٦
			=	3-wire (NPN)				M9NV	M9N	•	(101)	(L)	(2)		0			
		Grommet		3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	<u> </u>	0	IC circuit		
ڃ				2-wire		12 V		M9BV	M9B	•	•	•	0	_	0			
switch		Connector		2-wire		12 V		_	H7C	•	_	•	•	•	_			
		Terminal		3-wire (NPN)		5 V, 12 V		-	G39A	_	_	<u>  — </u>	_	•	_	IC circuit		>
auto		conduit	S	2-wire		12 V			K39A	_	_	_	_	•	_	_	Relay,	ı
e a	Diagnostic indication		Υe	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	•	0	<u>  — </u>	0	IC circuit	PLC	
state	(2-colour indication)			3-wire (PNP)				M9PWV	M9PW	•	•	•	0	_	0			ı
	,			2-wire		12 V		M9BWV	M9BW	•	•	•	0	<u> </u>	0			П
Solid	Water resistant	Grommet		3-wire (NPN)		5 V, 12 V		M9NAV***	M9NA*** M9PA***	0	0	•	0	_	0	IC circuit	1	П
٠,	(2-colour indication)			3-wire (PNP) 2-wire		12 V		M9PAV*** M9BAV***	M9BA***	0	0	•	0	$\vdash$	0			
	With diagnostic output (2-colour indication)			4-wire (NPN)		5 V, 12 V		IVISDAV	H7NF	•			0	H	0	IC circuit		П
	Will diagnosis output (2 colour indication)			3-wire		i i				_			0		0			ı
			Yes	(NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	_	_	_	IC circuit	_	
_		Grommet	-				100 V	A93V	A93	•	_	•	•	_	_	_		
switch		Grommet	No Yes No				100 V or less	A90V	A90	•	_	•		_	_	IC circuit		ιl
Ň			Yes				100 V, 200 V	_	B54	•	_	•	•	_	_		Relay,	ı
			2				200 V or less	_	B64	•	<u> </u>	•	_	<u> </u>	_	_	PLC	ı
an		Connector	No Yes	2-wire	24 V	12 V			C73C	•	_	•	•	•	_			ı
Reed auto			ž				24 V or less		C80C	•	<u> </u>	•	•	•	_	IC circuit		ı
Re		Terminal							A33A	_	_	<u> </u>	_	•	_		PLC	ı
		conduit	,es				100 V,		A34A	_	_	<u>  — </u>	_	•	_	_	Relay,	ı
	Diamontia indication (O colour indication)	DIN terminal	1				200 V		A44A BEOW	_	$\vdash$	_	_	•	_		PLC	1
	Diagnostic indication (2-colour indication)	Grommet							B59W		$_{\rm I}$	•		I —	_			

<sup>\*\*\*</sup> Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance Please contact SMC regarding water resistant types with the above model numbers.

- Lead wire length symbols: 0.5 m ······ (Example) M9NW \*
  - 1 m ······ M (Example) M9NWM
  - 3 m ······ L (Example) M9NWL
  - 5 m ······ Z (Example) M9NWZ None ····· N (Example) H7CN
- $\ast$  Solid state auto switches marked with "O" are produced upon receipt of order.
- \* Do not indicate suffix "N" for no lead wire on the D-A3 A44A/G39A/K39A models.
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details.
- \* For details about auto switches with pre-wired connector, refer to the **Auto Switch Guide.**
- \* The D-A9 \( \Box \) M9 \( \Box \) auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)



Standard
Double Acting, Double Rod
Do

Single Acting, Spring Return/Extend
CM2

e Rod Double Acting, 9

Retunification Double Acting.

uble Acting, Single Rod

Double Acting, Single Roy

CN2RK

M2 CM

With End Lo

Auto Switch

Made to Order

## Series CM2K

A cylinder which rod does not rotate because of the hexagonal rod shape.

### Non-rotating accuracy

ø **20**, ø **25**—±0.7°

ø 32, ø 40—±0.5°

#### Can operate without lubrication.


#### The same installation dimensions as the standard cylinder.

#### Auto switches can also be mounted.


It can be installed with auto switches to simplify the detection of the stroke position of the cylinder.

#### **Symbol**

Single acting, Spring return, Rubber bumper



Single acting, Spring extend, Rubber bumper





#### Made to Order

(For details, refer to pages 101 to 117.)

	· · · · · · · · · · · · · · · · · · ·
Symbol	Specifications
-XA□	Change of rod end shape
-XB12	External stainless steel cylinder*
-XC3	Special port location
-XC6	Made of stainless steel
-XC13	Auto switch rail mounting
-XC20	Head cover axial port
-XC25	No fixed throttle of connection port
-XC27	Double clevis and double knuckle pins made of stainless steel
-XC52	Mounting nut with set screw
-XC85	Grease for food processing equipment

\* The shape is the same as the existing product.

Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- · Auto switch mounting brackets/Part no.

#### **Specifications**

Bore s	ize [mm]	20	25	32	40				
Rod non-rotating acc	curacy	±0	.5°						
Action		Single acting,	Spring return	/Single acting,	Spring extend				
Fluid			А	ir					
Cushion			Rubber	bumper					
Proof pressure	re 1.5 MPa								
Maximum operating	pressure	1.0 MPa							
Minimum operating	Spring return								
pressure	Spring extend	0.23 MPa							
Ambient and fluid te	mperature	Without aut	to switch: –10 to switch: –10	°C to 70 °C °C to 60 °C	(No freezing)				
Lubrication			Not required	d (Non-lube)					
Stroke length tolerar	nce	+1.4 mm							
Piston speed		50 to 500 mm/s							
Allowable	Male thread	0.27 J	0.4 J	0.65 J	1.2 J				
kinetic energy	Female thread	0.11 J	0.18 J	0.29 J	0.52 J				

#### Standard Strokes

Bore size [mm]	Standard stroke [mm] Note)
20	25, 50, 75, 100, 125, 150
25	25, 50, 75, 100, 125, 150
32	25, 50, 75, 100, 125, 150, 200
40	25, 50, 75, 100, 125, 150, 200, 250

Note 1) Other intermediate strokes can be manufactured upon receipt of order. Manufacture of intermediate strokes at 1 mm intervals is possible. (Spacers are not used.)

Note 2) Please contact SMC for longer strokes.

Note 3) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.


#### **Mounting Bracket**

For the mounting bracket part numbers other than basic type, refer to page 64.

#### **Accessories**

Refer to pages 22 and 23 for accessories, since it is the same as standard type, double acting, single rod.

### Option: Ordering Example of Cylinder Assembly



Mounting C: Single clevis Pivot bracket N: Yes Rod end bracket V: Single knuckle joint Auto switch D-M9BW: 2 pcs.

- Pivot bracket, single knuckle joint and auto switch are shipped together with the product, but not assembled.
- \* Pivot bracket is available only for C, T, U, E, V, UZ mounting types.
- \* No bracket is provided for the female rod end.



	Accessories		Stan	idard (m	ounted	to the b	ody)		Sta	andard (	packag	ed toge	ether, b	ut not a	ıssembl	ed)			tion
Мо	unting	Body	Mounting nut	Rod end nut (Male thread)	Single clevis	Double clevis	Note 7)	Mounting nut	Foot	Flange	Pivot bracket	Pivot Note 5) bracket pin	Double Note 5)	Trunnion	Mounting nut (For trunnion)	Clevis pivot bracket (CM2E/CM2V)	Clevis pivot (M085) bracket pin (CM2E/CM2V)	Single knuckle joint (Male thread only)	Note 6) Double knuckle joint (Male thread only)
В	Basic (Double-side bossed)	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
L	Axial foot	●(1 pc.)	(1 pc.) <sup>Note 2)</sup>	●(1 pc.)	_	_	_	(1 pc.) <sup>Note 2)</sup>	●(2 pcs.)	_	_	_	_	_	_	_	_	•	•
F	Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_		_		●(1 pc.)	_	_	_	_	_	_	_	•	•
G	Head flange	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	●(1 pc.)	_	_	_	_	_	_	_	•	•
С	Single clevis	●(1 pc.)	Note 3)	●(1 pc.)	●(1 pc.)	_	●(Max. 3 pcs.)	Note 3)	_	_	_	_	_	_	_	_	_	•	•
D	Double clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	●(1 pc.)	●(Max. 3 pcs.)	Note 3)	_	_	_	_	●(1 pc.)	_	_	_	_	•	•
U	Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Т	Head trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•
Е	Integral clevis	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)	_	_	_	_	_	_	_	_	_	•	•
٧	Integral clevis (90°)	●(1 pc.)	Note 3)	●(1 pc.)	_	_	_	Note 3)		_	_	_	_	_	_	_	_	•	•
BZ	Boss-cut/Basic	●(1 pc.)	●(1 pc.)	●(1 pc.)	_	_	_	_	_	_	_	_	_	_	_	_	_	•	•
FZ	Boss-cut/ Rod flange	●(1 pc.)	●(1 pc.)	●(1 pc.)		_		_	_	●(1 pc.)		_		_		_		•	•
UZ	Boss-cut/ Rod trunnion	●(1 pc.)	Note 4)	●(1 pc.)	_	_	_	_	_	_	_	_	_	●(1 pc.)	●(1 pc.)	_	_	•	•

Note 1) Rod end nut is not provided for the female rod end.

Note 2) Two mounting nuts are packaged together.

Note 3) Mounting nut is not packaged for the clevis.

Note 4) Trunnion nut is packaged for U, T, UZ.

Note 5) Retaining rings are included.

Note 6) A pin and retaining rings (split pins for ø 40) are included.

Note 7) This is the part(s) used to adjust the clevis angle. Mounting quantity can vary.

#### **Mounting Brackets/Part No.**

Mounting brooket	Min.		Bore siz	ze [mm]		Contents (for minimum order assettits)	[-		
Mounting bracket	order q'ty	20	25	32	40	Contents (for minimum order quantity)	Marina		
Foot*	2	CM-L020B	CM-L	CM-L032B		2 foots, 1 mounting nut	3		
Flange	1	CM-F020B	CM-F032B		CM-F040B	1 flange			
Single clevis**	1	CM-C020B	CM-C	CM-C032B		1 single clevis, 3 liners	١١٥		
Double clevis (with pin)***	1	CM-D020B	CM-D032B		CM-D040B	1 double clevis, 3 liners, 1 clevis pin, 2 retaining rings	) [had and does not		
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut			
Rod end nut	1	NT-02	NT-03		NT-03		NT-04	1 rod end nut	
Mounting nut	1	SN-020B	SN-0	SN-032B		1 mounting nut	1		
Trunnion nut	1	TN-020B	TN-0	032B	TN-040B	1 trunnion nut	غ ا		
Single knuckle joint	1	I-020B	I-03	32B	I-040B	1 single knuckle joint			
Double knuckle joint	1	Y-020B	Y-0	32B	Y-040B	1 double knuckle joint, 1 clevis pin, 2 retaining rings	i i		
Clevis pin (Double clevis)	1		CDP-1		CDP-2	1 clevis pin, 2 retaining rings (split pins)	†		
Clevis pin (Double knuckle joint)	1		CDP-1		CDP-3	1 clevis pin, 2 retaining rings (split pins)	≻		
Pivot bracket pin	1		CDP-1		CD-S03	1 pin, 2 retaining rings	†		
Clevis pivot bracket pin (For CM2E/CM2V)	1	CD-			D-S03	1 clevis pin, 2 retaining rings	- 7 - 1		
Clevis pivot bracket (For CM2E/CM2V)	1	CM-E	CM-E020B CM-E		-E032B	1 clevis pivot bracket, 1 clevis pin, 2 retaining rings			
Pivot bracket (For CM2C)	1		CM-B032		CM-B040	2 pivot brackets (1 of each type)	14641		
Pivot bracket (For CM2T)	1	CM-B020	-B020 CM-B032			2 pivot brackets (1 of each type)			

<sup>\*</sup> Order 2 foots per cylinder.

ole Acting, Single Ro

CM2W

Spring Return/Extend Doubl

Acting, Single Rod Sing

Double Acting, Double Rod

Single Acting, Spring Returnless

CM2K

Double Acting, Single

gle Rod Double Acting,

Double Acting, S



 $<sup>\</sup>ast\ast$  3 liners are included with a clevis bracket for adjusting the mounting angle.

<sup>\*\*\*</sup> A clevis pin and retaining rings (split pins for ø 40) are included.

#### Weights

Spring	g Return/( ): Denotes	Spring Ex	ktend.		[kg]
	Bore size [mm]	20	25	32	40
	25 stroke	0.20 (0.19)	0.31 (0.30)	0.43 (0.41)	0.78 (0.75)
	50 stroke	0.23 (0.21)	0.34 (0.33)	0.48 (0.45)	0.86 (0.83)
	75 stroke	0.29 (0.25)	0.43 (0.41)	0.61 (0.56)	1.08 (0.99)
Basic	100 stroke	0.31 (0.27)	0.47 (0.44)	0.66 (0.60)	1.14 (1.06)
weight	125 stroke	0.37 (0.32)	0.56 (0.52)	0.81 (0.72)	1.34 (1.23)
	150 stroke	0.39 (0.34)	0.59 (0.55)	0.85 (0.76)	1.39 (1.31)
	200 stroke	- (-)	- (-)	1.04 (0.92)	1.71 (1.54)
	250 stroke	- (-)	- (-)	- (-)	2.00 (1.78)
	Foot	0.15 (0.15)	0.16 (0.16)	0.16 (0.16)	0.27 (0.27)
	Flange	0.06 (0.06)	0.09 (0.09)	0.09 (0.09)	0.12 (0.12)
	Single clevis	0.04 (0.04)	0.04 (0.04)	0.04 (0.04)	0.09 (0.09)
Marintina	Double clevis	0.05 (0.05)	0.06 (0.06)	0.06 (0.06)	0.13 (0.13)
Mounting brackets	Trunnion	0.04 (0.04)	0.07 (0.07)	0.07 (0.07)	0.10 (0.10)
DIACKEIS	Integral clevis	-0.02 (-0.02)	-0.02 (-0.02)	-0.01 (-0.01)	-0.04 (-0.04)
	Boss-cut/Basic	-0.01 (-0.01)	-0.02 (-0.02)	-0.02 (-0.02)	-0.03 (-0.03)
	Boss-cut/Flange	0.05 (0.05)	0.07 (0.07)	0.07 (0.07)	0.09 (0.09)
	Boss-cut/Trunnion	0.03 (0.03)	0.05 (0.05)	0.05 (0.05)	0.07 (0.07)
0 "	Clevis pivot bracket (with pin)	0.07 (0.07)	0.07 (0.07)	0.14 (0.14)	0.14 (0.14)
Option bracket	Single knuckle joint	0.06 (0.06)	0.06 (0.06)	0.06 (0.06)	0.23 (0.23)
Didoket	Double knuckle joint (with pin)	0.07 (0.07)	0.07 (0.07)	0.07 (0.07)	0.20 (0.20)

Calculation

(Example) CM2KL32-100SZ (Bore size ø 32, Foot, 100 stroke)

0.66 (Basic weight) + 0.16 (Mounting bracket weight) = 0.82 kg

### **⚠** Precautions

Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

#### Handling

#### 

1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

#### 

1. Avoid using the air cylinder in such a way that rotational torque would be applied to the piston rod.


If rotational torque is applied, the non-rotating guide will become deformed, thus affecting the non-rotating accuracy.

Refer to the table below for the approximate values of the allowable range of rotational torque.

Allowable rotational torque	ø <b>20</b>	ø <b>25</b>	ø <b>32</b>	ø <b>40</b>
(N⋅m or less)	0.2	0.25	0.25	0.44

To screw a bracket or a nut onto the threaded portion at the tip of the piston rod, make sure to retract the piston rod entirely, and place a wrench over the flat portion of the rod that protrudes.

Tighten it by giving consideration to prevent the tightening torque from being applied to the non-rotating guide.



#### 

2. When replacing rod seals, please contact SMC.

Air leakage may be happened, depending on the position in which a rod seal is fitted. Thus, please contact SMC when replacing them.

3. Not able to disassemble.


Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.


4. Do not touch the cylinder during operation.

Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

- 5. The oil stuck to the cylinder is grease.
- 6. The base oil of grease may seep out.
- When using a rod end bracket and/or pivot bracket, make sure they do not interfere with other brackets, workpieces and rod section, etc.







**Component Parts** 

No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2A	Head cover A	Aluminium alloy	Anodised
2B	Head cover B	Aluminium alloy	Anodised
2C	Head cover C	Aluminium alloy	Anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	
5	Piston rod	Stainless steel	
6	Non-rotating guide	Bearing alloy	
7	Seal retainer	Carbon steel	Nickel plating
8	Return spring	Steel wire	Zinc chromated
9	Spring guide	Aluminium alloy	Chromated
10	Spring seat	Aluminium alloy	Chromated
11	Plug with fixed orifice	Alloy steel	Black zinc chromated
12	Bumper	Resin	
13	Bumper A	Resin	
14	Bumper B	Resin	

No.	Description	Material	Note
15	Retaining ring	Stainless steel	
16	Rod seal	NBR	
17	Piston seal	NBR	
18	Wear ring	Resin	
19	Clevis bushing	Bearing alloy	
20	Mounting nut	Carbon steel	Nickel plating
21	Rod end nut	Carbon steel	Zinc chromated
22	Magnet	_	CDM2K□20 to 40-□S/TZ

#### **Replacement Part: Seal**

Ī	No. D	Description	Motorial		Part no.								
No. D	Description	Material	20	25	32	40							
	16	Rod seal	NBR	CM2K20-PS	CM2K25-PS	CM2K32-PS	CM2K40-PS						


Since the seal does not include a grease pack, order it separately.
 Grease pack part number: GR-S-010 (10 g)




## Series CM2K

#### Basic (Double-side Bossed) (B)






#### **Spring extend**




#### **Boss-cut**




**ZZ** + Stroke

#### Female rod end



#### Spring extend Female thread MM



															[mm]		
Bore size	ore size A AL B1 B2 E		Ε	F	FL	G	Н	H <sub>1</sub>	H <sub>2</sub>	I	KB	MM	NA	NN	Р		
20	18	15.5	13	26	20-0.033	13	10.5	8	41	5	8	28	8.2	M8 x 1.25	24	M20 x 1.5	1/8
25	22	19.5	17	32	26-0.033	13	10.5	8	45	6	8	33.5	10.2	M10 x 1.25	30	M26 x 1.5	1/8
32	22	19.5	17	32	26-0.033	13	10.5	8	45	6	8	37.5	12.2	M10 x 1.25	34.5	M26 x 1.5	1/8
40	24	21	22	41	32-0.039	16	13.5	11	50	8	10	46.5	14.2	M14 x 1.5	42.5	M32 x 2	1/4

Dimension	Dimensions by Stroke [mm												
Stroke	1 10	50	51 to 100		101 to 150		151 to 200		201 to 250				
Symbol Bore size	S	ZZ	S	ZZ	S	ZZ	S	ZZ	S	ZZ			
20	87	141	112	166	137	191	_	_	_	_			
25	87	145	112	170	137	195	_	_	_	_			
32	89	147	114	172	139	197	164	222	_	_			
40	113	179	138	204	163	229	188	254	213	279			

Boss-cut [mm											
Stroke	1 to 50	51 to 100	101 to 150	151 to 200	201 to 250						
Symbol Bore size	ZZ	ZZ	ZZ	ZZ	ZZ						
20	128	153	178	-	_						
25	132	157	182	_	_						
32	134	159	184	209	_						
40	163	188	213	238	263						


ŀ	-emale R	od E	nd											[mm]	
Stroke Symbol		Α.	-	8484	1 to	50	51 to	100	101 t	o 150	151 t	o 200	201 t	o 250	
В	ore size	<b>A</b> 1	Н	MM	S	ZZ	S	ZZ	S	ZZ	S	ZZ	S	ZZ	
	20	8	20	M4 x 0.7	87	120	112	145	137	170	_	_	-	_	
	25	8	20	M5 x 0.8	87	120	112	145	137	170	_	_	_	_	:
	32	12	20	M6 x 1	89	122	114	147	139	172	164	197	-	_	
Ī	40	13	21	M8 x 1.25	113	150	138	175	163	200	188	225	213	250	

- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

Series CM2R

RoHS

ø 20, ø 25, ø 32, ø 40



#### Applicable Auto Switches/Defer to the

App	Cable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.    Comparison																		
Type	Special function	Electrical	dicator	Wiring		Load vol	tage	Auto swit	ch model		id wii		<u> </u>		Pre-wired	Appli	cable	ةً	
туре	Special function	entry	Indic	(Output)	1	DC	AC	Perpendicular	In-line	0.5	1 (M)	3 (L)	5 (Z)	None (N)	connector	lo	ad	Centralised Piping   Direct Mount, Non-rotating Rod	
				3-wire (NPN)		5 V, 12 V		M9NV	M9N	•	•	•	0	_	0	IC circuit		otating	
		Grommet		3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	_	0	10 dilouit		Š	
ch		0	-	2-wire		12 V		M9BV	M9B	•	•	•	0	_	0	l _		Mount	
switch		Connector	-	3-wire (NPN)		5 V, 12 V			H7C G39A**	•	┢═	•	•	-		IC circuit		Direct	
auto s		Terminal conduit		2-wire		12 V	1		K39A**		Ε	Ξ	E	•		—		[2	
an			Yes		24 V		l _	M9NWV	M9NW	•	•	•	0	_	0	10 -11	Relay, PLC	niaic	
state	Diagnostic indication (2-colour indication)			3-wire (PNP)		5 V, 12 V		M9PWV	M9PW	•		•	0	_	0	IC circuit	PLC	Ped	
S	(2-colour indication)			2-wire		12 V	5 V 12 V	5 V 12 V	M9BWV	M9BW	•		•	0	_	0	_		1 1 2
Solid	Water resistant	Grommet		3-wire (NPN)		5 V. 12 V			12 V	M9NAV***	M9NA***	0	0	•	0	_	0	IC circuit	
0)	(2-colour			3-wire (PNP)			M9PAV***	M9PA***	0	0	•	0	_	0	<del>                                     </del>				
	indication) With diagnostic output (2-colour indication)			2-wire 4-wire (NPN)		12 V 5 V, 12 V	-	M9BAV***	M9BA*** H7NF		0	•	0	_	0	IC aireuit		2	
	iviin diagnosiic odiput (z-colour indication)					5 V, IZ V			п/иг	•	F		0	_	0	IC circuit			
			Yes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	_	•	-	_	_	IC circuit	_	With End Lock	
_		Grommet	1				100 V	A93V	A93	•	_	•	•	_	_	_		l lit	
auto switch		Grommet	2				100 V or less	A90V	A90	•	_	•	_	_	_	IC circuit		>	
Ň			Yes				100 V, 200 V	_	B54**		<u> </u> —			—	_		Relay,		
9			2				200 V or less	_	B64**	•	_		_	_	_	—	PLC		
an		Connector	No Yes	2-wire	24 V	12 V		_	C73C	•	<u>  —</u>	•	•	•	_				
Reed			ž				24 V or less	_	C80C	•	<u> </u>	•	•	•	_	IC circuit			
8		Terminal						_	A33A**	_	_	_	_	•	_		PLC	1	
		conduit	es				100 V,		A34A**	_	-	$\vdash$	$\vdash$	•		-	Relay,	1	
	Discounting to the first of the state of the	DIN terminal	~				200 V		A44A**	_	$\vdash$	_	_				PLC	1	
	Diagnostic indication (2-colour indication)	Grommet		I				_	B59W		I - I		_	<u> </u>	_			ĺ	

- \*\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance Please contact SMC regarding water resistant types with the above model numbers.
- (Example) M9NW \* Lead wire length symbols: 0.5 m
  - 1 m ..... M (Example) M9NWM
  - (Example) M9NWL 3 m ..... L
  - (Example) M9NWZ
  - None ······ N (Example) H7CN
- Solid state auto switches marked with "O" are produced upon receipt of order.
- \* Do not indicate suffix "N" for no lead wire on the D-A3 A44A/G39A/K39A models \*\* D-A3 A/A44A/G39A/K39A/B54/B64 cannot be mounted on bore sizes ø 20 and ø 25
  - cylinder with air cushion.
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 UM9 UM auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)



Switch

Auto

to Order

#### The CM2R direct mount cylinder can be installed directly through the use of a square rod cover.


Space saving has been realized. Because it is a directly mounted style without using brackets, its overall length is shorter, and its installation pitch can be made smaller. Thus, the space that is required for installation has been dramatically reduced.

Improved installation


accuracy and strength
A centering boss has been provided to improve the installation accuracy. Also, because it is the directly mounted style, the strength has been increased.

Two styles of installation

Two styles of installations are available and can be selected according to the purpose: the front mounting style or the bottom mounting style.



#### **Symbol**





#### Made to Order

(For details, refer to pages 101 to 117.)

Symbol	Specifications
-XA□	Change of rod end shape
-XB6	Heat resistant cylinder (-10 to 150 °C)
-XB7	Cold resistant cylinder (-40 to 70 °C)*1
-XB9	Low speed cylinder (10 to 50 mm/s)*1
-XB13	Low speed cylinder (5 to 50 mm/s)*2
-XC3	Special port location
-XC5	Heat resistant cylinder (-10 to 110 °C)
-XC6	Made of stainless steel
-XC8	Adjustable stroke cylinder/Adjustable extension type*1
-XC9	Adjustable stroke cylinder/Adjustable retraction type*1
-XC11	Dual stroke cylinder/Single rod type*1
-XC13	Auto switch rail mounting
-XC20	Head cover axial port*1
-XC22	Fluororubber seal
-XC25	No fixed throttle of connection port*1
-XC29	Double knuckle joint with spring pin
-XC85	Grease for food processing equipment
-X446	PTFE grease
4.0.11	. 1

<sup>\*1</sup> Rubber bumper only.

#### Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- · Minimum stroke for auto switch mounting
- Operating range
- · Auto switch mounting brackets/Part no.

#### **Specifications**

Bore size [mm]			20	25	32	40		
Action			Double acting, Single rod					
Fluid			Air					
Proof pres	ssure		1.5 MPa					
Maximum operating pressure			1.0 MPa					
Minimum operating pressure				0.05	MPa			
Ambient and fluid temperature			Without auto switch: -10 °C to 70 °C (No freezing) With auto switch: -10 °C to 60 °C					
Lubrication			Not required (Non-lube)					
Stroke length tolerance			+1.4 0 mm					
Piston speed			Rubber bumper: 50 to 750 mm/s, Air cushion: 50 to 1000 mm/s					
Cushion				Rubber bumpe	er, Air cushion			
	Rubber	Male thread	0.27 J	0.4 J	0.65 J	1.2 J		
Allowable	bumper	Female thread	0.11 J	0.18 J	0.29 J	0.52 J		
kinetic energy	Air cushion (Effective cushion	Male thread	0.54 J (11.0)	0.78 J (11.0)	1.27 J (11.0)	2.35 J (11.8)		
	length [mm])	Female thread	0.11 J	0.18 J	0.29 J	0.52 J		

#### Standard Strokes

Bore size [mm]	Standard stroke [mm] Note 1)	Max. manufacturable stroke [mm]
20	25, 50, 75, 100, 125, 150	
25	25, 50, 75, 100, 125, 150, 200	1000
32	25, 50, 75, 100, 125, 150, 200	1000
40	25, 50, 75, 100, 125, 150, 200, 250, 300	

Note 1) Other intermediate strokes can be manufactured upon receipt of order. Manufacture of intermediate strokes at 1 mm intervals is possible. (Spacers are not used.)


Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.

Note 3) Refer to the next page for Precautions.

Tightening Torque: Tighten the cylinder mounting bolts for the bottom mounting style (Series CM2RA) with the following tightening torque.

Bore size [mm]	Hexagon socket head cap screw size	Tightening torque (N⋅m)
20	M5 x 0.8	2.4 to 3.6
25	M6	4.2 to 6.2
32	M8	10.0 to 15.0
40	M10	19.6 to 29.4

#### Option: Ordering Example of Cylinder Assembly



Mounting A: Bottom mounting style Rod end bracket V: Single knuckle joint Auto switch D-M9BW: 2 pcs.

- Single knuckle joint and auto switch are shipped together with the product, but not assembled.
- \* No bracket is provided for the female rod end.



<sup>\*2</sup> The shape is the same as the existing product

Lock

Accessories	Standard	Ор	tion
Mounting	Rod end nut	Single knuckle joint	Double knuckle joint (with pin) *
Bottom mounting style	•	•	•
Front mounting style	•	•	•

<sup>\*</sup> A knuckle pin and retaining rings (split pin for ø 40) are shipped together.

#### Weights

					[ky]
Bore size [mm]		20	25	32	40
Basic weight	Bottom mounting style	0.14	0.23	0.32	0.62
basic weight	Front mounting style	0.14	0.22	0.32	0.61
Additional weight per 50 mm of stroke		0.04	0.06	0.08	0.13

Calculation:

#### (Example) CM2RA32-100Z

(ø 32, 100 stroke, Bottom mounting)

- Basic weight-----0.32 kg
- Additional weight-----0.08 kg
- Cylinder stroke-----100 stroke
  - $0.32 + 0.08 \times 100/50 = 0.48 \text{ kg}$

## **⚠** Precautions

Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

#### Handling

#### **⚠** Warning

1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

2. Do not operate with the cushion needle in a fully closed condition.

Using it in the fully closed state will cause the cushion seal to be damaged. When adjusting the cushion needle, use the "Hexagon wrench key: nominal size 1.5".

3. Do not open the cushion needle wide excessively.

If the cushion needle were set to be completely wide (more than 3 turns from fully closed), it would be equivalent to the cylinder with no cushion, thus making the impacts extremely high. Do not use it in such a way. Besides, using with fully open could give damage to the piston or cover.

4. In the case of exceeding the standard stroke length, implement an intermediate support.

When using cylinder with longer stroke, implement an intermediate support for preventing the joint of rod cover and cylinder tube from being broken by vibration or external load.

- Operate the cylinder within the specified cylinder speed, kinetic energy and lateral load at the rod end.
- The allowable kinetic energy is different between the cylinders with male rod end and with female rod end due to the different thread sizes.
- 7. When female rod end is used, use a washer, etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.
- 8. Do not apply excessive lateral load to the piston rod.

Easy checking method

Minimum operating pressure after the cylinder is mounted to the equipment [MPa] = Minimum operating pressure of cylinder [MPa] + {Load weight [kg] x Friction coefficient of guide/Sectional area of cylinder (mm²)}

If smooth operation is confirmed within the above value, the load on the cylinder is the resistance of the thrust only and it can be judged as having no lateral load.

#### **⚠** Caution

1. Not able to disassemble.

Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

2. Use caution to the popping of a retaining ring.

When replacing rod seals and removing and mounting a retaining ring, use a proper tool (retaining ring plier: tool for installing a type C retaining ring). Even if a proper tool is used, it is likely to inflict damage to a human body or peripheral equipment, as a retaining ring may be flown out of the tip of a plier. Be much careful with the popping of a retaining ring. Besides, be certain that a retaining ring is placed firmly into the groove of rod cover before supplying air at the time of installment.

3. Do not touch the cylinder during operation.

Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

4. Do not use the air cylinder as an air-hydro cylinder.

If it uses turbine oil in place of fluids for cylinder, it may result in oil

- 5. The oil stuck to the cylinder is grease.
- 6. The base oil of grease may seep out.
- 7. When using a rod end bracket, make sure it does not interfere with other brackets, workpieces and rod section, etc.

## Series CM2R

#### **Clean Series**



The type which is applicable for using inside the clean room graded Class 100 by making an actuator's rod section a double seal construction and discharging by relief port directly to the outside of clean room.




#### **Specifications**

Action	Double acting, Single rod
Bore size [mm]	ø 20, ø 25, ø 32, ø 40
Max. operating pressure	1.0 MPa
Min. operating pressure	0.05 MPa
Cushion	Rubber bumper (Standard equipment)
Relief port size	M5 x 0.8
Piston speed	30 to 400 mm/s
Mounting	Bottom mounting style, Front mounting style


<sup>\*</sup> Auto switch can be mounted.

#### Construction



	[mm]
Bore size [mm]	GC
20	6
25	6
32	7
40	$\overline{}$

#### Front mounting style





M5 x 0.8	
Relief port _	₄GC

#### Air-hydro



A low hydraulic pressure cylinder used at a pressures of 1.0 MPa or below.

Through the concurrent use of the CC series air-hydro unit, it is possible to operate at a constant or low speeds or to effect an intermediate stop, just like a hydraulic unit, while using pneumatic equipment such as a valve.




- For construction, refer to page 72.
- Since the dimensions of mounting style are the same as pages 73 and 74, refer to those pages.


#### **Specifications**

uid ction	С	Turbine oil		
etion	С	Navilal a satissas Obsasila sa al		
LIOII		ouble acting, Single rod		
ore size [mm]		ø 20, ø 25, ø 32, ø 40		
oof pressure		1.5 MPa		
ax. operating pressure		1.0 MPa		
in. operating pressure	0.18 MPa			
ston speed	15 to 300 mm/s			
ushion	Rubber bumper			
nbient and fluid temperature	+5 to +60 °C			
roke length tolerance	<sup>+1,4</sup> mm			
ounting	Bottom mounting style, Front mounting style			
ade to Order**	-XC3 Special port location			


- \* Auto switch can be mounted. Dimensions are the same as the standard type.
- \*\* For details, refer to pages 101 to 117.




## Air-hydro



## With air cushion





Comp	onent Parts		
No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2	Head cover	Aluminium alloy	Anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	
5	Piston rod	Carbon steel	Hard chrome plating
6	Bushing	Bearing alloy	
7	Seal retainer	Stainless steel	
8	Retaining ring	Carbon steel	Phosphate coating
9	Bumper	Resin	ø 25 or larger is
10	Bumper	Resin	common.
11	Piston seal	NBR	
12	Wear ring	Resin	
13	Rod end nut	Carbon steel	Zinc chromated
14	Magnet	_	CDM2R□20 to 40-□Z
15	Rod seal	NBR	

For auto switch proper mounting position (at stroke end), refer to pages 96 and 98, since the operating range is the same as standard type, single rod.

## **Replacement Part: Seal**

110	naocinicii	t i ui	t. Ocui									
• W	● With Rubber Bumper/With Air Cushion											
No.	Description	Matarial		Part	no.							
NO.	Description	ivialeriai	20	25	32	40						
15	Rod seal	NBR	CM20Z-PS	CM25Z-PS	CM32Z-PS	CM40Z-PS						
<u> </u>	a to a trans											

ΑI	r-h	yd	ro

No	Description	Motorial		Part	no.	
INO.	Description	ivialeriai	20	25	32	40
15	Rod seal	NBR	CM2H20-PS	CM2H25-PS	CM2H32-PS	CM2H40-PS

<sup>\*</sup> Since the seal does not include a grease pack, order it separately. Grease pack part number: GR-S-010 (10 g)

With End Lock

**Auto Switch** 


Made to Order



## Series CM2R

## **Bottom Mounting Style**


## CM2RA Bore size - Stroke Z



## With air cushion



## Female rod end



r							1
ı	r	ľ	٦	r	T	٦	ı
L							J


Bore size	Stroke range	Α	AL	В	B <sub>1</sub>	D	GA	GB	Н	H₁	Т	K	KA	L	LD	LH	LX	MM	N	ND	Р	S	X	Υ	ZZ
20	1 to 150	18	15.5	30.3	13	8	22	8	27	5	28	5	6	33.5	ø 5.5, ø 9.5 counterbore depth 6.5	15	21	M8 x 1.25	24	20_0.033	1/8	76	39	12	103
25	1 to 200	22	19.5	36.3	17	10	22	8	31	6	33.5	5.5	8	39	ø 6.6, ø 11 counterbore depth 7.5	18	25	M10 x 1.25	30	26_0.033	1/8	76	43	12	107
32	1 to 200	22	19.5	42.3	17	12	22	8	31	6	37.5	5.5	10	47	ø 9, ø 14 counterbore depth 10	21	30	M10 x 1.25	34.5	26_0.033	1/8	78	43	12	109
40	1 to 300	24	21	52.3	22	14	27	11	34	8	46.5	7	12	58.5	ø 11, ø 17.5 counterbore depth 12.5	26	38	M14 x 1.5	42.5	32_0.039	1/4	104	49	15	138


With Air Cushion [mn										
Bore size	WA	WB	W							
20	27	13	8.5							
25	27	13	10.5							
32	27	13	11.5							
40	32	16	15							


Female R	od E	nd			[mm]
Bore size	<b>A</b> 1	Н	KA	MM	ZZ
20	8	10	6	M4 x 0.7	86
25	8	10	8	M5 x 0.8	86
32	12	10	10	M6 x 1	88
40	13	10	12	M8 x 1.25	114

- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.










## With air cushion



## Female rod end



																					[mm]
Bore size	Stroke range	Α	AL	Вı	D	F	FF	FX	GA	GB	Н	H₁	I	K	KA	MM	N	ND	Р	S	ZZ
20	1 to 150	18	15.5	13	8	30.4	M5 x 0.8 depth 9	22	22	8	27	5	28	5	6	M8 x 1.25	24	20_0.033	1/8	76	103
25	1 to 200	22	19.5	17	10	36.4	M6 x 1 depth 11	26	22	8	31	6	33.5	5.5	8	M10 x 1.25	30	26_0.033	1/8	76	107
32	1 to 200	22	19.5	17	12	42.4	M6 x 1 depth 11	30	22	8	31	6	37.5	5.5	10	M10 x 1.25	34.5	26_0.033	1/8	78	109
40	1 to 300	24	21	22	14	52.4	M8 x 1.25 depth 14	36	27	11	34	8	46.5	7	12	M14 x 1.5	42.5	32-0.039	1/4	104	138

With Air Cushion [mm]											
Bore size	Bore size WA WB										
20	27	13	8.5								
25	27	13	10.5								
32	27	13	11.5								
40	32	16	15								

Female R	Female Rod End [mm]												
Bore size	<b>A</b> 1	Н	KA	MM	ZZ								
20	8	10	6	M4 x 0.7	86								
25	8	10	8	M5 x 0.8	86								
32	12	10	10	M6 x 1	88								
40	13	10	12	M8 x 1.25	114								


- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.

## Air Cylinder: Direct Mount, Non-rotating Rod Type **Double Acting, Single Rod**

## Series CM2RK



ø 20, ø 25, ø 32, ø 40



#### Applicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.

		Ele etnice I	tor	\A/:!		Load volt	age	Auto swite	oh modol	Lea	d wii	e len	igth [	m]	Pre-wired	Appli	cable												
Туре	Special function	Electrical entry	Indicator light	Wiring (Output)	ı	DC	AC	Perpendicular Perpendicular	In-line	0.5 (—)	1 (M)	3 (L)	5 (Z)	None (N)	connector		ad												
				3-wire (NPN)		5 V. 12 V		M9NV	M9N	•	•	•	0	_	0	IC circuit													
		Grommet		3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	_	0	IC circuit													
Ę.				2-wire		12 V		M9BV	M9B	•	•	•	0	_	0														
switch		Connector		Z-WIIE				_	H7C	•	_	•	•	•	_														
S		Terminal		3-wire (NPN)		5 V, 12 V		_	G39A	_	_	_	_	•	_	IC circuit													
auto		conduit	S	2-wire		12 V		_	K39A	_		_	_	•	_	_	Relay,												
a a	Diagnostic indication (2-colour indication)		Yes	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	•	0	_	0	IC circuit	PLC												
state		Grommet	Grommet	Grommet									3-wire (PNP)				M9PW	•	•	•	0	_	0	- TO OHOUR					
ο	,								2-wire	12	12 V	4	M9BWV	M9BW	•	•	•	0	_	0									
Solid	Water resistant (2-colour					3-wire (NPN)		5 V, 12 V		M9NAV**	M9NA**	0	0	•	0	_	0	IC circuit											
0)																				3-wire (PNP)				M9PAV**	M9PA**	0	0	•	0
	indication)			2-wire		12 V 5 V, 12 V		M9BAV**	M9BA**	0	0	•	0	_	0	<u> </u>	ļ												
	With diagnostic output (2-colour indication)			4-wire (NPN)		5 V, 12 V		_	H7NF	•	_	•	0	_	0	IC circuit													
							Yes	3-wire (NPN equivalent)	_	5 V	-	A96V	A96	•	_	•	_	_	_	IC circuit	_								
_		Grommet					100 V	A93V	A93	•	_	•	•	_	_	_													
호		aronninet	2				100 V or less	A90V	A90	•	_	•	_	_	_	IC circuit													
switch			No Yes No Yes No				100 V, 200 V	_	B54	•	_	•	•	_	_		Relay,												
ģ			2				200 V or less	_	B64	•	_	•	_	—	_	_	PLC												
auto		Connector	Yes	2-wire	24 V	12 V	_	_	C73C	•		•	•	•	_														
Reed			욷	2			24 V or less	_	C80C	•	_	•	•	•	_	IC circuit													
Be		Terminal							A33A	_		_	_	•	_		PLC												
		conduit	es				100 V,		A34A			_	_	•	_	_	Relay,												
		DIN terminal	>				200 V		A44A			_	_	•	_		PLC												
	Diagnostic indication (2-colour indication)	Grommet				_	_	_	B59W	•			I -	<u> </u>	_														

- \*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers.
- (Example) M9NW \* Lead wire length symbols: 0.5 m .... 1 m ..... M (Example) M9NWM
  - (Example) M9NWL 3 m ..... L
  - (Example) M9NWZ None ······ N (Example) H7CN
- Solid state auto switches marked with "O" are produced upon receipt of order
- \* Do not indicate suffix "N" for no lead wire on D-A3□A/A44A/G39A/K39A models
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 UM 9 UM auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)

The CM2RK direct mount cylinder can be installed directly through the use of a square rod cover.

Non-rotating accuracy

A cylinder which the rod does not rotate because of its hexagonal shape.


**Space-saving has been realised.**Because it is a directly mounted style without using brackets, its overall length is shorter, and its installation pitch can be made smaller. Thus, the space that is required for installation has been dramatically reduced.

Improved installation accuracy and strength

A centering boss has been provided to improve the installation accuracy. Also, because it is the directly mounted style, the strength has been increased.

Two styles of installation

Two styles of installations are available and can be selected according to the purpose: the front mounting style or the bottom mounting style.




Bottom mounting style

Front mounting style

#### **Symbol**

Rubber bumper





## **Made to Order**

(For details, refer to pages 101 to 117.)

Symbol	Specifications
-XA□	Change of rod end shape
-XB6	Heat resistant cylinder (-10 to 150 °C)
-XC3	Special port location
-XC6	Made of stainless steel
-XC8	Adjustable stroke cylinder/Adjustable extension type
-XC9	Adjustable stroke cylinder/Adjustable retraction type
-XC11	Dual stroke cylinder/Single rod type
-XC13	Auto switch rail mounting
-XC20	Head cover axial port
-XC22	Fluororubber seal
-XC25	No fixed throttle of connection port
-XC85	Grease for food processing equipment
-X446	PTFE grease

## **Specifications**

Bore size [r	nm]	20	25	32	40			
Rod non-rotating a	ccuracy	± 0.7° ± 0.5°						
Action		Double acting, Single rod						
Fluid			А	ir				
Proof pressure			1.5	MPa				
Maximum operating	g pressure		1.0	MPa				
Minimum operating	pressure	0.05 MPa						
Ambient and fluid t	emperature	Without auto switch: -10 °C to 70 °C (No freezing)  With auto switch: -10 °C to 60 °C						
Lubrication		Not required (Non-lube)						
Stroke length toler	ance	+1.4 0 mm						
Piston speed		50 to 500 mm/s						
Cushion		Rubber bumper						
Allowable kinetic	Male thread	0.27 J	0.4 J	0.65 J	1.2 J			
energy	Female thread	0.11 J	0.18 J	0.29 J	0.52 J			

## Standard Strokes

Bore size [mm]	20         25, 50, 75, 100, 125, 150           25         25, 50, 75, 100, 125, 150, 200           32         25, 50, 75, 100, 125, 150, 200           40         25, 50, 75, 100, 125, 150, 200, 250, 300	Max. manufacturable stroke [mm]			
20					
25		1000			
32	25, 50, 75, 100, 125, 150, 200	1000			
40	25, 50, 75, 100, 125, 150 25, 25, 50, 75, 100, 125, 150, 200 32, 50, 75, 100, 125, 150, 200				

Note 1) Other intermediate strokes can be manufactured upon receipt of order. Manufacture of intermediate strokes at 1 mm intervals is possible. (Spacers are not used.)


Note 2) Applicable strokes should be confirmed according to the usage. For details, refer to "Air Cylinders Model Selection". In addition, the products that exceed the standard stroke might not be able to fulfill the specifications due to the deflection etc.

Tightening Torque: Tighten the cylinder mounting bolts for the bottom mounting style (Series CM2RKA) with the following tightening torque.

Bore size [mm]	Hexagon socket head cap bolt size	Tightening torque (N·m)
20	M5 x 0.8	2.4 to 3.6
25	M6	4.2 to 6.2
32	M8	10.0 to 15.0
40	M10	19.6 to 29.4

## Option: Ordering Example of Cylinder Assembly

### Cylinder model: CDM2RKA20-100Z-V-M9BW



Mounting A: Bottom mounting style Rod end bracket V: Single knuckle joint Auto switch D-M9BW: 2 pcs

- Single knuckle joint and auto switch are shipped together with the product, but not assembled
- \* No bracket is provided for the female rod end.


Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.



## Series CM2RK

## Construction



#### **Component Parts**

<u> </u>	Jones Lanco		
No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Anodised
2	Head cover	Aluminium alloy	Anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	
5	Piston rod	Stainless steel	
6	Non-rotating guide	Bearing alloy	
7	Seal retainer	Carbon steel	Nickel plating
8	Retaining ring	Carbon steel	Phosphate coating
9	Bumper	Resin	
10	Bumper	Resin	
11	Retaining ring	Stainless steel	
12	Piston seal	NBR	

No.	Description	Note	
13	Wear ring	Resin	
14	Rod end nut	Carbon steel	Zinc chromated
15	Magnet	_	CDM2RK□20 to 40-□Z
16	Rod seal	NBR	

#### **Replacement Part: Seal**

No.	Description	Motorial	Part no.							
	Description	Ivialeriai	20	25	32	40				
16	Rod seal	NBR	CM2K20-PS	CM2K25-PS	CM2K32-PS	CM2K40-PS				

Since the seal does not include a grease pack, order it separately.
 Grease pack part number: GR-S-010 (10 g)

## **↑** Precautions

- Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch | Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website,
- http://www.smc.eu

## Handling/Disassembly

## 

1. Do not rotate the cover.

If a cover is rotated when installing a cylinder or screwing a fitting into the port, it is likely to damage the junction part with cover.

2. In the case of exceeding the standard stroke length, implement an intermediate support.

When using cylinder with longer stroke, implement an intermediate support for preventing the joint of rod cover and cylinder tube from being broken by vibration or external load.

## 

 Avoid using the air cylinder in such a way that rotational torque would be applied to the piston rod.

If rotational torque is applied, the non-rotating guide will become deformed, thus affecting the non-rotating accuracy.

Refer to the table below for the approximate values of the allowable range of rotational torque.

Allowable rotational torque	ø <b>20</b>	ø <b>25</b>	ø <b>32</b>	ø <b>40</b>
(N·m or less)	0.2	0.25	0.25	0.44

To screw a bracket or a nut onto the threaded portion at the tip of the piston rod, make sure to retract the piston rod entirely, and place a wrench over the flat portion of the rod that protrudes.

Tighten it by giving consideration to prevent the tightening torque from being applied to the non-rotating guide.





2. When replacing rod seals, please contact SMC.

Air leakage may be happened, depending on the position in which a rod seal is fitted. Thus, please contact SMC when replacing them.

3. Not able to disassemble.


Cover and cylinder tube are connected to each other by caulking method, thus making it impossible to disassemble. Therefore, internal parts of a cylinder other than rod seal are not replaceable.

4. Do not touch the cylinder during operation.


Use caution when handling a cylinder, which is running at a high speed and a high frequency, because the surface of a cylinder tube could get so hot enough as to cause you get burned.

- 5. The oil stuck to the cylinder is grease.
- 6. The base oil of grease may seep out.
- When using a rod end bracket, make sure it does not interfere with other brackets, workpieces and rod section, etc.





## Female rod end




Female Rod End           Bore size         A1         H         MM           20         8         10         M4 x 0.7           25         8         10         M5 x 0.8           32         12         10         M6 x 1				
Bore size	<b>A</b> 1	Н	MM	ZZ
20	8	10	M4 x 0.7	86
25	8	10	M5 x 0.8	86
32	12	10	M6 x 1	88
40	13	10	M8 x 1.25	114

- \* When female thread is used, use a thin wrench when tightening the piston rod.
- When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.


																							[mm]
Bore size	Stroke range	Α	AL	В	Вı	GA	GB	Η	Ηı	I	KB	L	LD	H	LX	MM	N	ND	Р	S	Χ	Υ	ZZ
20	1 to 150	18	15.5	30.3	13	22	8	27	5	28	8.2	33.5	ø 5.5, ø 9.5 counterbore depth 6.5	15	21	M8 x 1.25	24	20_0.033	1/8	76	39	12	103
25	1 to 200	22	19.5	36.3	17	22	8	31	6	33.5	10.2	39	ø 6.6, ø 11 counterbore depth 7.5	18	25	M10 x 1.25	30	26_0.033	1/8	76	43	12	107
32	1 to 200	22	19.5	42.3	17	22	8	31	6	37.5	12.2	47	ø 9, ø 14 counterbore depth 10	21	30	M10 x 1.25	34.5	26_0.033	1/8	78	43	12	109
40	1 to 300	24	21	52.3	22	27	11	34	8	46.5	14.2	58.5	ø 11, ø 17.5 counterbore depth 12.5	26	38	M14 x 1.5	42.5	32_0.039	1/4	104	49	15	138

## Front Mounting Style

## CM2RKB Bore size - Stroke Z



## Female rod end



Female R	od E	nd		[mm]	
Bore size	A <sub>1</sub>	Н	MM	ZZ	
20	8	10	M4 x 0.7	86	
25	8	10	M5 x 0.8	86	
32	12	10	M6 x 1	88	
40	13	10	M8 x 1.25	114	

- \* When female thread is used, use a thin wrench when tightening the piston rod.
- \* When female thread is used, use a washer etc. to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.
  [mm]

Bore size	Stroke range	Α	AL	Bı	F	FF	FX	GA	GB	Н	Ηı	I	KB	MM	N	ND	Р	S	ZZ
20	1 to 150	18	15.5	13	30.4	M5 x 0.8 depth 9	22	22	8	27	5	28	8.2	M8 x 1.25	24	20_0.033	1/8	76	103
25	1 to 200	22	19.5	17	36.4	M6 x 1 depth 11	26	22	8	31	6	33.5	10.2	M10 x 1.25	30	26-0.033	1/8	76	107
32	1 to 200	22	19.5	17	42.4	M6 x 1 depth 11	30	22	8	31	6	37.5	12.2	M10 x 1.25	34.5	26_0.033	1/8	78	109
40	1 to 300	24	21	22	52.4	M8 x 1.25 depth 14	36	27	11	34	8	46.5	14.2	M14 x 1.5	42.5	32_0.039	1/4	104	138

Double Acting, Single Ro

Double Acting, Double Rod

Single Acting, Spring Return Extend

Double Acting, Single Rod CM2K

Double Acting, Double Rod

Single Acting, Spring Return/Extend

ouble Acting, Single Rod

Direct Mount, Non-rotating Rod
Double Acting, Single Rod
CM2RK


Centralised Piping
Double Acting, Single Rod
CM2 P

# Air Cylinder: Centralised Piping Type Double Acting, Single Rod

# Series CM2 P

ø 20, ø 25, ø 32, ø 40

## **How to Order**



#### Applicable Auto Switches/Refer to the Auto Switch Guide for further information on auto switches.

		Electrical	tor	\A/:		Load volt	age	Auto swite	oh modal	Lea	ıd wi	e len	igth [	m]	Pre-wired	Appli	cable									
Гуре	Special function	Electrical entry	ndicator light	Wiring (Output)	1	C	AC	Perpendicular		0.5	1	3	5	None	connector		ad									
			<u>ě</u>	` ' '					In-line	(—)	(M)	(L)	(Z)	(N)												
				3-wire (NPN)		5 V, 12 V		M9NV	M9N	•	•	•	0	_	0	IC circuit										
		Grommet		3-wire (PNP)		0 1, 12 1		M9PV	M9P	•		•	0	_	0	10 circuit										
뜻				2-wire	12 V	12 V		M9BV	M9B			•	0	_	0	_	-									
switch		Connector		Z-WIIG		12 V			H7C		<u> </u>				_											
		Terminal		3-wire (NPN)		5 V, 12 V		_	G39A	_	_	_	—		_	IC circuit										
육		conduit	,	2-wire		12 V			K39A		<u> </u>	_	—		_	_	Polov									
a	Diagnostic indication (2-colour indication)		Yes	3-wire (NPN)	24 V	5 V, 12 V	,] —	M9NWV	M9NW				0	_	0	IC circuit	Relay,									
=			ĺ .	3-wire (PNP)		5 V, 12 V		M9PWV	M9PW				0	_	0	10 circuit	] 120									
				2-wire	12	12 V		M9BWV	M9BW				0	_	0	_	_									
	Water resistant	Grommet		3-wire (NPN)		5 V, 12 V		M9NAV**	M9NA**	0	0	•	0	_	0	IC circuit										
Ň	(2-colour			3-wire (PNP)		5 V, 12 V		M9PAV**	M9PA**	0	0	•	0	_	0	IC CITCUIT										
	indication)								2-wire		12 V		M9BAV**	M9BA**	0	0	•	0	_	0	_	]				
	With diagnostic output (2-colour indication)			4-wire (NPN)		5 V, 12 V		_	H7NF	•	_	•	0	_	0	IC circuit	]									
												ŕes	3-wire (NPN equivalent)	_	5 V	_	A96V	A96	•	-	•	_	_	_	IC circuit	_
		0	ĺ				100 V	A93V	A93	•	_	•	•	_	_	_										
switch		Grommet	2				100 V or less	A90V	A90	•	_	•	_	_	_	IC circuit	1									
Š			No Yes No				100 V, 200 V	_	B54	•	<u> </u>	•	•	_	_		Relay,									
			2				200 V or less	_	B64	•	_	•	_	_	_	l —	PLC									
ant		Connector	No Yes	2-wire	24 V	12 V	_	_	C73C	•	<u> </u>	•	•	•	_											
Reed auto		Connector	8	2-wire	24 V		24 V or less	_	C80C	•	_	•	•	•	_	IC circuit	1									
36		Terminal					_	_	A33A		_	_	_	•	_		PLC									
_		conduit	Yes				100 V,	_	A34A	_	_	_	_	•	_		Dale									
		DIN terminal	۳				200 V	_	A44A	—	_	_	_	•	_	1 -	Relay,									
	Diagnostic indication (2-colour indication)	Grommet				_	_	_	B59W		_	•	_	_	_	]	FLC									

<sup>\*\*</sup> Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers.

\* Lead wire length symbols: 0.5 m ······ (Example) M9NW

1 m ······ M (Example) M9NWM

None ······ N

3 m ······ Z (Example) M9NWL 5 m ······ Z (Example) M9NWZ

(Example) H7CN

<sup>\*</sup> Solid state auto switches marked with "O" are produced upon receipt of order.

<sup>\*</sup> Since there are other applicable auto switches than listed above, refer to page 99 for details.

<sup>\*</sup> For details about auto switches with pre-wired connector, refer to the **Auto Switch Guide**.


<sup>\*</sup> The D-A9 \( \Box \) M9 \( \Box \) auto switches are shipped together, (but not assembled). (However, only the auto switch mounting brackets are assembled before shipment.)

cylinder in which piping ports are provided in cover, head enabling pipes to be connected only in the axial direction.



## **Symbol**

Double acting, Single rod, Rubber bumper



## **Made to Order**

(For details, refer to pages 101 to 117.)

Symbol	Specifications
-XA□	Change of rod end shape
-XC4	With heavy duty scraper
-XC6	Made of stainless steel
-XC29	Double knuckle joint with spring pin
-XC52	Mounting nut with set screw
-XC85	Grease for food processing equipment

## **Precautions**

Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

## **Specifications**

Bore size [mm]	20	25	32	40	
Action		Double actin	g, Single rod		
Fluid		Α	ir		
Proof pressure	1.5 MPa				
Maximum operating pressure	1.0 MPa				
Minimum operating pressure	0.05 MPa				
Ambient and fluid temperature	Without auto switch: -10 °C to 70 °C (No freezing) With auto switch: -10 °C to 60 °C				
Lubrication	Not required (Non-lube)				
Stroke length tolerance		+1.4 0 r	nm		
Cushion		Rubber	bumper		
Piston speed	50 to 700 mm/s	50 to 650 mm/s	50 to 590 mm/s	50 to 420 mm/s	
Allowable kinetic energy	0.27 J	0.4 J	0.65 J	1.2 J	

## **Standard Strokes**

Bore size [mm]	Standard stroke [mm] Note 1)	Maximum manufacturable stroke [mm]		
20				
25	25, 50, 75, 100, 125, 150	1000		
32	200, 250, 300	1000		
40				

Note 1) Other intermediate strokes can be manufactured upon receipt of order. Manufacture of intermediate strokes at 1 mm intervals is possible. (Spacers are not used.)

Note 2) When exceeding 300 strokes, refer to "Air Cylinders Model Selection".

## **Mounting and Accessories**

Accessories	Stan	dard	Option						
Mounting	Mounting nut	Rod end nut	Single knuckle joint	Double knuckle joint (with pin)	Rod boot	Pivot bracket			
Basic	● (1 pc.)	•	•	•	•				
Rod flange	● (1 pc.)	•	•	•	•	l			
Rod trunnion	● (1 pc.)	•	•	•	•	•			

<sup>\*</sup> A pin and retaining rings (split pins for ø 40) are shipped together with double knuckle joint.

## Mounting Brackets/Part No.

Mounting brookst	Min. order	В	ore siz	ze [mn	n]	Contents
Mounting bracket	q'ty	20	25	32	40	(for minimum order quantity)
Flange	1	CM-F020B	CM-F	032B	CM-F040B	1 flange
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut

<sup>\*</sup> Order 2 foots per cylinder.

#### Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.



## Series CM2□P

## **Rod Boot Material**

Symbol	Rod boot material	Maximum ambient temperature		
J Nylon tarpaulin		70 °C		
K	Heat resistant tarpaulin	110 °C*		

 $<sup>\</sup>ast$  Maximum ambient temperature for the rod boot itself.

## Weights

					[kg]
	Bore size [mm]	20	25	32	40
٥ŧ	Basic	0.14	0.21	0.27	0.58
Basic weight	Rod flange	0.20	0.30	0.36	0.70
ш≽	Rod trunnion	0.18	0.28	0.33	0.68
Addi	Additional weight per 50 mm of stroke		0.08	0.10	0.17
Option bracket	Single knuckle joint	0.06	0.06	0.06	0.23
Opt	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20


Calculation: (Example) CM2F32P-100

Basic weight------0.36
 Additional weight-----0.10

• Cylinder stroke-----100 stroke

0.36 + 0.10 x 100/50 = **0.56 kg** 

## Construction



## **Component Parts**

No.	Description	Material	Note		
1	Rod cover	Aluminium alloy	Clear anodised		
2	Head cover	Aluminium alloy	Clear anodised		
3	Cylinder tube	Stainless steel			
4	Piston	Aluminium alloy	Chromated		
5	Piston rod	Carbon steel	Hard chrome plating		
6	Bushing	Bearing alloy			
7	Seal retainer	Stainless steel			
8	Retaining ring	Carbon steel	Phosphate coating		
9	Pipe	Aluminium alloy	Clear anodised		
10	Stud	Brass	Electroless nickel plating		
11	Bumper A	Urethane			
12	Bumper B	Urethane			


No.	Description	Material	Note
13	Retaining ring	Stainless steel	
14	Piston seal	NBR	
15	Piston gasket	NBR	
16	Gasket	Resin	
17	Pipe gasket	Urethane rubber	
18	Spacer gasket	Resin	Except ø 25
19	Wear ring	Resin	
20	Mounting nut	Carbon steel	Nickel plating
21	Rod end nut	Carbon steel	Zinc chromated

## **Replacement Part: Seal**

No.	Description	Material	Part no.							
	Description		20	25	32	40				
22	Rod seal	NBR	CM220-PS	CM225-PS	CM232-PS	CM240-PS				

<sup>\*</sup> Since the seal does not include a grease pack, order it separately. **Grease pack part number: GR-S-010** (10 g)

## Basic (B)



Bore size	Α	AL	Bı	B <sub>2</sub>	D	Е	F	FL	G	Н	H₁	H <sub>2</sub>	_	K	KA	MM	N	NA	NN	Р	Q	QY	S	ZZ
20	18	15.5	13	26	8	20_0033	13	10.5	_	41	5	8	28	5	6	M8 x 1.25	15	24	M20 x 1.5	1/8	19.8	14	62	103
25	22	19.5	17	32	10	26_0.033	13	10.5		45	6	8	33.5	5.5	8	M10 x 1.25	15	30	M26 x 1.5	1/8	22	14	62	107
32	22	19.5	17	32	12	26_0.033	13	10.5	9	45	6	8	37.5	5.5	10	M10 x 1.25	15	34.5	M26 x 1.5	1/8	25.8	16	64	109
40	24	21	22	41	14	$32_{-0.039}^{0}$	16	13.5	10.5	50	8	10	46.5	7	12	M14 x 1.5	21.5	42.5	M32 x 2	1/4	29.8	16	88	138

<sup>\*</sup> The dimensions of air cylinders with a rod boot are the same as the standard, double acting/single rod boss-cut type. Refer to page 13.

Double Acting, Single F

Double Acting, Double Rod

CM2W

Single Acting, Spring Return/Extend

SW Double Acting, 3

ing, Spring Return/Extend Double ,

uble Acting, Single Rod

Direct Mount, Non-rotating Rod
Double Acting, Single Rod

Double Acting, Single Rod

With End Lock


**Auto Switch** 

Made to Order

[mm]

## Series CM2□P


## Rod Flange (F)



Bore size	Α	AL	Bı	<b>B</b> <sub>2</sub>	$\mathbb{C}_2$	D	F	FB	FD	FT	FX	FY	FΖ	G	Н	H₁	H <sub>2</sub>	Ι	K	KA	MM	Ν	NA	NN	Р	Q	QY	S	Z	ZZ
20	18	15.5	13	26	30	8	13	34	7	4	60	_	75	_	41	5	8	28	5	6	M8 x 1.25	15	24	M20 x 1.5	1/8	19.8	14	62	37	103
25	22	19.5	17	32	37	10	13	40	7	4	60	_	75	_	45	6	8	33.5	5.5	8	M10 x 1.25	15	30	M26 x 1.5	1/8	22	14	62	41	107
32	22	19.5	17	32	37	12	13	40	7	4	60	_	75	9	45	6	8	37.5	5.5	10	M10 x 1.25	15	34.5	M26 x 1.5	1/8	25.8	16	64	41	109
40	24	21	22	41	47.3	14	16	52	7	5	66	36	82	10.5	50	8	10	46.5	7	12	M14 x 1.5	21.5	42.5	M32 x 2	1/4	29.8	16	88	45	138

<sup>\*</sup> The bracket is shipped together.

## **Rod Trunnion (U)**



<sup>\*</sup> The bracket is shipped together.

<sup>\*</sup>The dimensions of air cylinders with a rod boot are the same as the standard, double acting/single rod boss-cut type. Refer to page 13.




<sup>\*</sup> The dimensions of air cylinders with a rod boot are the same as the standard, double acting/single rod boss-cut type. Refer to page 13.

# Series CBM2

ø **20**, ø **25**, ø **32**, ø **40** 

## **How to Order**



## Applicable Auto Switches/Refer to the Auto Switch Guide for furth

<u> </u>	licable Auto	OWITCH	C3/	nelei lo lile A	ulo 3W	nten Guid	e ioi iuitiiei	IIIIOIIIIalioii	on auto swi	luics	•						
		Electrical	ator	Wiring		Load volt	age	Auto swit	ch model		ad wii	re len	<del>~ ·</del>		Pre-wired	Appli	cable
Type	Special function	entry	ndicato light	(Output)		DC	AC	Perpendicular	In-line	0.5	1 (M)	3 (L)	5 (7)	None (NI)	connector	loa	
			=	3-wire (NPN)				M9NV	M9N	(—)	(IVI)	(L)	(2)	(14)	0		
		Grommet		3-wire (PNP)	1	5 V, 12 V		M9PV	M9P	•	•	•	0	_	0	IC circuit	
ť				2-wire	1	12 V		M9BV	M9B	•	•	•	0	_	0		
switch		Connector		_				_	H7C	•	_	•	•	•	_		
S C		Terminal		3-wire (NPN)		5 V, 12 V		_	G39A**	_	_	_	_	•	_	IC circuit	
auto		conduit	S	2-wire		12 V			K39A**	_	_	_	_	•	_		Relay,
te a	Diagnostic indication		Yes	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•		•	0	_	0	IC circuit	PLC
state	(2-colour indication)			3-wire (PNP) 2-wire		12 V		M9PWV M9BWV	M9PW M9BW				0	_	0		
Solid	Water resistant	Grommet		3-wire (NPN)				M9NAV***	M9NA***				0	$\vdash$	0	_	
So	(2-colour	arominict		3-wire (PNP)	ł	5 V, 12 V		M9PAV***	M9PA***	0	0	-	0	_	0	IC circuit	
	indication)			2-wire	1	12 V		M9BAV***	M9BA***	0	0	•	0	_	0	_	
	With diagnostic output (2-colour indication)			4-wire (NPN)	1	5 V, 12 V		-	H7NF	•	_	•	0	_	0	IC circuit	
			Yes	3-wire (NPN equivalent)	_	5 V	-	A96V	A96	•	-	•	_		_	IC circuit	_
_		Grommet	ĺ				100 V	A93V	A93	•	_	•	•	_	_	_	
itch		Gioiiiiiet	2				100 V or less	A90V	A90	•	<u> </u>	•	_	_	_	IC circuit	
SWİ			No Yes				100 V, 200 V	_	B54**	•	<u> </u>	•	•	_	_		Relay,
ţ			2				200 V or less		B64**	•	<u> </u>	•	_	_		-	PLC
an		Connector	No Yes	2-wire	24 V	12 V		_	C73C	•	_	•	•	•		10 : "	
Reed auto switch			ž				24 V or less		C80C	•	_	•	•	•		IC circuit	DLC
Ä		Terminal conduit					100 V,		A33A** A34A**	$\vdash$	F	$\vdash$	F			-	PLC
		DIN terminal	Yes				200 V		A44A**	$\vdash =$	H	$\equiv$	Е			<u> </u>	Relay,
	Diagnostic indication (2-colour indication)	Grommet	1			<u> </u>			B59W		H		H			1	PLC

<sup>\*\*\*</sup> Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. Please contact SMC regarding water resistant types with the above model numbers.

- \* Lead wire length symbols: 0.5 m ·· (Example) M9NW
  - (Example) M9NWM 1 m ..... M (Example) M9NWL 3 m ..... L
  - (Example) M9NWZ None ······ N (Example) H7CN
- \* Solid state auto switches marked with "O" are produced upon receipt of order
- \* Do not indicate suffix "N" for no lead wire on D-A3 A/A44A/G39A/K39A models
- \*\* The D-A3□A/A44A/G39A/K39A/B54/B64 cannot be mounted on bore sizes ø 20 and ø 25 cylinder with air cushion.
- \* Since there are other applicable auto switches than listed above, refer to page 99 for details
- \* For details about auto switches with pre-wired connector, refer to the Auto Switch Guide.
- \* The D-A9 \( \to \)-\( \t

Direct Mount

Centralised Piping Direct Mount, Non-rotating Rod

End Lock

Switch Auto

Made to Order

## Series CBM2

## Holds the cylinder's home position even if the air supply is cut off.

When air is discharged at the stroke end position, the lock engages to maintain the rod in that position.


Non-locking type and locking type are standardised for manual release.

Auto switch is mountable.



## **Symbol**

Rubber bumper





### Made to Order (For details, refer to pages 101 to 117.)

Symbol	Specifications
-ХА□	Change of rod end shape
-XB6	Heat resistant cylinder (-10 to 150 °C)
-XB9	Low speed cylinder (10 to 50 mm/s)
-XC3	Special port location
-XC4 *	With heavy duty scraper
-XC5	Heat resistant cylinder (-10 to 110 °C)
-XC6	Made of stainless steel
-XC8 *	Adjustable stroke cylinder/Adjustable extension type
-XC13	Auto switch rail mounting
-XC22	Fluororubber seal
-XC25	No fixed throttle of connection port
-XC27	Double clevis and double knuckle pins made of stainless steel
-XC29	Double knuckle joint with spring pin
-XC35	With coil scraper
-XC52	Mounting nut with set screw

<sup>\*</sup> Available only for locking at head end

## **Specifications**

Bore size [mm]	20	25	32	40				
Туре		Pneu	ımatic					
Action	Double acting, Single rod							
Fluid	Air							
Proof pressure	1.5 MPa							
Maximum operating pressure		1.0	MPa					
Minimum operating pressure		0.15	MPa *					
Ambient and fluid temperature	Without auto switch: -10 °C to 70 °C (No freezing With auto switch: -10 °C to 60 °C							
Cushion	Rubber bumper, Air cushion							
Lubrication			d (Non-lube)					
Stroke length tolerance		+1.4 0	mm					
Piston speed	Rubber bu	ımper	50 to 750 r	nm/s				
Fision speed	Air cush	ion	50 to 1000	mm/s				
	В	asic, Axial fo	ot, Rod flang	e,				
Mounting	Head flange, Single clevis, Double clevis,							
	F	n						

<sup>\* 0.05</sup> MPa for other part than the lock unit

## **Lock Specifications**

Lock position	He	ad end, Rod	end, Double	end						
Holding force (May ) [N]	ø <b>20</b>	ø <b>25</b>	ø <b>32</b>	ø <b>40</b>						
Holding force (Max.) [N]	215	330	550	860						
Backlash		1 mm or less								
Manual release	No	Non-locking type, Locking type								

## **Allowable Kinetic Energy**

E	Bore size [mm]	20	25	32	40
Rubber bumper	Allowable kinetic energy [J]	0.27	0.4	0.65	1.2
	Effective cushion length [mm]	11.0	11.0	11.0	11.8
Air	Cushion sectional area [cm²]	2.09	3.30	5.86	9.08
cushion	Absorbable kinetic energy [J]	0.54	0.78	1.27	2.35

## **Standard Strokes**

Bore size [mm]	Standard stroke [mm]	Long stroke * [mm]	Maximum manufacturable stroke [mm]
20	25, 50, 75, 100,	400	
25	125, 150, 200, 250	450	1000
32	l ' ' '	450	1000
40	300	500	]

<sup>\*</sup> Long stroke applies to the axial foot and rod flange types only.

When using other types of mounting brackets or exceeding the long stroke limit, refer to "Air Cylinders Model Selection".

Refer to pages 95 to 99 for cylinders with auto switches.

- Auto switch proper mounting position (detection at stroke end) and its mounting height
- Minimum stroke for auto switch mounting
- Operating range
- Auto switch mounting brackets/Part no.



<sup>\*</sup> Manufacture of intermediate strokes at 1 mm intervals is possible. (Spacers are not used.)

## Accessories/For details, refer to pages 22 and 23, since it is the same as Series CM2 standard type.

Standard	Mounting nut, Rod end nut, Lock release bolt (N type only)
Option	Single knuckle joint, Double knuckle joint (with pin)

<sup>\*</sup> Mounting nuts are not equipped to single clevis and double clevis.

## **Rod Boot Material**

Sy	mbol	Rod boot material	Max. ambient temperature
	L	Nylon tarpaulin	60 °C
	K	Heat resistant tarpaulin	110 °C*

<sup>\*</sup> Maximum ambient temperature for the rod boot itself.

## Weights

					[kg]
	Bore size [mm]	20	25	32	40
	Basic	0.14	0.21	0.28	0.56
	Axial foot	0.29	0.37	0.44	0.83
Basic	Flange	0.20	0.30	0.37	0.68
weight	Single clevis	0.18	0.25	0.32	0.65
	Double clevis	0.19	0.27	0.33	0.69
	Trunnion	0.18	0.28	0.34	0.66
Additional	weight per 50 mm of stroke	0.04	0.06	0.08	0.13
	Clevis pivot bracket (with pin)	0.07	0.07	0.14	0.14
Option bracket	Single knuckle joint	0.06	0.06	0.06	0.23
Diacket	Double knuckle joint (with pin)	0.07	0.07	0.07	0.20

## **Lock Unit Additional Weights**

					[kg]
Bore s	Bore size [mm]			32	40
Non-locking type	Head end lock (H)	0.02	0.02	0.02	0.04
manual release (N)	Rod end lock (R)	0.01	0.01	0.01	0.02
manual release (N)	Double end lock (W)	0.03	0.03	0.03	0.06
Looking type	Head end lock (H)	0.03	0.03	0.03	0.06
Locking type manual release (L)	Rod end lock (R)	0.02	0.02	0.02	0.04
manuar release (L)	Double end lock (W)	0.05	0.05	0.05	0.10

#### Calculation: (Example) CBM2L32-100-HN

- Basic weight------0.44 (Foot, ø 32)
- Additional weight-----0.08/50 stroke
- Cylinder stroke -----100 stroke
- Lock unit weight ......0.02 (Locking at head end, Non-locking type manual release)

 $0.44 + 0.08 \times 100/50 + 0.02 =$ **0.62 kg** 

## Mounting Brackets/Part No.

Maunting brookst	Min.	В	ore siz	ze [mn	n]	Contents
Mounting bracket	order q'ty	20	25 32		40	(for minimum order quantity)
Axial foot*	2	CM-L020B	CM-L	032B	CM-L040B	2 foots, 1 mounting nut
Flange	1	CM-F020B	CM-F	032B	CM-F040B	1 flange
Single clevis**	1	CM-C020B	CM-C	CM-C032B CM-C040B		1 single clevis, 3 liners
**	4	CM-D020B	CM-D032B		CM-D040B	1 double clevis, 3 liners,
Double clevis (with pin)	l	CIVI-DUZUB	CIVI-D	032D	CIVI-DU4UD	1 clevis pin, 2 retaining rings
Trunnion (with nut)	1	CM-T020B	CM-T	032B	CM-T040B	1 trunnion, 1 trunnion nut

<sup>\*</sup> Order 2 foots per cylinder.

<sup>\*\* 3</sup> liners are included with a clevis bracket for adjusting the mounting angle.

<sup>\*\*\*</sup> A clevis pin and retaining rings (split pins for ø 40) are included.

## Series CBM2

## **Double Rod Type End Lock Cylinder**

CBM2W Mounting style Bore size - Stroke - H Manual release type

Double rod type end lock cylinder


## **Specifications**

Action	Double acting, Double rod
Bore size [mm]	ø 20, ø 25, ø 32, ø 40
Max. operating pressure	1.0 MPa
Min. operating pressure	0.15 MPa
Cushion	Rubber bumper
Piston speed	50 to 750 mm/s
Mounting	Basic, Foot, Flange, Trunnion
Lock position	Head end lock
Max. manufacturable stroke	500 mm

Note 1) Auto switch can be mounted.

Bore size [mm]	Н	ZZ
20	41	144
25	45	152
32	45	154
40	50	188

**Dimensions** 



## Non-rotating Rod Type End Lock Cylinder

CBM2K | Mounting style | Bore size | - | Stroke | - H | Manual release type

Non-rotating rod type end lock cylinder

## **Specifications**

Action	Double acting, single rod					
Bore size [mm]	ø 20, ø 25, ø 32, ø 40					
Max. operating pressure	1.0 MPa					
Min. operating pressure	0.15 MPa					
Cushion	Rubber bumper					
Piston speed	50 to 500 mm/s					
Mounting	Basic, Foot, Rod flange, Head flange, Single clevis, Double clevis, Rod trunnion, Head trunnion					
Lock position	Head end lock					
Max. manufacturable stroke	1000 mm					

Note 1) Auto switch can be mounted.


Note 2) Refer to the Precautions on page 90 for the head flange and head trunnion types.

Note 3) When exceeding 300 strokes, refer to the stroke selection table.

## **Dimensions**

Bore size [mm]	KA	
20	8.2	
25	10.2	
32	12.2	
40	14.2	

\* Dimensions for other bore sizes are the same as the double acting single rod model.







Note 2) Refer to the Precautions on page 90 when mounting flange and trunnion brackets on the end lock side.


<sup>\*</sup> Dimensions for other bore sizes are the same as the double acting single rod model.

## Rod end lock

## With air cushion







## **Component Parts**

001111	poriorit i arto		
No.	Description	Material	Note
1	Rod cover	Aluminium alloy	Clear anodised
2	Head cover	Aluminium alloy	Clear anodised
3	Cylinder tube	Stainless steel	
4	Piston	Aluminium alloy	Chromated
5	Piston rod	Carbon steel	Hard chrome plating
6	Bushing	Bearing alloy	
7	Seal retainer	Stainless steel	
8	Retaining ring	Carbon steel	Phosphate coating
9	Lock piston	Carbon steel	Hard chrome plating, Heat treated
10	Lock bushing	Bearing alloy	
11	Lock spring	Stainless steel	
12	Bumper	Urethane	
13	Hexagon socket head cap screw	Alloy steel	Black zinc chromated
14A	Cap A	Aluminium die-casted	Black painted
14B	Cap B	Carbon steel	Oxide film treated
15	Rubber cap	Synthetic rubber	
16	M/O knob	Zinc die-casted	Black painted
17	M/O bolt	Alloy steel	Black zinc chromated, Red painted
18	M/O spring	Steel wire	Zinc chromated
19	Stopper ring	Carbon steel	Zinc chromated
20	Bumper A	Urethane	
21	Bumper B	Urethane	
22	Retaining ring	Stainless steel	
23	Piston seal	NBR	
24	Piston gasket	NBR	
25	Wear ring	Resin	
28	Mounting nut	Carbon steel	Nickel plating
29	Rod end nut	Carbon steel	Zinc chromated
30	Cushion ring	Aluminium alloy	Anodised
31	Cushion needle	Alloy steel	Electroless nickel plating
32	Cushion seal	Urethane	

## **Component Parts**

No.	Description	Material	Note
26	Rod seal	NBR	
27	Lock piston seal	NBR	
33	Cushion needle seal	NBR	

## **Replacement Parts: Seal Kit**

## With one end lock

Bore size [mm]	[mm] 20		32	40
Kit no.	CBM2-20-PS	CBM2-25-PS	CBM2-32-PS	CBM2-40-PS

## With double end lock

Kit no.	CBM2-20-PS-W	CBM2-25-PS-W	CBM2-32-PS-W	CBM2-40-PS-W
1 1 /4 / 1	-1	O	1.94 January I. am	

- st Seal kit includes lpha and lpha. Order the seal kit, based on each bore size. (Except 33.)
- \* Seal kit includes a grease pack (10 g). Order with the following part number when only the grease pack is needed. Grease pack part number: GR-S-010 (10 g)


## How to Replace the Rod Seal

#### <Removal>

•Remove the retaining ring (A) by using a tool for installing a type C retaining ring for hole. Shut off the port on the rod cover by finger and then pull out the piston rod, and the seal retainer (B) and the rod seal (C) are removed.

## <Mounting>


• After applying enough grease on the rod seal, attach in this order, rod seal (C), seal retainer (B) and retaining ring (A).




## Series CBM2

Basic (Dimensions are common irrespective of the lock position; rod end, head end or double end.)


Head end lock: CBM2B Bore size - Stroke -HN






Non-locking type manual release: Suffix N


Rod end lock: CBM2B Bore size - Stroke -RN






Double end lock: CBM2B Bore size - Stroke -WN

Locking type manual release: Suffix L



#### With rod boot



																											[111111]
Symbol Bore size [mm]	Stroke range	A	AL	B <sub>1</sub>	B <sub>2</sub>	D	DL	E	F	FL	G	Н	H₁	H <sub>2</sub>	HR	HN (Max.)	I	K	KA	ММ	МО	N	NA	NN	Р	S	ZZ
20	Up to 300	18	15.5	13	26	8	8	20 0 -0.033	13	10.5	8	41	5	8	22.3	34	28	5	6	M8 x 1.25	15	15	24	M20 x 1.5	1/8	62	116
25	Up to 300	22	19.5	17	32	10	8	26 -0.033	13	10.5	8	45	6	8	25.3	37	33.5	5.5	8	M10 x 1.25	15	15	30	M26 x 1.5	1/8	62	120
32	Up to 300	22	19.5	17	32	12	8	26 -0.033	13	10.5	8	45	6	8	27.6	39.3	37.5	5.5	10	M10 x 1.25	15	15	34.5	M26 x 1.5	1/8	64	122
40	Up to 300	24	21	22	41	14	11	32 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	16	13.5	11	50	8	10	33.6	47.8	46.5	7	12	M14 x 1.5	19	21.5	42.5	M32 x 2	1/4	88	154

With Ro	d B	oot	t														[mm]
Symbol	В3		£				h				e						
Bore size [mm]	ВЗ	е	'	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	30	36	18	68	81	93	106	131	156	181	12.5	25	37.5	50	75	100	125
25	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125
32	32	36	18	72	85	97	110	135	160	185	12.5	25	37.5	50	75	100	125
40	41	46	20	77	90	102	115	140	165	190	12.5	25	37.5	50	75	100	125

		-	_	-	-	_	-		_		
With Ro			[mı	m]							
Symbol		ZZ									
Bore size [mm]	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	J	"	JW	
20	143	156	168	181	206	231	256	23	3.5	10.5	
25	147	160	172	185	210	235	260	23	3.5	10.5	
32	149	162	174	187	212	237	262	23	3.5	10.5	
40	181	194	206	219	244	269	294	27	,	10.5	

<sup>\*</sup> For details about the rod end nut and accessories, refer to pages 22 and 23.






Direct Mount, Non-rotating Rod


Centralised Piping


Lock


End

## With Mounting Bracket (For dimensions other than shown below, refer to page 89.) Axial foot: CBM2L Bore size **Stroke**









\* The bracket is shipped together.

			Tr	unr	iion			
1	тт	τv	ΤY	T7	2	<u> </u>	Z	Z
		1 ^	11	14				

Bore						Axia	al fo	ot										FI	anç	ge								CI	evis	;								Tr	unn	ion			
size [mm]		В								v	v	7	77	Stroke	range	В	_	FD		FV	ΓV		2	<u> </u>	Stroke	CD.	٥v	C7		DD		_	<b>,,</b> S	troke	TD		TV	TV	T7	- 2	Z	Z	Z
[mm]	range	Р	LC	LD	LN	LO	LI	LA	LZ	^	Y	2	22	Rod side	Head side	Р	<b>C</b> 2	ΓD	г	ΓX	Гĭ	<b>F</b> Z	Rod side	Head side	range	CD	CX	UZ.	_	nn	١	-	<b>~~</b>   n	ange	טו	"	1.	11	12	Rod side	Head side	Rod side	Head side
20	Up to 400	40	4	6.8	25	102	3.2	40	55	20	8	21	131	Up to 400	Up to 300	34	30	7	4	60	_	75	37	107	Up to 300	9	10	19	30	9	14	133	142 Up	to 300	8	10	32	32	52	36	108	116	118
25	Up to 450	47	4	6.8	28	102	3.2	40	55	20	8	25	135	Up to 450	Up to 300	40	37	7	4	60	_	75	41	111	Up to 300	9	10	19	30	9	14	137	146 Up	to 300	9	10	40	40	60	40	112	120	122
32	Up to 45	47	4	6.8	28	104	3.2	40	55	20	8	25	137	Up to 450	Up to 300	40	37	7	4	60	_	75	41	113	Up to 300	9	10	19	30	9	14	139	148 Up	to 300	9	10	40	40	60	40	114	122	124
40	Up to 50	54	4	7	30	134	3.2	55	75	23	10	27	171	Up to 500	Up to 300	52	47.3	7	5	66	36	82	45	143	Up to 300	10	15	30	39	11	18	177	188 Up	to 300	10	11	53	53	77	44.5	143.5	154	154

<sup>\*</sup> Dimensions other than mentioned above are the same as on page 89.

## Precautions on Trunnion Type, Flange Type

<sup>(1)</sup> Bod truppion with rod end lock (2) Head truppion with head end lock (3) With double end lock. For these cases, use caution since the trunnion pin and fittings may be interfered with each other because the trunnion pin and port are very closed to each other.

<sup>2.</sup> Flange type (ø 20 to ø 32)

<sup>(1)</sup> Rod flange with rod end lock (2) Head flange with head end lock (3) With double end lock. For these cases, use caution since the bolt for mounting a cylinder and fittings may be interfered with each other.


## Series CBM2


## With Air Cushion (For dimensions other than shown below, refer to pages 89 and 90.)



Head end lock: CBM2B Bore size - Stroke A-HN

Non-locking type manual release: Suffix N






## With Air Cushion

[mm]


Bore size		S			WA <sub>1</sub>			WA <sub>2</sub>			ZZ	
[mm]	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock
20	72	73	83	13	24	24	23	13	23	126	127	137
25	72	73	83	13	24	24	23	13	23	130	131	141
32	72	75	83	13	24	24	21	13	21	130	133	141
40	93	96	101	16	24	24	21	16	21	159	162	167





Rod flange: CBM2F Bore size – Stroke A -R N + -W L






## **Rod trunnion:**







\* The bracket is shipped together.







## **Head trunnion:**



Z + Stroke
ZZ + Stroke

									[mm]
D i			Axia	l foot				Head flange	)
Bore size [mm]		LS			ZZ			Z	
[IIIIII]	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock
20	112	113	123	141	142	152	117	118	128
25	112	113	123	145	146	156	121	122	132
32	112	115	123	145	148	156	121	124	132

												[mm]
			Cle	evis					Head t	runnion		
Bore size [mm]		Z			ZZ			Z			ZZ	
[111111]	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock	Head end lock	Rod end lock	Double end lock
20	143	144	154	152	153	163	118	119	129	128	129	139
25	147	148	158	156	157	167	122	123	133	132	133	143
32	147	150	158	156	159	167	122	125	133	132	135	143
40	182	185	190	193	196	201	148.5	151.5	156.5	159	162	167






Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

#### **Use the Recommended Pneumatic Circuit**

## **△** Caution

 This is necessary for proper operation and release of the lock.



## Handling

## 

1. Do not use 3 position solenoid valves.

Avoid use in combination with 3 position solenoid valves (especially closed centre metal seal types). If pressure is trapped in the port on the lock mechanism side, the cylinder cannot be locked. Furthermore, even after being locked, the lock may be released after some time, due to air leaking from the solenoid valve and entering the cylinder.

2. Back pressure is required to release end lock.

Be sure air is supplied to the side of the cylinder without a lock mechanism (side of the piston rod without lock for double end lock), before starting up, as in the above figures. Otherwise, the lock may not be released. (Refer to "Releasing the Lock".)

3. Release the lock when mounting or adjusting the cylinder.

If mounting or other work is performed when the cylinder is locked, the lock unit may be damaged.

4. Operate with a load ratio of 50 % or less.

If the load ratio exceeds 50 %, this may cause problems such as failure of the lock to release, or damage to the lock unit.

Do not operate multiple cylinders in synchronisation.

Avoid applications in which two or more cylinders with end lock are synchronised to move one workpiece, as one of the cylinder locks may not be able to release when required.

Use a speed controller with meter-out control. Lock cannot be released occasionally by meter-in control.

7. Be sure to operate completely to the cylinder stroke end on the side with the lock.

If the cylinder piston does not reach the end of the stroke, locking might not work or locking might not be released.

8. The base oil of grease may seep out.

The base oil of grease in the cylinder may seep out of the tube, cover, or crimped part depending on the operating conditions (ambient temperature 40 °C or more, pressurised condition, low frequency operation).

## **Operating Pressure**

## **⚠** Caution

1. Supply air pressure of 0.15 MPa or higher to the port on the lock mechanism side, as it is necessary for releasing the lock.

#### **Exhaust Speed**

## 

1. The lock will be engaged automatically if the pressure applied to the port on the lock mechanism side falls to 0.05 MPa or less. In cases where the piping on the lock mechanism side is long and thin, or the speed controller is separated at some distance from the cylinder port, the exhaust speed will be reduced. Take note that some time may be required for the lock to engage. In addition, clogging of a silencer mounted on the solenoid valve exhaust port can produce the same effect.

#### **Relation to Cushion**

## **△** Caution

 When cushion valve at lock mechanism side is fully opened or closed, piston rod may not be reached at stroke end. Thus, lock is not established. And when locking is done at cushion valve fully closed, adjust cushion valve since lock may not be released.

## Releasing the Lock

## **△ Warning**

1. Before releasing the lock, be sure to supply air to the side without a lock mechanism, so that there is no load applied to the lock mechanism when it is released. (Refer to the recommended pneumatic circuits.) If the lock is released when the port on the other side is in an exhaust state, and with a load applied to the lock unit, the lock unit may be subjected to an excessive force and be damaged. Furthermore, sudden movement of the piston rod is very dangerous.





# Series CBM2 Specific Product Precautions 2

Be sure to read this before handling. Refer to the back cover for Safety Instructions. For Actuator and Auto Switch Precautions, refer to "Handling Precautions for SMC Products" and the Operation Manual on SMC website, http://www.smc.eu

#### **Manual Release**

## 

## 1. Non-locking type manual release


Insert the accessory bolt from the top of the rubber cap (it is not necessary to remove the rubber cap), and after screwing it into the lock piston, pull it to release the lock. If you stop pulling the bolt, the lock will return to an operational state.

Thread sizes, pulling forces and strokes are as shown below.

Bore size [mm]	Thread size	Pulling force	Stroke [mm]
20, 25, 32	M2.5 x 0.45 x 25 L or more	4.9 N	2
40	M3 x 0.5 x 30 L or more	10 N	3

Remove the bolt for normal operation.


It can cause lock malfunction or faulty release.



## 2. Locking type manual release

While pushing the M/O knob, turn it 90° counterclockwise. The lock is released (and remains in a released state) by aligning the ▲ mark on the cap with the ▼OFF mark on the M/O knob. When locking is desired, turn M/O knob clockwise 90° while pushing fully, correspond ▲ mark on cap and ▼ON mark on M/O knob. The correct position is confirmed by a clicking sound.

If not confirmed, locking is not done.




## **Working Principle**


The figures below are the same as those for Series CBA2.

#### •Head end lock (Rod end lock is the same, too.)


 When the piston rod is getting closer to the stroke end, the taper part (\*) of the piston rod edge will push the lock piston up.




2. Lock piston is pushed up further.




3. Lock piston is pushed up into the groove of piston rod to lock it. (Lock piston is pushed up by spring force.) At this time, it is exhausted from port in head side and introduced to atmosphere.



**4.** When pressure is supplied in the head side, lock piston will be pushed up to release the lock.



**5.** Lock will be released, then cylinder will move forward.



## Series CM2

## **Auto Switch Mounting**


## Auto Switch Proper Mounting Position (Detection at stroke end) and Its Mounting Height

### Solid state auto switch

**D-M9**□

D-M9□W

D-M9□A






( ): Values for D-M9 $\square$ A and B are the dimensions from the end of the head cover/rod cover to the end of the auto switch.

D-M9□V

D-M9□WV









( ): Values for D-M9 $\square$ AV A and B are the dimensions from the end of the head cover/rod cover to the end of the auto switch.

#### D-H7 | /H7 | W/H7NF/H7BA/H7C






## D-G5NT






## D-G39A/K39A



#### Reed auto switch


## **D-A9**□





( ): Values for D-A96 A and B are the dimensions from the end of the head cover/rod cover to the end of the auto switch.


#### D-A9□V






A and B are the dimensions from the end of the head cover/rod cover to the end of the auto switch.

#### D-C7/C8/C73C/C80C






#### D-B5/B6/B59W






## **D-A33A/A34A**



## **D-A44A**



## Auto Switch Proper Mounting Position (Detection at stroke end) and Its Mounting Height

## **Auto Switch Proper Mounting Position**

(Standard type (except single acting type), Non-rotating rod type, Direct mount type, Direct mount, Non-rotating rod type (except single acting type))

Auto switch model		⊐W(V)	<b>D-A</b> 9	)□(V)	D-G D-K D-A D-A	39A 3□A	D-H7 D-H7 D-H7 D-H7	7C 7□W 7BA	D-G	5NT	D-C D-C D-C		D-B5□ D-B64 A B 1.5 0		D-B	59W
Bore size \	Α	В	Α	В	Α	В	Α	В	Α	В	Α	В	Α	В	Α	В
20	11	9.5	7	5.5	1	0	6.5	5	3	1.5	7.5	6	1.5	0	4	3
25	10	10	6	6	0	0	5.5	5.5	2	2	6.5	6.5	0.5	0.5	3.5	3.5
32	11.5	10.5	7.5	6.5	1.5	0.5	7	6	3.5	2.5	8	7	2	1	5	4
40	17.5	15.5	13.5	11.5	7.5	5.5	13	11	9.5	7.5	14	12	8	6	11	9

Note) Adjust the auto switch after confirming the operating condition in the actual setting.

Auto Switch Proper Mounting Position (Centralised piping type, With end lock)

Auto Sv	VII.	1 Opci	woun	9 : .		. (00:	tiunoc	<u>a pipi</u>	<u> </u>	, , ,	ii ciia	10011				[mm]
Auto switch mode	<b>D-M9</b>	⊐W(V)	D-A9	)□(V)	D-G D-K D-A D-A	39A 3□A	D-H7 D-H7 D-H7 D-H7	7C 7□W 7BA	D-G	5NT	D-E D-E	-	_		D-B	59W
Bore size	Α	В	Α	В	Α	В	Α	В	Α	В	Α	В	Α	В	Α	В
20	10.5 (8)	9.5 (7)	6.5 (4)	5.5 (3)	0.5 (—)	0 (—)	6 (4)	5 (3)	2.5 (0.5)	1.5 (0)	1 (—)	0 ( <del></del> )	7 (5)	6 (4)	4 (2)	3 (1)
25	10.5 (8)	9.5 (7)	6.5 (4)	5.5 (3)	0.5 (—)	0 (—)	6 (4)	5 (3)	2.5 (0.5)	1.5 (0)	1 (—)	0 (—)	7 (5)	6 (4)	4 (2)	3 (1)
32	11.5 (9)	10.5 (8)	7.5 (5)	6.5 (4)	1.5 (0)	0.5 (0)	7 (5)	6 (4)	3.5 (1.5)	2.5 (0.5)	2 (0)	1 (0)	8 (6)	7 (5)	5 (3)	4 (2)
40	17.5	15.5	13.5	11.5	6.5	5.5	12	11	8.5	7.5	7	6	13	12	10	9

<sup>\* ( ):</sup> Setting position for the auto switch with an air cushion.

## **Auto Switch Mounting Height**

Auto Sw	itch Mountir	ng Height			[mm]
Auto switch model	( - )	D-B5□ D-B64 D-B59W D-G5NT D-H7C	D-C73C D-C80C	D-G39A D-K39A D-A3□A	D-A44A
Bore size \	Hs	Hs	Hs	Hs	Hs
20	24.5	25.5	25	60	69.5
25	27	28	27.5	62.5	72
32	30.5	31.5	31	66	75.5
40	34.5	35.5	35	70	79.5

The D-B5/B6/A3□A/A44A/G39A/K39A cannot be mounted on the bore size ø 20 and ø 25 cylinder with an air cushion.

Note 1) Adjust the auto switch after confirming the operating condition in the actual setting.

Note 2) The D-A3□A/A44A/G39A/K39A cannot be mounted on the centralised piping type CDM2□P series.

## Series CM2

## **Auto Switch Proper Mounting Position (Detection at stroke end)** Single Acting/Spring Return Type (S), Spring Extend Type (T)

## **Standard Type/Spring Return Type (S)**

Non-rotating	Rod Ty	pe/Spring					[m
Auto switch model	Bore size			A dimensions			В
1010 01110111110001		Up to 50 st	51 to 100 st		151 to 200 st	201 to 250 st	
D-M9□(V)	20	36	61	86	_	_	9.5
D-M9□W(V)	25	35	60	85		_	10
D-M9□A(V)	32	36.5	61.5	86.5	111.5	_	10.5
D INIO LA(V)	40	42.5	67.5	92.5	117.5	142.5	15.5
	20	32	57	82	_	_	5.5
D-A9□(V)	25	31	56	81	_	_	6
D-A3□( <b>V</b> )	32	32.5	57.5	82.5	107.5	_	6.5
	40	38.5	63.5	88.5	113.5	138.5	11.5
D-H7□	20	31.5	56.5	81.5	_		5
D-H7C D-H7□W	25	30.5	55.5	80.5	_	_	5.5
D-H7BA	32	32	57	82	107	_	6
D-H7NF	40	38	63	88	113	138	11
	20	28	53	78	_	_	1.5
D-G5NT	25	27	52	77	_	_	2
D-GSIVI	32	28.5	53.5	78.5	103.5	_	2.5
	40	34.5	59.5	84.5	109.5	134.5	7.5
	20	26.5	51.5	76.5	_	_	0
D-B5□	25	25.5	50.5	75.5	_	_	0.5
D-B64	32	27	52	77	102	_	1
	40	33	58	83	108	133	6
D-C7□	20	32.5	57.5	82.5	_	_	6
D-C80	25	31.5	56.5	81.5	_	_	6.5
D-C73C	32	33	58	83	108	_	7
D-C80C	40	39	64	89	114	139	12
	20	29	54	79	_	_	2.5
D DEOW	25	28.5	53.5	78.5	_	_	3.5
D-B59W	32	30	55	80	105	_	4
	40	36	61	86	111	136	9
D-G39A	20	26	51	76	_		0
D-K39A	25	25	50	75	_	_	0
D-A3□A	32	26.5	51.5	76.5	101.5	_	0.5
D-A44A	40	32.5	57.5	82.5	107.5	132.5	5.5

Note) Adjust the auto switch after confirming the operating condition in the actual setting.

## Standard Type/Spring Extend Type (T) Non-rotating Rod Type/Spring Extend Type (T)

Non-rotating	nou iy	ser abi iii c	Exterio	Type (T)			[mm]
Auto switch model	Bore size	Α			<b>B</b> dimensions		
Auto Switch model	Dore Size	A	Up to 50 st	51 to 100 st	101 to 150 st	151 to 200 st	201 to 250 st
D-M9□(V)	20	11	34.5	59.5	84.5	_	_
D-M9□(V)	25	10	35	60	85		_
D-M9□A(V)	32	11.5	35.5	60.5	85.5	110.5	_
D-IVIS A(V)	40	17.5	40.5	65.5	90.5	115.5	140.5
	20	7	30.5	55.5	80.5	_	_
D-A9□(V)	25	6	31	56	81		_
D-A3□(V)	32	7.5	31.5	56.5	81.5	106.5	_
	40	13.5	36.5	61.5	86.5	111.5	136.5
D-H7□	20	6.5	30	55	80		_
D-H7C D-H7□W	25	5.5	30.5	55.5	80.5	_	_
	32	7	31	56	81	106	_
D-H7BA D-H7NF	40	13	36	61	86	111	136
	20	3	26.5	51.5	76.5	_	_
D-G5NT	25	2	27	52	77	_	_
D-GSIVI	32	3.5	27.5	52.5	77.5	102.5	_
	40	9.5	32.5	57.5	81.5	107.5	132.5
	20	1.5	25	50	75	_	_
D-B5□	25	0.5	25.5	50.5	75.5		_
D-B64	32	2	26	51	76	101	_
	40	8	31	56	81	106	131
D-C7□	20	7.5	31	56	81		_
D-C80	25	6.5	31.5	56.5	81.5		_
D-C73C	32	8	32	57	82	107	_
D-C80C	40	14	37	62	87	112	137
	20	4	28	53	78		_
D-B59W	25	3.5	28.5	53.5	78.5	_	_
D-D39W	32	5	29	54	79	104	_
	40	11	34	59	84	109	134
D-G39A	20	1	24.5	49.5	74.5	_	_
D-K39A	25	0	25	50	75	_	_
D-A3□A	32	1.5	25.5	50.5	75.5	100.5	_
D-Δ44Δ	40	7.5	30.5	55.5	80.5	105.5	130.5

Note) Adjust the auto switch after confirming the operating condition in the actual setting.



## **Minimum Stroke for Auto Switch Mounting**

(Standard type (except single acting type), Non-rotating rod type, Direct mount type, Direct mount, Non-rotating rod type (except single acting type), Centralised piping type, With end lock)

				n: Numb	per of auto switches [mm]
			Number of auto switches		
Auto switch model	With 1 pc.	With	2 pcs.	With	n pcs.
	with t pc.	Different surfaces	Same surface	Different surfaces	Same surface
D-M9□	5	15 Note 1)	40 Note 1)	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6···)^{\text{Note 3}}$	55 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-M9□W	10	15 Note 1)	40 Note 1)	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \cdot \cdot \cdot)^{\text{Note } 3}$	55 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-M9□A	10	15 Note 1)	40 Note 1)	$25 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \cdots)^{\text{Note } 3)}$	60 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-A9□	5	15	30 Note 1)	$15 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \cdot \cdot \cdot)^{\text{Note } 3}$	50 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-M9□V	5	15 Note 1)	35	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6···)^{\text{Note 3}}$	35 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-A9□V	5	15	25	$15 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6···)^{\text{Note 3}}$	25 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-M9□WV D-M9□AV	10	15 Note 1)	35	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6···)^{\text{Note 3}}$	35 + 35 (n - 2) (n = 2, 3, 4, 5···)
D-C7□ D-C80	10	15	50	$15 + 45 \frac{(n-2)}{2}$ $(n = 2, 4, 6···)^{\text{Note 3}}$	50 + 45 (n - 2) (n = 2, 3, 4, 5···)
D-H7□ D-H7□W D-H7BA D-H7NF	10	15	60	$15 + 45 \frac{(n-2)}{2}$ $(n = 2, 4, 6\cdots)^{\text{Note } 3)}$	60 + 45 (n - 2) (n = 2, 3, 4, 5···)
D-H7C D-C73C D-C80C	10	15	65	$15 + 50 \frac{(n-2)}{2}$ $(n = 2, 4, 6)^{\text{Note 3}}$	65 + 50 (n - 2) (n = 2, 3, 4, 5···)
D-G5NT D-B5□/B64	10	15	75	$15 + 50 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \dots)^{\text{Note 3}}$	75 + 55 (n - 2) (n = 2, 3, 4, 5···)
D-B59W	15	20	75	$20 + 50 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \dots)^{\text{Note 3}})$	75 + 55 (n - 2) (n = 2, 3, 4, 5···)
D-G39A Note 4) D-K39A D-A3□A D-A44A	10	35	100	35 + 30 (n - 2) (n = 2, 3, 4, 5···)	100 + 100 (n - 2) (n = 2, 3, 4, 5···)

Note 3) When "n" is an odd number, an even number that is one larger than this odd number is used for the calculation.

Note 4) The D-A3□A/A44A/G39A/K39A cannot be mounted on the centralised piping type CDM2□P series.

Note 1) Auto switch mo	unting						
	With 2 auto switches						
	Different surfaces	Same surface					
Auto switch model	The proper auto switch mounting position is 3.5 mm inward from the switch holder edge.	The auto switch is mounted by slightly displacing it in a direction (cylinder tube circumferential exterior) so that the auto switch and lead wire do not interfere with each other.					
D-M9□(V) D-M9□W(V)	15 to 20 stroke Note 2)	40 to 55 stroke Note 2)					
D-M9□A(V)	15 to 25 stroke Note 2)	40 to 60 stroke Note 2)					
D-A9□(V)	_	30 to 50 stroke Note 2)					

Note 2) Minimum stroke for auto switch mounting in styles other than those in Note 1.

Direct Mount

With End Lock | Centralised Piping | Drest Mour, Morroling Roll Couble Acting, Single Roll Couble Acting, Single Roll COM2 P CM2RK

## **Operating Range**

				[mm]		
Auto switch model	Bore size					
Auto switch model	20	25	32	40		
D-A9□(V)	6	6	6	6		
D-M9□(V) D-M9□W(V) D-M9□A(V)	3	3	4	3.5		
D-C7□/C80 D-C73C/C80C	7	8	8	8		
D-B5□/B64 D-A3□A/A44A Note)	8	8	9	9		
D-B59W	12	12	13	13		
D-H7□/H7□W/H7BA D-G5NT/H7NF	4	4	4.5	5		
D-H7C	7	8.5	9	10		
D-G39A/K39A Note)	8	9	9	9		

\* Values which include hysteresis are for guideline purposes only, they are not a guarantee (assuming approximately ±30 % dispersion) and may change substantially depending on the ambient environment.

Note) The D-A3□A/A44A/G39A/K39A cannot be mounted on the centralised piping type CDM2□P series.

## Auto Switch Mounting Brackets/Part No.

	. Bore size [mm]					
Auto switch model	ø <b>20</b>	ø <b>25</b>	ø <b>32</b>	ø 40		
D-M9□(V) D-M9□W(V) D-A9□(V)	BM5-020 (A set of a, b, c, d)	BM5-025 (A set of a, b, c, d)	BM5-032 (A set of a, b, c, d)	BM5-040 (A set of a, b, c, d)		
<b>D-M9</b> □ <b>A(V)</b> Note 2)	BM5-020S (A set of b, c, d, e)	BM5-025S (A set of b, c, d, e)	BM5-032S (A set of b, c, d, e)	BM5-040S (A set of b, c, d, e)		
Switch bracket (Resin) Transparent (Nylon) Note 1)  White (PBT)  Switch holder (Zinc)  Auto switch  Auto switch mounting screw						
D-H7□ D-H7□W D-H7NF D-C7□/C80 D-C73C/C80C	BM2-020A (A set of band and screw)	BM2-025A (A set of band and screw)	BM2-032A (A set of band and screw)	BM2-040A (A set of band and screw)		
D-H7BA BM2-020AS BM2-025AS BM2-032. (A set of band and screw) (A set of band and screw) (A set of band and screw)				BM2-040AS (A set of band and screw)		
D-R50W		BA2-032 (A set of band and screw)	BA2-040 (A set of band and screw)			
D-A3  A/A44A Note 3)  D-G39A/K39A	BM3-020 (A set of band and screw)	BM3-025 (A set of band and screw)	BM3-032 (A set of band and screw)	BM3-040 (A set of band and screw)		

Note 1) Since the switch bracket (made from nylon) are affected in an environment where alcohol, chloroform, methylamines, hydrochloric acid or sulfuric acid is splashed over, so it cannot be used. Please contact SMC regarding other chemicals.

Note 2) As the indicator LED is projected from the switch unit, indicator LED may be damaged if the switch bracket is fixed on the indicator LED.

Note 3) The D-A3□A/A44A/G39A/K39A cannot be mounted on the centralized piping type CDM2□P series.

#### **Band Mounting Brackets Set Part No.**

Set part no.	Contents		
BM2-□□□A(S) * S: Stainless steel screw	<ul><li>Auto switch mounting band (c)</li><li>Auto switch mounting screw (d)</li></ul>		
BJ4-1	Switch bracket (White/PBT) (e) Switch holder (b)		
BJ5-1	Switch bracket (Transparent/Nylon) (a)     Switch holder (b)		

## Other than the applicable auto switches listed in "How to Order", the following auto switches are mountable.

Refer to the Auto Switch Guide for the detailed specifications.

Туре	Model	Electrical entry	Features
	D-H7A1, H7A2, H7B		_
Solid state	D-H7NW, H7PW, H7BW	Grommet (In-line)	Diagnostic indication (2-colour indication)
Solid state	D-H7BA	Grommer (m-ine)	Water resistant (2-colour indication)
	D-G5NT		With timer
Pood	D-B53, C73, C76	Grommet (In-line)	_
Reed	D-C80	Grommet (In-line)	Without indicator light

\* With pre-wired connector is also available for solid state auto switches. For details, refer to the Auto Switch Guide.


\* Normally closed (NC = b contact) solid state auto switches (D-F9G/F9H) are also available. For details, refer to the Auto Switch Guide.


ı

П

# Prior to Use Auto Switch Connection and Example


## Sink Input Specifications






## Source Input Specifications

3-wire, PNP






Connect according to the applicable PLC input specifications, as the connection method will vary depending on the PLC input specifications.


## **Example of AND (Series) and OR (Parallel) Connection**

st When using solid state auto switches, ensure the application is set up so the signals for the first 50 ms are invalid.


## 3-wire AND connection for NPN output (Using relays)




## (Performed with auto switches only)




## 3-wire OR connection for NPN output




## 3-wire AND connection for PNP output (Using relays)






## 3-wire OR connection for PNP output



## 2-wire AND connection



Example: Power supply is 24 VDC


When two auto switches are connected in series, a load may malfunction because the load voltage will decline when in the ON state.

The indicator lights will light up when both of the auto switches are in the ON state. Auto switches with load voltage less than 20 V cannot be used.

Load voltage at ON = Power supply voltage -Residual voltage x 2 pcs. = 24 V - 4 V x 2 pcs. = 16 V

Internal voltage drop in auto switch is 4 V.

## 2-wire OR connection



(Solid state)
When two auto
switches are
connected in parallel,
malfunction may occur
because the load
voltage will increase
when in the OFF state.

Load voltage at OFF = Leakage current x 2 pcs. x Load impedance = 1 mA x 2 pcs. x 3 k $\Omega$  = 6 V

Example: Load impedance is 3 k $\Omega$ . Leakage current from auto switch is 1 mA.

(Reed)
Because there is no current leakage, the load voltage will not increase when turned OFF.
However, depending on the number of auto switches in the ON state, the indicator lights may sometimes grow dim or not light up, due to the dispersion and reduction of the current flowing to the auto switches.



## Series CM2

# Simple Specials/Made to Order Please contact SMC for detailed specifications, delivery and prices. Made to Order

Double acting



Single acting

The following special specifications can be ordered as a simplified Made-to-Order.

There is a specification sheet available on paper and CD-ROM. Please contact your SMC sales representatives if necessary

	There is a specification sheet available on paper	and OB From: Frouse contact your own sales representatives if necessary.	•
Combal	Considirations	CM2 (Standard type)	

Single rod Double rod Single rod Rubber Rubber Rubber Air Air -XA0 to 30 Change of rod end shape


■ Mad	e to Order		•	'	'	
			CM2 (Standard type)			
Symbol	Specifications			e acting		Single acting
		Single Rubber	rod Air	Double Rubber	rod Air	Single rod Rubber
XB6	Heat resistant cylinder (–10 to 150 °C) Note 1)	•	•	•	•	
ХВ7	Cold resistant cylinder (-40 to 70 °C) Note 1)	•		<u> </u>	_	
XB9	Low speed cylinder (10 to 50 mm/s)	•				
XB12	External stainless steel cylinder Note 2)	<u> </u>		•		<u> </u>
XB13	Low speed cylinder (5 to 50 mm/s) Note 2)	•				
хсз	Special port location	•	•	•	•	•
XC4	With heavy duty scraper	•	•	•	-	
XC5	Heat resistant cylinder (-10 to 110 °C) Note 1)	•	•	•	•	
XC6	Made of stainless steel	•	•	•	•	•
XC8	Adjustable stroke cylinder/Adjustable extension type	•	•		_	
XC9	Adjustable stroke cylinder/Adjustable retraction type	•	•		-	
XC10	Dual stroke cylinder/Double rod type	•	_		-	
XC11	Dual stroke cylinder/Single rod type	•	•		_	
XC12	Tandem cylinder	•	_			
XC13	Auto switch rail mounting	•	•	•	•	•
XC20	Head cover axial port	•	•			•
XC22	Fluororubber seal	•	•	•	•	
XC25	No fixed throttle of connection port	•		•	_	•
XC27	Double clevis and double knuckle joint pins made of stainless steel	•	•			•
XC29	Double knuckle joint with spring pin	•	•	•	•	•
XC35	With coil scraper	•	_	•	_	
XC38	Vacuum specification (Rod through-hole)			•	-	
XC52	Mounting nut with set screw	•	•	•	•	•
XC85	Grease for food processing equipment	•	•	•	-	•
X446	PTFE grease	-	<b>-</b>	<u> </u>	-	
			-	-	-	-

Note 1) The products with an auto switch are not compatible.

Note 2) The shape is the same as the existing product.



## Simple Specials/Made to Order Series CM2





Double Acting, Double F.

Double Acting, Single Rod CM2K Non-rotating Rod Double Acting, Double Rod

o Acting, Spring ReturnExt

uble Acting, Single Rod Direct Mount

Direct Mount, Non-rotating Rod CM2RK Centralised Piping Single Ro Double Acting, S

With End Lock CBM2

**Auto Switch** 

Made to Order

# Series CM2 Simple Specials

These changes are dealt with Simple Specials System.

## 1 Change of Rod End Shape


-XA0 to XA30

## **Applicable Series**


Series		Action	Symbol for change of rod end shape	Note
	CM2	Double acting, Single rod	XA0 to 30	*1
Standard type	CIVIZ	Single acting (Spring return/extend)	XA0 to 30	*1
	CM2W	Double acting, Double rod	XA0 to 30	
	CM2K	Double acting, Single rod	XA0,1,6,10,11,13,14,17,19,21	*1
Non-rotating rod type	CIVIZK	Single acting (Spring return/extend)	XA0,1,6,10,11,13,14,17,19,21	*1
	CM2KW	Double acting, Double rod	XA0,1,6,10,11,13,14,17,19,21	*1
Direct mount type	CM2R	Double acting, Single rod	XA0 to 30	*2
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	XA0,1,6,10,11,13,14,17,19,21	*2
Standard type (Air-hydro type)	CM2H	Double acting, Single rod	XA0 to 30	
Standard type (All-flydro type)	CM2WH	Double acting, Double rod	XA0 to 30	
Centralised piping type	CM2□P	Double acting, Single rod	XA0 to 30	
With end lock	CBM2	Double acting, Single rod	XA0 to 30	

## **Precautions**

- SMC will make appropriate arrangements if no dimension, tolerance, or finish instructions are given in the diagram.
- Standard dimensions marked with "\*" will be as follows to the rod diameter (D). Enter any special dimension you desire.
- $D \le 6 \rightarrow D-1$  mm,  $6 < D \le 25 \rightarrow D-2$  mm,  $D > 25 \rightarrow D-4$  mm
- 3. In the case of double rod type and single acting retraction type, enter the dimensions when the rod is retracted.



## Simple Specials Series CM2



## Series CM2 **Made to Order**

Please contact SMC for detailed dimensions, specifications and lead times.



## Heat Resistant Cylinder (-10 to 150 °C)

**Symbol** -XB6

Air cylinder which changed the seal material and grease, so that it could be used even at higher temperature up to 150 from -10 °C.

Applicable Series

Description Mo		Action	Note	
Standard type	CM2	Double acting, Single rod	Except with auto switch	
Standard type	CM2W	Double acting, Double rod	Except with auto switch	
Non rotating rad type	CM2K	Double acting, Single rod	Except with auto switch	
Non-rotating rod type	CM2KW	Double acting, Double rod	Except with auto switch	
Direct mount type	CM2R	Double acting, Single rod	Except with auto switch	
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	Except with auto switch	
With end lock	CBM2	Double acting, Single rod	Except with auto switch	

Note 1) Operate without lubrication from a pneumatic system lubricator.

Note 2) Please contact SMC for details on the maintenance intervals for this cylinder, which differ from those of the standard cylinder.

Note 3) In principle, it is impossible to make built-in magnet type and the one with auto switch. But, as for the one with auto switch, and the heat resistant cylinder with heat resistant auto switch, please contact SMC. Note 4) Piston speed is ranged from 50 to 500 mm/s.

#### **Specifications**

Ambient temperature range	–10 °C to 150 °C	
Seal material	Fluororubber	
Grease	Heat resistant grease	
Auto switch	Not mountable Note)	
Dimensions	Same as standard type	
Specifications other than above	Same as standard type	

Note) Manufacturing built-in magnet type and the one with auto switch is impossible.

## **⚠** Warning **Precautions**

Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

## **How to Order**

Standard model no. XB6 Heat resistant cylinder

Cold Resistant Cylinder (-40 to 70 °C)

**Symbol** 

Air cylinder which changed the seal material and grease, so that it could be used even at lower temperature down to -40 °C.

Applicable Series

Description	Model	Action	Note	
Standard type	CM2	Double acting, Single rod	Except with air cushion and auto switch, rod end bracket, pivot bracket	
	CM2W	Double acting, Double rod	Except with air cushion and auto switch	
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion and auto switch, pivot bracket	

Note 1) Operate without lubrication from a pneumatic system lubricator.

Note 2) Use dry air which is suitable for heatless air dryer etc. not to cause the moisture to be frozen.

Note 3) Please contact SMC for details on the maintenance intervals for this cylinder, which differ from those of the standard cylinder.

Note 5) No cushion type is adopted. Piston speed is ranged from 50 to 500 mm/s.

## **Specifications**

Ambient temperature range	−40 °C to 70 °C
Seal material	Low nitrile rubber
Grease	Cold resistant grease
Auto switch Not mountable Note)	
Dimensions	Same as standard type
Specifications other than above	Same as standard type

Note) Manufacturing built-in magnet type and the one with auto switch is impossible.

## Note 4) Manufacturing built-in magnet type and mounting an auto switch are impossible.

## **How to Order**

Standard model no. Cold resistant cylinder

## ⚠Warning

#### **Precautions**

Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

## 3 Low Speed Cylinder (10 to 50 mm/s)

Symbol

Even if driving at lower speeds 10 to 50 mm/s, there would be no stick-slip phenomenon and it can run smoothly.

**Applicable Series** 

TPP:://dabio.com			
Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	Except air-hydro, with air cushion, with rod boot
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion
With end lock	CBM2	Double acting, Single rod	Except with air cushion

## How to Order

11011	to oraci	
	Standard model no.	- XB9
	Low speed cyli	inder •

#### **Specifications**

Piston speed	10 to 50 mm/s
Dimensions	Same as standard type
Specifications other than above	Same as standard type

Note) Operate without lubrication from a pneumatic system lubricator.

## **⚠** Warning

#### **Precautions**

Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.



## **External Stainless Steel Cylinder**

-XB12

A cylinder that uses stainless steel that excels in rust resistance for all external parts that are exposed to the surrounding environment. Its external dimensions and installation dimensions are identical to those of the standard Series CM2.

**Specifications** 

## Applicable Series

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	
	CIVIZ	Single acting (Spring return/extend)	
	CM2W	Double acting, Double rod	
Non rotating rad type	CM2K	Double acting, Single rod	
Non-rotating rod type	CIVIZK	Single acting (Spring return/extend)	

Material	External stainless steel 304		
Series	CM2, CM2K CM2W		
Cushion	Rubber bumper (Standard equipment)		
Mounting	Basic, Axial foot, Rod flange, Head flange, Integral clevis, Boss- cut/Basic, Boss-cut/Rod flange		
Specifications other than above and external dimensions	Same as standard type		

Note) With air cushion, built-in One-touch fitting type are not available.

## **How to Order**

Standard model no. **XB12** 

External stainless steel cylinder

## Mounting Bracket Part No.

Description	Bore size [mm]			
Description	20	25	32	40
Foot Note 1)	CM-L020B-XB12	CM-L03	2B-XB12	CM-L040B-XB12
Flange	CM-F020B-XB12	CM-F03	2B-XB12	CM-F040B-XB12
Mounting nut	SN-020BSUS	SN-032	SN-032BSUS	
Rod end nut	NT-02SUS	NT-03SUS		NT-04SUS
Single knuckle joint	I-020B-XB12	I-032B-XB12		I-040B-XB12
Double knuckle Note 2) joint	Y-020B-XB12	Y-032B-XB12		Y-040B-XB12
Pin for double Note 3) knuckle joint	CDP-1-XC27		CDP-3-XC27	

Note 1) The minimum order quantity includes 2 foot brackets and 1 mounting nut. Order 2 pcs. per cylinder.

Note 2) With pin, retaining rings

Note 3) With retaining rings (split pins for ø 40)

## Symbol -XB13

Even if driving at lower speeds 5 to 50 mm/s (CY: 7 to 50 mm/s), there would be no stick-slip phenomenon and it can run smoothly.

## **Applicable Series**

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	Except with air cushion
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion

Low Speed Cylinder (5 to 50 mm/s)

#### **How to Order**

Standard model no. **XB13** Low speed cylinder

## **Specifications**

Piston speed	5 to 50 mm/s (CY: 7 to 50 mm/s)
Dimensions	Same as standard type
Additional specifications	Same as standard type

Note 1) Operate without lubrication from a pneumatic system lubricator. Note 2) For the speed adjustment, use speed controllers for controlling at lower speeds. (Series AS-FM/AS-M)



Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

Symbol

-XC3

**Symbol** 


-XC4


Compared with the standard type, a cylinder which changes the connection port location of rod/head cover and the location of cushion valve.

#### **Applicable Series**

the bureaution of			
Description	Model	Action	Note
	0140	Double acting, Single rod	
Standard type	CM2	Single acting (Spring return/extend)	
	CM2W	Double acting, Double rod	
Air-hydro type	CM2H	Double acting, Single rod	
	CM2K	Double acting, Single rod	
Non-rotating rod type	CIVIZK	Single acting (Spring return/extend)	
	CM2KW	Double acting, Double rod	
Direct mount type	CM2R	Double acting, Single rod	
Direct mount type, Air-hydro type	CM2RH	Double acting, Single rod	
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	
With end lock	CBM2	Double acting, Single rod	Except with air cushion

## **How to Order**





## Specifications: Same as standard type

#### **Port Location**

I OIL E	Joacion			
Series	Corresponding symbol of mounting bracket (Positional relationships)			
CM2	* Viewed from the rod side, the ports are rendered A, B, C, and D, in the clockwise direction.	<positional and="" between="" clevis="" port="" relationship=""> * Viewed from the rod side, with the clevis positioned as shown in the diagram, the ports are rendered A, B, C, and D, in the clockwise direction.  * Port  * D  * D  * D  * D  * D  * D  * D  *</positional>		
	Positional relationships between port and cushion valve cannot be changed.			

## Relationship between Port Location and Cushion Valve Location

Series	Corresponding symbol of mounting bracket (Positional relationships)
	Port location Rod side port and head side port are at the same location. Symbols of lock position and port location are as the following diagrams.  Port  End lock Standard (AD) AC AB
СВМ2	Clevis and trunnion types are based on the direction of clevis bracket.  AD CD BD  Standard (BA) CA DA
	Diagrams viewed from the rod side

## 7 With Heavy Duty Scraper

It is suitable for using cylinders under the environment, where there are much dusts in a surrounding area by using a heavy duty scraper on the wiper ring, or using cylinders under earth and sand exposed to the die-casted equipment, construction machinery, or industrial vehicles.

## Applicable Series

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	
	CM2W	Double acting, Double rod	
Centralised piping type	CM2□P	Double acting, Single rod	
With end lock	CBM2	Double acting, Single rod	Head end lock only (except with air cushion)

## **How to Order**




## Specifications: Same as standard type


\* The D-A3□A/A44A/G39A/K39A/B54/B64 cannot be mounted on bore sizes Ø 20 and Ø 25 cylinder with air cushion.

## **⚠** Caution

Either heavy duty scraper or rod seal cannot be replaced.

## Construction (Dimensions are the same as standard.)







# 8 Heat Resistant Cylinder (-10 to 110 °C)

Symbol -XC5

Cylinder which changed the seal material for heat resistance (up to 110 °C) in order to use under the severe ambient temperature condition which exceeds the standard specifications of -10 to 70 °C.

**Applicable Series** 

Description	Model	Action	Note
Chandaud huna	CM2	Double acting, Single rod	
Standard type	CM2W	Double acting, Double rod	
Direct mount type CM2R		Double acting, Single rod	

# Specifications

Ambient temperature range	–10 °C to 110 °C
Seal material	Fluororubber
Auto switch	Not mountable Note 2)
Specifications other than above and external dimensions	Same as standard type

Note 1) Please contact SMC for details on the maintenance intervals for this cylinder, which differ from those of the standard cylinder.

Note 2) Manufacturing built-in magnet type and the one with auto switch is impossible. Note 3) Material of rod boot is heat resistant tarpaulin.

Symbol -XC6

#### **How to Order**

Standard model no. – XC5

Heat resistant cylinder

# 9 Made of Stainless Steel

Suitable for the cases it is likely to generate rust by being immersed in the water and corrosion.

# **Applicable Series**

Applicable collec					
Description	Model	Action	Note		
	CM2	Double acting, Single rod			
Standard type	CIVIZ	Single acting (Spring return/extend)			
	CM2W	Double acting, Double rod			
	CM2K	Double acting, Single rod			
Direct mount type	CIVIZK	Single acting (Spring return/extend)			
	CM2KW Double acting, Double rod				
Direct mount type	CM2R	Double acting, Single rod			
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod			
Centralised piping type	CM2□P	Double acting, Single rod			
With end lock	CBM2	Double acting, Single rod			

#### **How to Order**

Standard model no. – XC6

Made of stainless steel

### **Specifications**

Parts changed to stainless steel	Piston rod, Rod end nut
Specifications other than above and external dimensions	Same as standard type

Symbol -XC8

# 10 Adjustable Stroke Cylinder/Adjustable Extension Type

It adjusts the extending stroke by the stroke adjustable mechanism equipped in the head side. (After the stroke is adjusted, with cushion on both sides is altered to single-sided, with cushion.)


#### **Applicable Series**

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	
Non-rotating rod type	CM2K	Double acting, Single rod	
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	
With end lock	CBM2	Double acting	Except clevis type. Head end lock only, except with air cushion

#### Specifications

- poomounomo		
Stroke adjustment symbol	Α	В
Stroke adjustment range [mm]	0 to 25	0 to 50
Specifications other than above	Same as standard type	

#### **How to Order**



**≜**Warning

Precautions

 When the cylinder is operating, if something gets caught between the stopper bracket for adjusting the stroke and the cylinder body, it could cause bodily injury or damage the peripheral equipment. Therefore, take preventive measures as necessary, such as installing a protective cover. 2. To adjust the stroke, make sure to secure the wrench flats of the stopper bracket by a wrench etc. before loosening the lock nut. If the lock nut is loosened without securing the stopper bracket, be aware that the area that joins the load to the piston rod or the area in which the piston rod is joined with the load side and the stopper bracket side could loosen first. It may cause an accident or malfunction.

Α

В


Symbol Stroke adjustment range

0 to 25 mm

0 to 50 mm

# Dimensions (Dimensions other than below are the same as standard type.)

Stroke adjustment mechanism



										[mm]
Bore size	Вз	Нз	MA	МІ	МК	MM <sub>2</sub>	МТ	МН	ML	ZZ
20	10	3.6	12	14	7	M6 x 1	16.5	47	18	150
25	13	5	17	20	9	M8 x 1.25	17.5	49	18	156
32	13	5	17	20	9	M8 x 1.25	17.5	49	18	158
40	17	6	19	25	10	M10 x 1.25	21.5	60	24	198

11 Adjustable Stroke Cylinder/Adjustable Retraction Type

Symbol

-XC9

The retracting stroke of the cylinder can be adjusted by the adjustment bolt.

#### **Applicable Series**

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	
Non-rotating rod type	CM2K	Double acting, Single rod	Except with air cushion
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	

#### **Specifications**

Stroke adjustment symbol	А	В
Stroke adjustment range [mm]	0 to 25	0 to 50
Specifications other than above	Same as st	andard type

#### **How to Order**

CM2K CM2K CM2R CM2RK

Mounting style

Bore size

Stroke Ro

Adjustment bolt

Rod end thread Z -

Pivot bracket

Rod end bracket

Auto switch

- XC9 A

Adjustable stroke cylinder/Adjustable retraction type


### Stroke adjustment symbol

Symbol	Stroke adjustment range
Α	0 to 25 mm
В	0 to 50 mm

# **⚠** Caution Precautions

- When air is supplied to the cylinder, if the stroke adjustment bolt is loosened in excess of the allowable stroke adjustment amount, be aware that the stroke adjustment bolt could fly out or air could be discharged, which could injure personnel or damage the peripheral equipment.
- Adjust the stroke when the cylinder is not pressurised.If it is adjusted in the pressurised state, the seal of the adjustment section could become deformed, leading to air leakage.

### **Dimensions** (Dimensions other than below are the same as standard type.)



			[mm]
Bore size	ВМ	MH	ZZ
20	M10 x 1.25	26.5	142.5
25	M14 x 1.5	29	149
32	M14 x 1.5	29	151
40	M16 x 1.5	32	186

# 12 Dual Stroke Cylinder/Double Rod Type

Symbol -XC10

Two cylinders are constructed as one cylinder in a back-to-back configuration allowing the cylinder stroke to be controlled in three steps.

#### **Applicable Series**


Description	Model	Action	Note
Standard type	CM2	0,	Except with air cushion and auto switch, rod end bracket, pivot bracket
Non-rotating rod type	CM2K	Double acting, Single rod	Except with air cushion and auto switch, rod end bracket, pivot bracket

#### **Specifications**

Maximum manufacturable stroke [mm]	1000
Specifications other than above	Same as standard type

#### **How to Order**





- Stroke A


+ Stroke B

Z - XC10

Dual stroke cylinder/Double rod type


# Function

109



When air pressure is supplied to ports **3** and **3**, both strokes A and B retract.


When air pressure is supplied to ports **3** and **6**, A out strokes.



When air pressure is supplied to ports **4** and **9**, B out strokes.

When air pressure is supplied to ports (a) and (b), both strokes A and B out strokes.

# Dimensions (Dimensions other than below are the same as standard type.)



					[mm]
Bore size	GC	GD	SA	SB	ZZ
20	7	24	47	78	207
25	7	24	47	78	215
32	7	24	49	80	219
40	10.5	33.5	66.5	110.5	277

# 13 Dual Stroke Cylinder/Single Rod Type

Symbol -XC11

Two cylinders can be integrated by connecting them in line, and the cylinder stroke can be controlled in two stages in both directions.

### **Applicable Series**

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	
Non-rotating rod type	CM2K	Double acting, Single rod	Except with air cushion
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	

### Specifications:

# Same as standard type


- Please contact SMC for each manufacturable stroke length.
- \* The D-A3□A/A44A/G39A/K39A/ B54/B64 cannot be mounted on bore sizes Ø 20 and Ø 25 cylinder with air cushion.



#### **How to Order**




**Dimensions** (Dimensions other than below are the same as standard type.)



			[mm]
Bore size	SA	SB	ZZ
20	48	62	164
25	48	62	168
32	50	64	172
40	67.5	88.5	222

### Functional description of dual stroke cylinder




- Initial state
   (0 stroke position)
- Stroke B-A

  B

  C


  Stroke A
- 2) 1st stage
  (Stroke A operation)
  When the air pressure is supplied from the port, the rod operates the stroke A.
- 3) 2nd stage (Stroke B-A operation) Following the 1st stage, when the air pressure is supplied from the port, the rod operates the stroke B-A.
- Stroke B Stroke A
- 4) Cylinder retraction When the air pressure is supplied from the ③ port, the rod retracts completely.

### Double output is possible.



- Initial state
   (0 stroke position)
- W Stroke A
  - 2) Double output
    When the air pressure is supplied to the
    and ports at the same time, the double output can be obtained in the stroke A range.

# Stroke A or Stroke B operation can be made individually.



# **⚠** Caution Precautions

- Do not supply air until the cylinder is fixed with the attached bolt.
- 2. If air is supplied without securing the cylinder, the cylinder could lurch, posing the risk of bodily injury or damage to the peripheral equipment.

14 Tandem Cylinder

Symbol

-XC12

This is a cylinder produced with two air cylinders in line allowing double the output force.

#### **Applicable Series**


Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	Except with air cushion


#### **How to Order**



Tandem cylinder


# Specifications: Same as standard type





When air pressure is supplied to ports **a** and **6**, the output force is doubled in the out stroke.

# Dimensions (Dimensions other than below are the same as standard type.)



			[mm]
Bore size	SA	SB	ZZ
20	48	62	164
25	48	62	168
32	50	64	172
40	67.5	88.5	222

# 15 Auto Switch Rail Mounting

Symbol -XC13

A cylinder on which a rail is mounted to enable auto switches, in addition to the standard method for mounting auto switches (Band mounting type).


### **Applicable Series**

Applicable Series					
Description	Model	Action	Note		
	CM2	Double acting, Single rod			
Standard type	CIVIZ	Single acting (Spring return/extend)			
	CM2W	Double acting, Double rod			
	CM2K	Double acting, Single rod			
Non-rotating rod type	CIVIZK	Single acting (Spring return/extend)			
	CM2KW	Double acting, Double rod			
Direct mount type	CM2R	Double acting, Single rod			
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod			
With end lock	СВМ2	Double acting, Single rod	Except with air cushion For XC13A and XC13C only		

#### **How to Order**

Standard model no XC13						
Rail mounting direction						
	XC13A Mounted on the right side when viewed from the rod with the ports facing upward.					
	XC13B	Mounted on the left side when viewed from the rod.				
	XC13C	Mounted on the underside when viewed from the rod.				





### **CDM2 Applicable Auto Switches**

Rail mounting	Solid state	D-F7□, D-F7□V, D-F7BA, D-F79F, D-F79W, D-F7□WV, D-J79, D-J79C, D-J79W			
type	Reed	D-A9□/A9□V, D-A7/A8, D-A7□H/A80H, D-A73C/A80C, D-A79W			
Auto switch specifications		For detailed specifications about an auto switch for itself, refer to the Auto Switch Guide.			



[mm]

D-A79W

Hs

25

28


31.5


35.5

# 16 Auto Switch Rail Mounting

Symbol -XC13

# Auto Switch Proper Mounting Position (Detection at stroke end) and Its Mounting Height





D-F7□/F79F D-J79/F7NT

D-F7 W/J79W

D-A9□/A9□V A7□H/A80H

23.5

26.5

30

34

D-F7BA

**Auto Switch Proper Mounting Position (Detection at stroke end)** 

Auto switch model	D-013/0130	: '9W/F7□WV BAV H/A80H	D-F7NT		D-A9□ D-A9□V D-A79W		D-A7□ D-A80	
Bore size	Α	В	Α	В	Α	В	Α	В
20	8.5	7	13.5	12	5.5	4	8	6.5
25	7.5	7.5	12.5	12.5	4.5	4.5	7	7
32	9	8	14	13	6	5	8.5	7.5
40	15	13	20	18	12	10	14.5	12.5

Note) Adjust the auto switch after confirming the operating conditions in the actual setting.

# **Minimum Stroke for Auto Switch Mounting**

			[mm]			
		No. of auto switch mounted				
Auto switch model	With 1 pc.	With 2 pcs. Same surface	With n pcs. (n: No. of auto switches) Same surface			
D-F7□V D-J79C	5	5	10 + 10 (n - 2) (n = 4, 6) <sup>Note)</sup>			
D-F7□ D-J79	5	5	15 + 15 (n - 2) (n = 4, 6) Note)			
D-F7□WV D-F7BAV D-A79W	10	15	10 + 15 (n - 2) (n = 4, 6) Note)			
D-F7□W/J79W D-F7BA D-F79F/F7NT	10	15	15 + 20 (n - 2) (n = 4, 6) Note)			
D-A9□ D-A9□V	5	10	10 + 15 (n - 2) (n = 4, 6) <sup>Note)</sup>			
D-A7□/A80 D-A7□H/A80H D-A73C/A80C	5	10	15 + 10 (n - 2) (n = 4, 6) Note)			
D-A7□H D-A80H	5	10	15 + 15 (n – 2) (n = 4, 6) <sup>Note)</sup>			

Note) When "n" is an odd number, an even number that is one larger than this odd number is used for the calculation. However, the minimum even number is 4. So, 4 is used for the calculation when "n" is 1 to 3.

# Auto Switch Mounting Brackets/Part No.

A. da accidada una dal	Bore size [mm]
Auto switch model	ø <b>20</b> to ø <b>40</b>
D-A9□/A9□V	BQ2-012

Note 1) When adding D-A9 $\square$ (V), order a set of auto switch mounting brackets BQ-1 and BQ2-012 for the CDQ2 series (ø 12 to ø 25) separately.

When adding the auto switches other than D-A9 $\square$ (V) and D-F7BA(V) mentioned on the above, order auto switch mounting brackets BQ-1 separately.

**多SMC** 

Note 2) When adding the auto switch D-F7BA(V), order a stainless steel screw set BBA2 separately.

**Auto Switch Mounting Height** 

D-F7□V

D-F7□WV

D-F7BAV

Hs

26

29

32 5

36.5

D-J79C

Hs

29

32

35.5

39.5

				[mm]		
Auto switch model		Bore size				
Auto switch model	20	25	32	40		
D-F7□/F79F/F7□V D-J79/J79C D-F7□W/J79W/F7□WV D-F7BA/F7BAV D-F7NTL	3.5	3.5	4	3.5		
D-A9□/D-A9□V	5.5	6	6.5	6.5		
D-A7□/A80 D-A7□H/A80H D-A73C/A80C	7.5	8	8.5	8.5		
D-A79W	10	10.5	12.5	12.5		

D-A7□

D-A80

Hs

22.5

25.5

29

33

D-A73C

D-A80C

Hs

29.5

32.5

35

40

\* Values which include hysteresis are for guideline purposes only, they are not a guarantee (assuming approximately ±30 % dispersion) and may change substantially depending on the ambient environment.

# **Operating Range**

Symbol

-XC20

# 17 Head Cover Axial Port

Head side port position is changed to the axial direction.

### **Applicable Series**

Description	Model	Action	Note
0	CM2	Double acting, Single rod	
Standard type	CIVIZ	Single acting (Spring return/extend)	
	CM2K	Double acting, Single rod	
Non-rotating rod type		Single acting (Spring return/extend)	
Direct mount type	CM2R	Double acting, Single rod	Except with air cushion
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	


# Specifications: Same as standard type

#### **How to Order**

Standard model no. – XC20

Head cover axial port

# Construction



Bore size [mm]	Port size
20, 25, 32	Rc1/8
40	Rc1/4

\* Same dimensions as standard type except port size.

# 18 Fluororubber Seal

Symbol -XC22

### **Applicable Series**

Description Model		Action	Note
Ot a seal a seal to sea a	CM2	Double acting, Single rod	
Standard type	CM2W	Double acting, Double rod	
Non-rotating rod type	CM2K	Double acting, Single rod	
	CM2KW	Double acting, Double rod	
Direct mount type	CM2R	Double acting, Single rod	
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	
With end lock	CBM2	Double acting, Single rod	

### **How to Order**



# **Specifications**

Seal material	Fluororubber		
Ambient temperature range	With auto switch $^{Note1}$ : $-10$ °C to 60 °C (No freezing Without auto switch : $-10$ °C to 70 °C (No freezing		
Specifications other than above and external dimensions	Same as standard type		

Note 1) Please contact SMC, as the type of chemical and the operating temperature may not allow the use of this product.

Note 2) Cylinders with auto switches can also be produced; however, auto switch related parts (auto switch units, mounting brackets, built-in magnets) are the same as standard products.

Before using these, please contact SMC regarding their suitability for the operating environment.

# 19 No Fixed Throttle of Connection Port

Symbol -XC25

Type with no restrictor on the port, since it's using air-hydro type on the rod cover and the head cover of air cylinder CM2 series.

#### **Applicable Series**

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	
	CIVIZ	Single acting (Spring return/extend)	
	CM2W	Double acting, Double rod	
	CM2K	Double acting, Single rod	
Non-rotating rod type		Single acting (Spring return/extend)	
	CM2KW	Double acting, Double rod	
Direct mount type	CM2R	Double acting, Single rod	
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	·

\* Standard equipment for with air cushion


# How to Order

Standard model no. – XC25

No fixed throttle of connection port

## Specifications: Same as standard type

# Construction (Dimensions are the same as standard.)



# **⚠** Caution

1. Use a shock absorber etc.

When the piston speed exceeds 750 mm/s, make sure that direct impact does not apply on the cylinder cover by using an external stopper (shock absorber etc).

Symbol -XC27

# Double Clevis and Double Knuckle Joint Pins Made of Stainless Steel

To prevent the oscillating portion of the double clevis or the double knuckle joint from rusting, the material of the pin and the retaining ring is changed to stainless steel.

### **Applicable Series**

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	Except rod end bracket
Standard type	CIVIZ	Single acting (Spring return/extend)	Except rod end bracket
Non-rotating rod type	CM2K	Double acting, Single rod	Except rod end bracket
Non-rotating rod type		Single acting (Spring return/extend)	
With end lock	CBM2	Double acting, Single rod	

# **Specifications**

Mounting	Only double clevis type (D), double knuckle joint			
Pin and retaining ring material	Stainless steel 304			
Specifications other than above	Same as standard type			

#### **How to Order** CM<sub>2</sub>D CM2□D Standard model no. - XC27 CBM2D Double clevis pin made of stainless steel Double clevis type 020B, 032B, 040B **XC27** Double knuckle joint Double knuckle joint pin made of stainless steel CDP -1, 2 - XC27 Clevis pin Clevis pin made of stainless steel

Knuckle pin

Symbol -XC29

# 21 Double Knuckle Joint with Spring Pin

To prevent loosening of the double knuckle joint of standard air cylinder (Series CM2/CA2)

## **Applicable Series**

Applicable of	CIICS		
Description	Model	Action	Note
	CM2	Double acting, Single rod	Except rod end bracket
Standard type	CIVIZ	Single acting (Spring return/extend)	Except rod end bracket
	CM2W	Double acting, Double rod	Except rod end bracket
Direct mount type	CM2R	Double acting, Single rod	Except rod end bracket
Centralised piping type	CM2□P	Double acting, Single rod	
With end lock	CBM2	Double acting, Single rod	·

### How to Order


Knuckle pin

Standard model no. – XC29

Double knuckle joint with spring pin

Specifications: Same as standard type

# Dimensions: For mounting bracket, pin is shipped together. (Dimensions other than below are the same as standard type.)



		_
10		E
1	2)	-
		-

								[mm]
Bore size	Н	L <sub>1</sub>	ND <sub>H10</sub>	NZ	R	Z	ZZ	Spring pin
20	41	36	9+0.058	18	10	61	146	ø 3 x 16 L
25	45	38	9+0.058	18	10	65	150	ø 3 x 16 L
32	45	38	9+0.058	18	10	65	152	ø 3 x 16 L
40	50	55	12+0.070	38	13	83	200	ø 4 x 24 L

22 With Coil Scraper

Symbol

-XC35

It gets rid of frost, ice, weld spatter, cutting chips adhered to the piston rod, and protects the seals etc.

**Applicable Series** 

Description	Model	Action	Note
Standard type	CM2	Double acting, Single rod	Except with air cushion
	CM2W	Double acting, Double rod	Except with air cushion
With end lock	CBM2	Double acting, Single rod	Head end lock only (except with air cushion)

**How to Order** 

Standard model no. – XC35

With coil scraper

Specifications: Same as standard type

23 Vacuum (Rod through-hole)


Symbol -XC38

Through-hole of hollow rod can be used as the passage of vacuum air.

**Applicable Series** 

Description	Model	Action	Note		
Standard type	CM2W	Double acting, Double rod	Except rod end bracket		

# **How to Order**




Vacuum (Rod through-hole)



Specifications: Same as standard type

# Construction/Dimensions (Other dimensions are the same as standard.)



				[mm]
Bore size	d	J	HA	ZZ
20	3	M5 x 0.8	32	135
25	3	M5 x 0.8	32	139
32	3	M5 x 0.8	32	141
40	4	Rc1/8	36	174

# 24 Mounting Nut with Set Screw

Symbol -XC52

In order to prevent the mounting nut from being loosen, set screw should be tighten from the two directions to fix the mounting nut.

**Applicable Series** 

Description	Model	Action	Note
	CM2	Double acting, Single rod	
Standard type	CIVIZ	Single acting (Spring return/extend)	
	CM2W	Double acting, Double rod	
	CM2K	Double acting, Single rod	
Non-rotating rod type		Single acting (Spring return/extend)	
Tod type	CM2KW	Double acting, Double rod	
Centralised piping type	CM2□P	Double acting, Single rod	
With end lock	CBM2	Double acting, Single rod	


**How to Order** 

Standard model no. – XC52

Mounting nut with set screw

Specifications: Same as standard type

### Dimensions (Dimensions other than below are the same as standard type.)



# 25 Grease for Food Processing Equipment

Food grade grease (certified by NSF-H1) is used as lubricant.

**Applicable Series** 

Description	Model	Action	Note
	CM2	Double acting, Single rod	
Standard type	CIVIZ	Single acting (Spring return/extend)	
	CM2W	Double acting, Double rod	
Non-rotating rod type	CM2K	Double acting, Single rod	
	CIVIZK	Single acting (Spring return/extend)	
	CM2KW	Double acting, Double rod	
Direct mount type	CM2R	Double acting, Single rod	
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	
Centralised piping type	CM2□P	Double acting, Single rod	

#### **How to Order**

Standard model no. – XC85

Grease for food processing equipment

# **∆**Warning

### **Precautions**

Be aware that smoking cigarettes etc after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

#### Not installable zone

Food zone.....An environment where the raw materials and materials of food products, semi-finished food products and food products that make direct or indirect contact in a normal processing process.

Splash zone...An area where a portion of food products accidentally splash and stick under the intended operating conditions. An environment where food products that enter this area do not return to the food product contact portion again, and are not used as food products.


#### Installable zone

Non-food zone...Other environments including the food splash zone, except for the food contact portions.

- Note 1) Avoid using this product in the food zone. (Refer to the figure on the right.) Note 2) When the product is used in an area of liquid splash, or a water re-
- sistant function is required for the product, please consult with SMC. Note 3) Operate without lubrication from a pneumatic system lubricator.
- Note 4) Use the following grease pack for the maintenance work. GR-H-010 (Grease: 10 g)
- Note 5) Please contact SMC for details about the maintenance intervals for this cylinder, which differ from those of the standard cylinder.

# **Specifications**

Ambient temperature range	–10 °C to 70 °C		
Seal material	Nitrile rubber Grease for food processing equipment		
Grease			
Auto switch	Mountable		
Dimensions	Same as standard type		
Specifications other than above	Same as standard type		



26 PTFE Grease

Symbol -X446

### **Applicable Series**

Description	Model	Action	Note
04	CM2	Double acting, Single rod	
Standard type	CM2W	Double acting, Double rod	
Non-rotating	CM2K	Double acting, Single rod	
rod type	CM2KW	Double acting, Double rod	
Direct mount type	CM2R	Double acting, Single rod	
Direct mount, Non-rotating rod type	CM2RK	Double acting, Single rod	

### **How to Order**



# Specifications: Same as standard type

# Dimensions: Same as standard type

 $\ast$  When grease is necessary for maintenance, grease pack is available, please order it separately. GR-F-005 (Grease: 5 g)

# **⚠ Warning** Precautions

Be aware that smoking cigarettes etc after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

# **⚠ Safety Instructions**

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

Caution indicates a hazard with a low level of risk

which, if not avoided, could result in minor or moderate injury.

-----

injury

**Warning:** Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

⚠ Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

\*1) ISO 4414: Pneumatic fluid power – General rules relating to systems. ISO 4413: Hydraulic fluid power – General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements) ISO 10218-1: Manipulating industrial robots - Safety.

# **⚠** Warning

 The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
  - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
  - Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
  - An application which could have negative effects on people, property, or animals requiring special safety analysis.
  - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

# Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### **Limited warranty and Disclaimer**

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, wichever is first.\*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
  - \*2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited

#### **Compliance Requirements**

- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

# **↑** Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

# **⚠** Caution

 $\ensuremath{\mathsf{SMC}}$  products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

### SMC Corporation (Europe)

ome corporation (Laropo)								
	Austria	<b>2</b> +43 (0)2262622800	www.smc.at	office@smc.at	Lithuania	<b>☎</b> +370 5 2308118	www.smclt.lt	info@smclt.lt
	Belgium	<b>*</b> +32 (0)33551464	www.smcpneumatics.be	info@smcpneumatics.be	Netherlands	<b>2</b> +31 (0)205318888	www.smcpneumatics.nl	info@smcpneumatics.nl
	Bulgaria	<b>2</b> +359 (0)2807670	www.smc.bg	office@smc.bg	Norway	<b>2</b> +47 67129020	www.smc-norge.no	post@smc-norge.no
	Croatia	<b>*</b> +385 (0)13707288	www.smc.hr	office@smc.hr	Poland	<b>2</b> +48 222119600	www.smc.pl	office@smc.pl
	Czech Republic	<b>*</b> +420 541424611	www.smc.cz	office@smc.cz	Portugal	<b>*</b> +351 226166570	www.smc.eu	postpt@smc.smces.es
	Denmark	<b>2</b> +45 70252900	www.smcdk.com	smc@smcdk.com	Romania	<b>2</b> +40 213205111	www.smcromania.ro	smcromania@smcromania.ro
	Estonia	<b>*</b> +372 6510370	www.smcpneumatics.ee	smc@smcpneumatics.ee	Russia	<b>*</b> +7 8127185445	www.smc-pneumatik.ru	info@smc-pneumatik.ru
	Finland	<b>2</b> +358 207513513	www.smc.fi	smcfi@smc.fi	Slovakia	<b>2</b> +421 (0)413213212	www.smc.sk	office@smc.sk
	France	<b>2</b> +33 (0)164761000	www.smc-france.fr	promotion@smc-france.fr	Slovenia	<b>*</b> +386 (0)73885412	www.smc.si	office@smc.si
	Germany	<b>2</b> +49 (0)61034020	www.smc.de	info@smc.de	Spain	<b>*</b> +34 902184100	www.smc.eu	post@smc.smces.es
	Greece	<b>2</b> +30 210 2717265	www.smchellas.gr	sales@smchellas.gr	Sweden	<b>2</b> +46 (0)86031200	www.smc.nu	post@smc.nu
	Hungary	<b>*</b> +36 23511390	www.smc.hu	office@smc.hu	Switzerland	<b>*</b> +41 (0)523963131	www.smc.ch	info@smc.ch
	Ireland	<b>2</b> +353 (0)14039000	www.smcpneumatics.ie	sales@smcpneumatics.ie	Turkey	<b>2</b> +90 212 489 0 440	www.smcpnomatik.com.tr	info@smcpnomatik.com.tr
	Italy	<b>2</b> +39 0292711	www.smcitalia.it	mailbox@smcitalia.it	UK	<b>*</b> +44 (0)845 121 5122	www.smcpneumatics.co.uk	sales@smcpneumatics.co.uk
	Latvia	<b>2</b> +371 67817700	www.smclv.lv	info@smclv.lv				