# Safety Relay Modules
## PROTECT SRB series

SCHMERSAL

## PROTECT -SRB's:
## The new generation of multifunctional safety relay modules

To provide new functions and to continue with well tried and tested features: this is the SCHMERSAL Group's aim for its new generation of innovative PROTECT SRB series of safety relay modules.

- It's now easier to install safety-related parts of control systems even more simply and quickly.
- An increased availability of machine controls is achieved by additional functions and features.

The many years of experience within the SCHMERSAL Group companies Elan/ Wettenberg, Steute/Löhne and K.A. Schmersal/Wuppertal are reflected in this new development through a special combination of design and functional advantages.

PROTECT SRBs have been used successfully since 2001. An extended range (status: beginning of 2002) now takes the following shape:

- **Multifunctional versions in housings with an installed width of 45 mm**
- **Standard versions with additional features in housings of 22.5 mm installed width**
- **Two-hand modules in housings of 22.5 mm installed width.**

## Examples of the type of protective devices which can be connected

**Safety switches**

**Safety switches with guard locking**

**Position switches with safety function**

**Pull-wire emergency switches**

**Two-hand operating panels**



**Safety switches for rotating protective devices**

# PROTECT -SRB's: Common features

The circuitry of all **PROTECT** SRB safety relay modules complies with the control category 4 to EN 954-1 (BG prototype testing in preparation or applied for).

Apart from a few exceptions, all versions have the special feature of a "hybrid" fuse.



**Hybridsicherung: Maßstab 4:1**

Unlike a glass fuse, if a hybrid fuse is used the function can be restored following a short-circuit without accessing the hardware. However, this is not automatic as is the case with commercially available electronic fuses but only once the supply voltage has been interrupted and then switched on again. This reset thus avoids the danger of an unexpected restart in the operating mode of "automatic operation" following the rectification of a short-circuit.

Another common feature of all **PROTECT** SRB modules is the new housing design which offers the following advantages to the user from the outset irrespective of the chosen circuitry:

① Plug-in terminals so that pre-assembled cable harnesses can be used and the unit can be serviced quicker (SRB 301LC on request).




② Looping through of the supply voltage without additional wiring in the case of several adjacent modules by the push-out current transfer knife contacts assuming this task.

③ EN 292 compliant, front accessible adjustment which is protected from tampering by a cover.

④ Snap-on item designations

⑤ Air vents in the new housings for applications under even higher operating temperatures.

**Additional services**

There is a CD ROM in the envelope at the back of this catalogue as a special customer service with the aid of which a complete connection diagram can be drawn up from the different functionalities (refer to page 15).


**Safety laser scanner**

**Magnet safety sensors**

**Safety light grids**



**Foot switches with safety function**



**Tactile protective devices**

**EMERGENCY STOP pushbuttons**

# PROTECT-SRB's: Multifunctional versions

Multifunctionality is reflected in the module developments SRB 308IT and SRB 219IT (for data sheet refer to page 10 and 12 respectively) and refers in particular to additional options concerning:

- Diagnosis and visualisation
- Potential uses
- Circuitry.

**Increased availability of machines and controls**
The broad and easy to handle diagnostic features are the prime economic advantages of these modules. These relate both to the relay circuitry itself and the connected periphery.

Nearly every status in the safety circuit can be incorporated into the trouble-shooting management part of a machine control via terminals specially provided for this task.

- Fewer diagnostic contacts in the form of additional PLC feedback signals from the sensor/actuator level are required.
- No additional bus interfaces.
- The need to interpret LED function displays also loses importance.

**Universal possibilities of use**
All commercially available protective devices with an electro-mechanical principle of operation can be connected to the SRB modules 308IT and 219IT, e.g. emergency stop control devices, interlocking devices with or without locking, contact mats and similar, but also




| Signalling outputs ... | Operating voltage not applied | Operating voltage applied, guard open, feed-back loop closed | Operating voltage applied, guard closed, feed-back loop closed | Operating voltage applied, guard closed, feed-back loop open |
|---|---|---|---|---|
| ... for diagnostic purposes | Module not ready for operation | Module ready for operation | Module ready for operation | Module active |
| Y1 – Operating voltage | 0 | 1 | 1 | 1 |
| Y2 – Internal operating voltage | 0 | 1 | 1 | 1 |
| Y3 – Channel 1 (S11-S12) | 0 | 0 | 1 | 1 |
| Y4 – Channel 2 (S21-S22, S31-S32) | 0 | 0 | 1 | 1 |
| Y5 – Feedback loop (X1-X2) | 0 | 1 | 1 | 0 |
| Y6 – Relay K1 | 0 | 0 | 0 | 0 |
| Y7 – Relay K4, K5 | 0 | 0 | 0 | 1 |
| Y8 – Auxiliary NO contact | 0 | 0 | 0 | 1 |
| Auxiliary NC contact 41-42 | 0 | 1 | 1 | 0 |

Excerpt!
Refer to page 22
for complete table

- Opto-electronic protective devices as well as
- magnetic safety sensors because the circuitry also contains a current and voltage restriction.

The following functions are available options

- 1 and 2 channel operation
- Reset with trailing edge detection or automatic start, optionally with time monitoring of the channels 1 and 2 ∞ or 100 ms
- Start-up testing
- Cross-short recognition
- Feedback loop monitoring.

**Special features of the circuitry**

A 3-relay circuitry with its own start relay permits moving protective devices to be operated with traditional start-up testing. This means that – after the supply voltage is switched on – the protective safeguard must be opened and must be closed again before the module can be enabled.

The start-up testing enables inconsistencies in the upstream and downstream periphery to be detected if the relay circuitry has lost its capacity to store faults in de-energised state.

The start-up testing serves to tune the subsystem of "sensor level/pre-control level/ main control level" in the direction of a comprehensive control category 4 to EN 954-1. Without start-up testing the control category of all commercially available safety relay modules refers exclusively to the circuitry itself.

In addition to the safety-related advantage of the start-up testing, the traditional 3-relay technology (start relay plus two channel relays) guarantees increased availability of the modules in the operating mode "automatic start".

A slow increase in voltage or a short interruption of the voltage (< 20 ms) does not lead to interlocking of the two channel relays – as a result of the additional start relay – and thus avoids operational disturbances which can only be avoided in today's 2-relay technology with additional circuitry measures.




**Example of a safety circuitry with start-up testing. The start-up testing also enables the upstream and downstream periphery to be tuned in the direction of control category 4 to EN 954-1. See above.**

**Multifunctional versions – installed width 45 mm (refer to page 9 et seq.)**

| | SRB 308IT | SRB 219IT |
|---|---|---|
| **Configuration of safety enabling outputs** | | |
| Safety enabling outputs STOP 0 | 3 | 2 |
| Safety enabling outputs STOP 1 | 0 | 1 |
| – maximum load current/A | 6 | 6 |
| **Diagnostic options** | | |
| Auxiliary NC contact/auxiliary NO contact | 2 | 1 |
| – maximum load current/A | 2 | 2 |
| Signalling contacts | 6 | 8 |
| – maximum load current/mA | 10 | 10 |
| **Start configuration** | | |
| Trailing edge | ● | ● |
| Automatic start | ● | ● |
| Start-up testing | ● | ● |
| **Sensor configuration** | | |
| Time window channels 1/2, ∞ | ■ | ■ |
| | | |
| Cross-short recognition | ■ | ■ |
| 1-channel control | ● | ● |
| Antivalent control | | |
| **Fusing** | | |
| Hybrid fusing | ▲ | ▲ |
| **Supply current** | | |
| 24 VDC/VAC | ▲ | ▲ |
| 48 VAC | ▲ | |
| 115 VAC | ▲ | |
| 230 VAC | ▲ | |
| **Certifications** | | |
| BG (in preparation) | | |
| CSA (in preparation) | | |
| UL (in preparation) | | |

▲ = preset, ● = as an option, ■ = special feature as an option

## PROTECT -SRB's:
## Standard versions with additional advantages

This part of the range corresponds to the state of the art in terms of design principle using which the modules have been developed in 2-relay technology. However, additional circuitry features also in the "automatic start" operating mode achieve the same reliability as known from 3-relay modules.

This part of the range also features the advantages offered by the new housing technology used in the PROTECT SRBs and – with only a few exceptions – the advantage of hybrid fusing.

For reasons of size and cost, the functionality of the different versions is tailored to suit the defined tasks (refer also to selection table on page 8).

LED displays are provided in the standard versions with optical fibres.

## PROTECT -SRB's:
## Two-hand modules

The special feature of the two-hand module SRB 201ZH of the PROTECT series is the simple and inexpensive circuit design. The special mode of function enables a simplified design whilst fully satisfying the requirements of the highest safety category III/C to EN 574 (control category 4 to EN 954-1).

The two-hand modules SRB 201ZH are equipped for the connection of two actuators each with one NC and NO contact. Both actuators must be operated simultaneously within a specific time of < 0.5 s in compliance with EN 574 type III/C requirements. If the time is exceeded they must both be released before a restart can be initiated.



**Standard versions – installed width 22.5 mm (refer to page 23 et seq.)**

| | SRB 301LC | SRB 301ST | SRB 301AN | SRB 211ST | SRB 201ZH |
|---|---|---|---|---|---|
| **Configuration of safety enabling outputs** | | | | | |
| Safety enabling outputs STOP 0 | 3 | 3 | 3 | 2 | 2 |
| Safety enabling outputs STOP 1 | 0 | 0 | 0 | 1 | 0 |
| – maximum load current/A | 6 | 6 | 6 | 4 | 6 |
| **Diagnostic options** | | | | | |
| Auxiliary NC contact/Auxiliary NO contact | 1 | 1 | | | 1 |
| – maximum load current/A | 2 | 2 | | | 2 |
| Signalling contacts | | | 1 | 1 | |
| – maximum load current/mA | | | 100 | 100 | |
| **Start configuration** | | | | | |
| Trailing edge | | ■ | ■ | ■ | |
| Automatic start | ■ | ■ | ■ | ■ | |
| Start-up testing | | | | | |
| **Sensor configuration** | | | | | |
| Time window channels 1/2, ∞ | ▲ | ▲ | ▲ | ▲ | |
| Cross-short recognition | ■ | ■ | ▲ | ■ | ▲ |
| 1-channel control | ● | ● | | ● | |
| Antivalent control | | | ▲ | | ▲ |
| **Fusing** | | | | | |
| Hybrid fusing | | ▲ | | ▲ | |
| Electronic fusing (polyswitch) | | | ▲ | | ▲ |
| Glass fusing* | ▲ | | | | |
| **Supply current** | | | | | |
| 24 VDC | | | | | ▲ |
| 24 VDC/VAC | ▲ | ▲ | ▲ | ▲ | |
| **Certifications** | | | | | |
| BG (in preparation) | | | | | |
| CSA (in preparation) | | | | | |
| UL (in preparation) | | | | | |

▲ = preset, ● = as an option, ■ = special feature as an option

* On request: electronic fusing (polyswitch)

**Safety relay modules**
**Protect SRB series**
**– Multifunctional version**

# 1.1 SRB 308IT




**Features**

- Plug-in terminals
- 1 or 2-channel control
- 3 safety enabling outputs
- 6 signalling outputs (semiconductor)
- 1 feedback output with NC and NO function (floating contacts)
- Version with different operating voltages
- with hybrid fusing
- optionally
  - cross-short recognition
  - trailing edge
  - automatic reset function
- Suitable for signal processing of optionally
  - floating outputs, e.g. emergency stop control devices, interlocking devices, etc.
  - outputs of magnet safety sensors (for which current and voltage restriction integrated)
  - P-switching semiconductor outputs, e.g. AOPD's
- Installed width: 45 mm
- Green LED displays for relays K1, K2, K3, $U_B$ and $U_i$

**Dimensions** 45 x 100 x 121 mm

| **Type designation** | Operating voltage | **24 VAC/DC** | **48 VAC** | **115 VAC** | **230 VAC** |
|---|---|---|---|---|---|
| | Enabling paths 3 NO/1 NC | **SRB 308IT-24V** | **SRB 308IT-48V** | **SRB 308IT-115V** | **SRB 308IT-230V** |

**Test symbol** (in preparation) FRG USA CAN

**Circuit example**




**NB**

- 2-channel control (example without cross-short recognition), shown by way of example of a guard monitoring system with two contacts A and B, at least one of which is a contact with positive opening; with external reset button ®
- F1 = hybrid fusing
- F2 = protection of signalling outputs
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- (H2) = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.

# 1.2 SRB 219IT




**Features**

- Plug-in terminals
- 1 or 2-channel control
- 3 safety enabling outputs, of which one with drop-out delay: 1–30 sec.
- 8 signalling outputs (semiconductor)
- 1 feedback output with NC function (floating contacts)
- with hybrid fusing
- optionally
  - cross-short recognition
  - trailing edge
  - automatic reset function
- Suitable for signal processing of optionally
  - floating outputs, e.g. emergency stop control devices, interlocking devices, etc.
  - outputs of magnet safety sensors (for which current and voltage restriction integrated)
  - P-switching semiconductor outputs, e.g. AOPD's
- Installed width: 45 mm
- Green LED displays for relays K1, K2, K3, K4, K5, $U_B$ and $U_i$

**Dimensions** 45 x 100 x 121 mm

| **Type designation** | Operating voltage | **24 VAC/DC** |
|---|---|---|
| | Enabling paths<br>2 NO/1 NO ⊰/1 NC | **SRB 219IT-24V** |

**Test symbol** (in preparation)

| | | |
|---|---|---|
| FRG | USA | CAN |

**Circuit example**




**NB**

- 2-channel control (example without cross-short recognition), shown by way of example of a guard monitoring system with two contacts A and B, at least one of which is a contact with positive opening; with external reset button ®
- F1 = hybrid fusing
- F2 = protection of signalling outputs
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- (H2) = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.

**Time delay**

- The time-delayed safety enabling output 37/38 can be set with a dropout delay of between 1 to 30 seconds (see setting instructions).
- The safety enabling output 37/38 corresponds to STOP category 1 to EN 60 204-1. The safety enabling outputs 13/14 and 23/24 correspond to STOP category 0 to EN 60204-1.
- The dropout delay can be set by means of potentiometer accessible on the front side of the housing.

**Premature switching off of the time delay**

- The dropout delay can be ended prematurely via the RT input.
- The RT input facilitates the “switching off” of time-delayed enabling output 37/38 before expiry of the set time.
- The reset function is only effective during the dropout delay (after switching off the safety relay module). Internally a reset signal is generated by a “rising edge” (activation of the 24 VDC signal at the RT input).



# 1.3 Technical data

| | SRB 308IT | SRB 219IT |
|---|---|---|
| Operating voltage | 24 VDC –15%/+20%, residual ripple max. 10%<br>24 VAC, 48 VAC, 115 VAC, 230 VAC –15%/+10% | 24 VDC –15%/+20%, residual ripple max. 10%<br>24 VAC –15%/+10% |
| Frequency range | 50/60 Hz (with AC operating voltage) | |
| Fuse of operating voltage | internal electronic fuse F1, triggering current > 0.5 A,<br>reset after interruption of supply voltage | |
| Power consumption | max. 3 VA, 3 W | max. 5.2 VA, 4.4 W |
| Voltage and current restrictions of the control circuits S11/S12, S21/S22, S31/S32 | max. 28 VDC/50 mA | |
| Voltage and current of the control circuits X3/X5 | max. 28 VDC/100 mA | |
| Switching capacity of the enabling contacts | 230 VAC, 6 A ohmic (inductive with suitable suppressor circuit) | |
| Fuse of the enabling contacts | 6 A slow-blowing | |
| Switching capacity of the auxiliary outputs | 41/42, 53/54: 24 VDC, 2 A | 41/42: 24 VDC, 2 A |
| Fuse of the auxiliary contacts | 2 A slow-blowing | |
| Switching capacity of the signalling contacts | Y1, Y2, Y3, Y4, Y5, Y6: 24 VDC, max. 10 mA | Y1, Y2, Y3, Y4, Y5, Y6, Y7, Y8: 24 VDC, max. 10 mA |
| Fuse of the signalling outputs | internal electronic fuse F2, tripping current > 100 mA | |
| External auxiliary voltages | A1.1: 24 VDC –10%/+10% | |
| Utilisation categories | 13/14, 23/24, 33/34:<br>AC 15: 230 VAC, 6 A<br>DC 13: 24 VDC, 6 A | 13/14, 23/24:<br>AC 15: 230 VAC, 6 A; DC 13: 24 VDC, 6 A<br>37/38:<br>AC 15: 230 VAC, 3 A; DC 13: 24 VDC, 2 A |
| Pickup delay | ≤ 60 ms/≤ 200 ms (autostart/reset button) | |
| Dropout delay | ≤ 20 ms | |
| Varistor circuitry* | Shorter dropout delay | |
| Contact material/contacts | AgNi, AgSnO, self-cleaning, positively driven | |
| Contact resistance | max. 100 mOhm in new state | |
| Air clearance and creepage distance | DIN VDE 0110-1 (04.97), 4 kV/2 | |
| Cable connections | Plug-in self-lifting screw terminals<br>min. 0.2 $mm^2$, max. 2.5 $mm^2$, strand or multicore with wire end ferrule | |
| Dimensions | h/b/d 100 mm/45 mm/121 mm | |
| Weight | 340 g (400 g with transformer) | 360 g |
| Ambient operating temperature | –25 °C ... 45 °C (derating curve upon request) | |
| Mechanical life | $10^7$ switching cycles | |
| Terminal markings | DIN EN 50 005/DIN 50 013 | |

* upon request

The following selection of applications is intended to provide users with assistance on which functionalities PROTECT SRBs offer.

The circuit examples are suggestions which do not (cannot), however, release the user from his own responsibility to check the circuitry carefully in terms of its suitability for the individual case.

A CD ROM is provided with this catalogue as an additional service with the aid of which a complete connection diagram can be compiled from the different individual functionalities.

Since EN 954-1 does not require an overall control category for safety circuits, the control category (SK) is shown separately for upstream and downstream periphery as well as for the SRB module itself.

## Example: monitored start / without cross-short recognition / dual-channel control

**Monitored start**




**Without cross-short recognition**




**Dual-channel control**







**Control category:**
- **Sensor configuration SK3**
- **SRB module SK4**
- **Actuator level SK4**

### 1.4 Selection of applications

**Start configuration**
External reset button . . . . . Page 16
Automatic (time offset approx. 100 ms) . . . . . Page 16
Start-up testing . . . . . Page 16

**Sensor configuration**
EMERGENCY-STOP . . . . . Page 17
Guard . . . . . Page 18
P-switching semiconductor . . . . . Page 19
Magnetic safety sensors . . . . . Page 19

**Actuator configuration/contact multiplication (KV)**
Single-channel . . . . . Page 20
Dual-channel . . . . . Page 20
Diversitary . . . . . Page 20

## Start configuration

**External reset button**
- The external reset button is connected to terminals X3-X4.
- Programming to the function “trailing edge” by means of switch AF (switch position = 1) on the front side of the housing.




**Automatic start**
- Programming to automatic start by means of connecting terminals X3-X5.
- The time offset between channels 1 and 2 is approx. 100 ms.
- Programming to endless time offset between channels 1 and 2 by means of connecting terminals X3-X6.
- If the operating mode “automatic start” is used, an automatic restart after standstill in case of emergency to EN 60 204-1 Section 9.2.5.4.2 and 10.8.3 is to be prevented by higher ranking system.




**Time offset ∞** **Time offset 100 ms**

**Start-up testing**
- Start-up testing, see page 6
- Additional auxiliary contacts are to be provided as contacts serving the purposes of start-up testing.



## Sensor configuration

**Single-channel EMERGENCY STOP circuit to EN 418/EN 60 947-5-5**

- Detects wire break and earth leakage in EMERGENCY STOP circuit.




**Dual-channel EMERGENCY STOP circuit to EN 418/EN 60 947-5-5**

- Detects wire break and earth leakage in the EMERGENCY STOP circuits.
- Cross shorts in the EMERGENCY STOP circuits are not detected.




**Dual-channel EMERGENCY STOP circuit to EN 418/EN 60 947-5-5**

- Detects wire breaks and earth leakage in the EMERGENCY STOP circuits.
- Cross shorts in the EMERGENCY STOP circuits are detected.



**Single-channel guard monitoring to EN 1088**
- With positively opening position switch.
- Detects wire break and earth leakage in the guard monitoring circuit.




**Dual-channel guard monitoring to EN 1088**
- With at least one positively opening position switch.
- Detects wire break and earth leakage in the guard monitoring circuits.
- Cross shorts between the guard monitoring circuits are not detected.




**Dual-channel guard monitoring to EN 1088**
- With positively opening position switches.
- Detects wire break and earth leakage in the guard monitoring circuits.
- Cross shorts between the guard monitoring circuits are detected.



**Dual-channel control with safety-orientated P-switching semiconductor components, e.g. AOPDs to EN 61 496**

- Detects wire breaks and earth leakage in the control circuits.
- Cross shorts between the monitoring circuits are not detected. Monitoring is performed at sensor level.
- The terminals S11 and S21 are used here to feed the P-switching sensors.




**Single-channel control of magnet safety sensor switches to EN 60 947-5-3**

- Detects wire breaks and earth leakage in the control circuits.

**ATTENTION**

It is only admissible to connect magnet safety sensor switches to the analysis circuitry if the requirements of standard EN 60 947-5-3: 1999 are satisfied.
The following minimum technical requirements must be satisfied:
Switching capacity: min. 3 W
Switching voltage: min. 30 VDC
Switching current: min. 100 mA
The requirements are satisfied, for example, by the following Schmersal safety sensor:

- BNS33-02z-2187




**Dual-channel control of magnet safety sensor switches to EN 60 947-5-3**

- Detects wire breaks and earth leakage in the control circuits.

**ATTENTION**

It is only admissible to connect magnet safety sensor switches to the analysis circuitry if the requirements of standard EN 60 947-5-3: 1999 are satisfied.
The following minimum technical requirements must be satisfied:
Switching capacity: min. 3 W
Switching voltage: min. 30 VDC
Switching current: min. 100 mA
The requirements are satisfied, for example, by the following Schmersal safety sensor:

- BNS33-02z-2187




**without cross-short detection** **with cross-short detection**

## Actuator configuration

**Single-channel control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.




**Dual-channel control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.




**Diversitary control (type SRB 219IT)**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.



## Terminal designation

**Voltages**

| | |
|---|---|
| A1 | +24 VDC/24 VAC |
| A2 | 0 VDC/24 VAC |
| A1.1 | Feed of the semiconductor outputs (24 VDC) |

**Inputs**

| | |
|---|---|
| S11/S12 | Input channel 1 |
| S21/S22 | Input channel 2 |
| S31/S32 | Input for cross-short detection |

**Outputs**

| | |
|---|---|
| 13/14 | First safety enabling output (STOP 0) |
| 23/24 | Second safety enabling output (STOP 0) |
| 33/34 | Third safety enabling output (STOP 0) (in the case of type SRB 308IT) |
| 37/38 | Third safety enabling output (STOP 1), with dropout delay 1 ... 30 sec. (in the case of type SRB 219IT) |
| 41/42 | Auxiliary NC contact |
| 53/54 | Auxiliary NO contact |
| RT | Premature termination of the dropout delay |

**Start**

| | |
|---|---|
| X1/X2 | Feedback loop |
| X3 | Supply start |
| X4 | Manual start (reset button) |
| X5 | Automatic start |
| X6 | Time offset to infinity |

**Signalling outputs**

| | |
|---|---|
| Y1 | Operating voltage |
| Y2 | Internal voltage |
| Y3 | Status channel 1 |
| Y4 | Status channel 2 |
| Y5 | Status feedback loop |
| Y6 | Status start relay (K1) |
| Y7 | Status stop 1 (K4, K5) |
| Y8 | Auxiliary NO contact stop 0 (K2, K3) |

**Type SRB 308IT**

| Messages | Operating voltage applied, guard open, feedback loop closed | Operating voltage applied, guard closed, feedback loop closed | Operating voltage applied, guard closed, feedback loop closed, start button pushed | Operating voltage applied, guard closed, feedback loop closed, start button released | Operating voltage applied, guard closed, feedback loop open |
|---|---|---|---|---|---|
| **Status** | **Module off** | **Module off** | **Module started** | **Module started** | **Module on** |
| Y1 – Operating voltage | 1 | 1 | 1 | 1 | 1 |
| Y2 – Internal voltage | 1 | 1 | 1 | 1 | 1 |
| Y3 – Channel 1 (S11-S12) | 0 | 1 | 1 | 1 | 1 |
| Y4 – Channel 2 (S21-S22, S31-S32) | 0 | 1 | 1 | 1 | 1 |
| Y5 – Feedback loop (X1-X2) | 1 | 1 | 1 | 1 | 0 |
| Y6 – Relay K1 | 0 | 0 | 0 | 1 | 0 |
| Auxiliary NC contact 41-42 | 1 | 1 | 1 | 1 –> 0 | 0 |
| Auxiliary NO contact 53-54 | 0 | 0 | 0 | 0 –> 1 | 1 |

**Type SRB 219IT**

| Messages | Operating voltage applied, guard open, feedback loop closed | Operating voltage applied, guard closed, feedback loop closed | Operating voltage applied, guard closed, feedback loop closed, start button pushed | Operating voltage applied, guard closed, feedback loop closed, start button released | Operating voltage applied, guard closed, feedback loop open |
|---|---|---|---|---|---|
| **Status** | **Module off** | **Module off** | **Module started** | **Module started** | **Module on** |
| Y1 – Operating voltage | 1 | 1 | 1 | 1 | 1 |
| Y2 – Internal voltage | 1 | 1 | 1 | 1 | 1 |
| Y3 – Channel 1 (S11-S12) | 0 | 1 | 1 | 1 | 1 |
| Y4 – Channel 2 (S21-S22, S31-S32) | 0 | 1 | 1 | 1 | 1 |
| Y5 – Feedback loop (X1-X2) | 1 | 1 | 1 | 1 | 0 |
| Y6 – Relay K1 | 0 | 0 | 0 | 1 | 0 |
| Y7 – Relay K4, K5 | 0 | 0 | 0 | 0 | 1 |
| Auxiliary NC contact 41-42 | 1 | 1 | 1 | 1 –> 0 | 0 |
| Y8 – Auxiliary NO contact | 0 | 0 | 0 | 0 –> 1 | 1 |

# Safety relay modules
# Protect SRB series
# – Standard version

# 2.1 SRB 301LC




**Features**

- 1 or 2-channel control
- 3 safety enabling outputs
- 1 feedback output with NC function (floating contact)
- optionally
  – cross-short recognition
- Suitable for signal processing of optionally
  – floating outputs, e.g. emergency stop control devices, interlocking devices, etc.
  – P-switching semiconductor outputs, e.g. AOPD's
- Installed width: 22.5 mm
- Green LED displays for relays K1, K2, $U_B$ and $U_i$

**Dimensions** 22.5 x 100 x 121 mm

| **Type designation** | | |
|---|---|---|
| | Operating voltage | **24 VAC/DC** |
| | Enabling paths 3 NO/1 NC | **SRB 301LC** |

**Test symbol** (in preparation)

| | | |
|---|---|---|
| FRG | USA | CAN |

**Circuit example**




**NB**

- 2-channel control (example with cross-short recognition) of a guard monitoring system with two contacts A and B, at least one of which is a contact with positive opening; with external reset button ®
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- (H2) = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.

# 2.2 SRB 301ST




**Features**

- Plug-in terminals
- 1 or 2-channel control
- 3 safety enabling outputs
- 1 feedback output with NC function (floating contact)
- with hybrid fusing
- optionally
  - cross-short recognition
  - trailing edge
  - automatic reset function
- Suitable for signal processing of optionally
  - floating outputs, e.g. emergency stop control devices, interlocking devices, etc.
  - P-switching semiconductor outputs, e.g. AOPD's
- Installed width: 22.5 mm
- Green LED displays for relays K1, K2, $U_B$ and $U_i$

**Dimensions** 22.5 x 100 x 121 mm

| **Type designation** | | |
|---|---|---|
| | Operating voltage | **24 VAC/DC** |
| | Enabling paths 3 NO/1 NC | **SRB 301ST** |

**Test symbol** (in preparation)

| | | |
|---|---|---|
| FRG | USA | CAN |

**Circuit example**




**NB**

- 2-channel control (example with cross-short recognition) of a guard monitoring system with two contacts A and B, at least one of which is a contact with positive opening; with external reset button ®
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- (H2) = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.

# 2.3 SRB 301AN




**Features**

- Plug-in terminals
- 1 or 2-channel control
- 3 safety enabling outputs
- 1 feedback output with NC function (floating contact)
- optionally
  - trailing edge
  - automatic reset function
- Suitable for signal processing of optionally
  - floating outputs, e.g. emergency stop control devices, interlocking devices, etc.
- Current and voltage restriction of the input circuits
- Installed width: 22.5 mm
- Green LED displays for relays K1, K2 and $U_i$

**Dimensions** 22.5 x 100 x 121 mm

| **Type designation** | | |
|---|---|---|
| | Operating voltage | **24 VAC/DC** |
| | Enabling paths 3 NO/1 NC | **SRB 301AN** |

**Test symbol** (in preparation)

| | | |
|---|---|---|
| FRG | USA | CAN |

**Circuit example**




**NB**

- 2-channel control (example with cross-short recognition) of a guard monitoring system with two contacts A and B, at least one of which is a contact with positive opening; with external reset button ®
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- H2 = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.




**Features**

- Plug-in terminals
- 1 or 2-channel control
- 3 safety enabling outputs, of which one with drop-out delay: 1–30 sec.
- 1 feedback output with NC function (floating contact)
- with hybrid fusing
- optionally
  - cross-short recognition
  - trailing edge
  - automatic reset function
- Suitable for signal processing of optionally
  - floating outputs, e.g. emergency stop control devices, interlocking devices, etc.
  - P-switching semiconductor outputs, e.g. AOPD's
- Installed width: 22.5 mm
- Green LED displays for relays K1, K2, K3/K4, $U_B$ and $U_i$

**Dimensions** 22.5 x 100 x 121 mm

| **Type designation** | | |
|---|---|---|
| | Operating voltage | **24 VAC/DC** |
| | Enabling paths<br>2 NO/1 NO ⊰/1 NC | **SRB 211ST** |
| **Test symbol** (in preparation) | FRG USA CAN | |

**Circuit example**




**NB**

- 2-channel control (example with cross-short recognition) of a guard monitoring system with two contacts A and B, at least one of which is a contact with positive opening; with external reset button ®
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- (H2) = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.

**Time delay**

- The time-delayed safety enabling output 37/38 can be set with a dropout delay of between 1 to 30 seconds (see setting instructions).
- The safety enabling output 37/38 corresponds to STOP category 1 to EN 60 204-1. The safety enabling outputs 13/14 and 23/24 correspond to STOP category 0 to EN 60 204-1.
- The dropout delay can be set by means of potentiometer accessible on the front side of the housing.

| | SRB 301LC | SRB 301ST |
|---|---|---|
| Operating voltage | 24 VDC –15%/+20%, residual ripple max. 10%<br>24 VAC –15%/+10% | |
| Frequency range | 50/60 Hz (with AC operating voltage) | |
| Fuse of operating voltage | internal F1: T 1.25 A | internal electronic fuse F1, tripping current > 0.6 A, reset after interruption of supply voltage |
| Power consumption | max. 1.7 W, 1.9 VA | max. 2.4 W; 3.8 VA |
| Voltage and current restriction of the control circuits | | 26 VDC/250 mA |
| Switching capacity of the enabling contacts | 230 VAC, 6 A ohmic<br>(inductive with suitable suppressor circuit) | 230 VAC, 6 A ohmsch<br>(inductive with suitable suppressor circuit) |
| Fuse of the enabling contacts | 6 A slow-blowing | 6 A slow-blowing |
| Switching capacity of the auxiliary contacts | 24 VDC, 2 A | 24 VDC, 2 A |
| Fuse of the auxiliary contacts | 2 A slow-blowing | 2 A slow-blowing |
| Switching capacity of the signalling outputs | | |
| Fuse of the signalling outputs | | |
| Utilisation categories | AC 15/DC 13: EN 60 947-5-1 | |
| Pickup delay | ≤ 30 ms | ≤ 200 ms |
| Dropout delay | ≤ 50 ms | ≤ 20 ms |
| Varistor circuitry* | | Shorter dropout delay |
| Contact materials/contacts | AgSnO, self-cleaning, positively driven | |
| Contact resistance | max. 100 mOhm in new state | |
| Air clearance and creepage distance | DIN VDE 0110-1 (04.97), 4 kV/2 | |
| Cable connections | Self-lifting screw terminals<br>min. 0.2 $mm^2$, max. 2.5 $mm^2$,<br>strand or multicore with wire end ferrule | Self-lifting plug-in screw terminals<br>min. 0.2 $mm^2$, max. 2.5 $mm^2$,<br>strand or multicore with wire end ferrule |
| Dimensions | h/b/d 100 mm/22.5 mm/121 mm | |
| Weight | 230 g | 240 g |
| Ambient operating temperature | –25 °C ... 45 °C (derating curve upon request) | |
| Mechanical life | $10^7$ switching cycles | |
| Terminal markings | DIN EN 50 005/DIN 50 013 | |

* upon request

| | SRB 301AN | SRB 211ST |
|---|---|---|
| Operating voltage | 24 VDC –15%/+20%, residual ripple max. 10%<br>24 VAC –15%/+10% | |
| Frequency range | 50/60 Hz (with AC operating voltage) | |
| Fuse of operating voltage | internal electronic fuse F1, tripping current > 0.6 A, reset approx. 1 second | internal electronic fuse F1, tripping current > 1 A, reset after interruption of supply voltage |
| Power consumption | max. 1.8 W, 2.5 VA, plus signalling output Y1 | max. 5.1 W, 5.7 VA, plus signalling output Y1 |
| Voltage and current restriction of the control circuits | 26 VDC/100 mA | |
| Switching capacity of the enabling contacts | 230 VAC, 6 A ohmic<br>(inductive with suitable suppressor circuit) | 230 VAC, 4 A ohmic<br>(inductive with suitable suppressor circuit),<br>13/14, 23/24: AC 15: 250 V/1.5 A,<br>DC 13: 24 V/1.2 A<br>37/38: AC 15: 250 V/3 A,<br>DC 13: 24 V/2 A |
| Fuse of the enabling contacts | 6 A slow-blowing | 4 A slow-blowing |
| Switching capacity of the auxiliary contacts | | |
| Fuse of the auxiliary contacts | | |
| Switching capacity of the auxiliary contacts | 24 VDC, 100 mA | 24 VDC, 100 mA |
| Fuse of the signalling outputs | internal electronic fuse, tripping current > 500 mA | internal electronic fuse, tripping current > 100 mA |
| Utilisation categories | AC 15/DC 13: EN 60 947-5-1 | |
| Pickup delay | ≤ 30 ms | ≤ 40 ms |
| Dropout delay | ≤ 20 ms | ≤ 40 ms |
| Varistor circuitry* | Shorter dropout delay | |
| Contact material/contacts | AgSnO, self-cleaning, positively driven | |
| Contact resistance | max. 100 mOhm in new state | |
| Air clearance and creepage distance | DIN VDE 0110-1 (04.97), 4 kV/2 | |
| Cable connections | Plug-in self-lifting screw terminals<br>min. 0.2 $mm^2$, max. 2.5 $mm^2$,<br>strand or multicore with wire end ferrule | Plug-in self-lifting screw terminals<br>min. 0.2 $mm^2$, max. 2.5 $mm^2$,<br>strand or multicore with wire end ferrule |
| Dimensions | h/b/d 100 mm/22.5 mm/121 mm | |
| Weight | 235 g | 255 g |
| Ambient operating temperature | –25 °C ... 45 °C (derating curve upon request) | |
| Mechanical life | $10^7$ switching cycles | |
| Terminal markings | DIN EN 50 005/DIN 50 013 | |

* upon request

## Notes

The following selection of applications is intended to provide users with assistance on which functionalities PROTECT SRBs offer.

The circuit examples are suggestions which do not (cannot), however, release the user from his own responsibility to check the circuitry carefully in terms of its suitability for the individual case.

A CD ROM is provided with this catalogue as an additional service with the aid of which a complete connection diagram can be compiled from the different individual functionalities.

Since EN 954-1 does not require an overall control category for safety circuits, the control category (SK) is shown separately for upstream and downstream periphery as well as for the SRB module itself.

## Example: monitored start / without cross-short recognition / dual-channel control

**Monitored start** | **Without cross-short recognition** | **Dual-channel control**







**Control category:**
- **Sensor configuration SK3**
- **SRB module SK4**
- **Actuator level SK4**

### 1.4 Selection of applications

**Start configuration**
External reset button . . . . . Page 36
Automatic . . . . . Page 36

**Sensor configuration**
EMERGENCY-STOP . . . . . Page 37
Guard . . . . . Page 38
P-switching semiconductor . . . . . Page 39
Magnet safety sensors . . . . . Page 39

**Actuator configuration/contact multiplication (KV)**
Single-channel . . . . . Page 40
Dual-channel . . . . . Page 40
Diversitary . . . . . Page 40

## Start configuration

**External reset button**

- The external reset button is connected to terminals X1-X2, S12-X2.
- The feedback loop is connected in series to the reset button.




SRB 301LC, SRB 301AN, SRB 211ST




SRB 301ST

**Automatic start**

- Programming to automatic start by means of connecting the feedback loop to terminals X1-X3, X1-X2, S12-X3. If the feedback loop is not required it is to be replaced by a bridge.
- If the operating mode “automatic start” is used, an automatic restart after standstill in case of emergency to EN 60 204-1 Section 9.2.5.4.2 and 10.8.3 is to be prevented by higher ranking system.




SRB 301AN, SRB 211ST




SRB 301LC




SRB 301ST

## Sensor configuration

**Single-channel EMERGENCY STOP circuit to EN 418/EN 60 947-5-5**

- Detects wire break and earth leakage in EMERGENCY STOP circuit.




**SRB 301LC, SRB 301ST, SRB 211ST**

**Dual-channel EMERGENCY STOP circuit to EN 418/EN 60 947-5-5**

- Detects wire break and earth leakage in the EMERGENCY STOP circuits.
- Cross shorts in the EMERGENCY STOP circuits are not detected.




**SRB 301LC, SRB 301ST, SRB 211ST**

**Dual-channel EMERGENCY STOP circuit to EN 418/EN 60 947-5-5**

- Detects wire breaks and earth leakage in the EMERGENCY STOP circuits.
- Cross shorts in the EMERGENCY STOP circuits are detected.




**SRB 301LC, SRB 301ST, SRB 211ST**




**SRB 301AN**

**Single-channel guard monitoring to EN 1088**
- With positively opening position switch.
- Detects wire break and earth leakage in the guard monitoring circuit.




**SRB 301LC, SRB 301ST, SRB 211ST**

**Dual-channel guard monitoring to EN 1088**
- With at least one positively opening position switch.
- Detects wire break and earth leakage in the guard monitoring circuits.
- Cross shorts between the guard monitoring circuits are not detected.




**SRB 301LC, SRB 301ST, SRB 211ST**

**Dual-channel guard monitoring to EN 1088**
- With positively opening position switches.
- Detects wire break and earth leakage in the guard monitoring circuits.
- Cross shorts between the guard monitoring circuits are detected.




**SRB 301LC, SRB 301ST, SRB 211ST**




**SRB 301AN**

**Dual-channel control with safety-orientated P-switching semiconductor components, e.g. AOPDs to EN 61496**

- Detects wire breaks and earth leakage in the control circuits.
- Cross shorts between the monitoring circuits are not detected. Monitoring is performed at sensor level.
- The terminal S11 is used here to feed the P-switching sensors.




**SRB 301LC, SRB 301ST, SRB 211ST**

**ATTENTION**

It is only admissible to connect magnet safety sensor switches to the analysis circuitry if the requirements of standard EN 60947-5-3: 1999 are satisfied.
The following minimum technical requirements must be satisfied:

| | |
|---|---|
| Switching capacity: | min. 3 W |
| Switching voltage: | min. 30 VDC |
| Switching current: | min. 100 mA (SRB 301AN) |
| | min. 250 mA (SRB 301ST) |

The requirements are satisfied, for example, by the following Schmersal safety sensors:

- SRB 301 AN:
  - BNS33-11z, BNS33-11z-2063
  - BNS250-11z
  - BNS120-11z
  - BNS180-11z
  - BNS303-11z
- SRB 301ST:
  - BNS33-02z-2187

**Dual-channel control of magnet safety sensor switches to EN 60947-5-3**

- Detects wire breaks, earth leakage and cross shorts in the control circuits.




**SRB 301ST**




**SRB 301AN**

## Actuator configuration

**Single-channel control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.




SRB 301LC, SRB 301AN, SRB 211ST




SRB 301ST

**Dual-channel control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.




SRB 301LC, SRB 301AN, SRB 211ST




SRB 301ST

**Diversitary control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.




SRB 211ST

## Terminal designation

**Voltages**

| | |
|---|---|
| A1 | +24 VDC/24 VAC |
| A2 | 0 VDC/24 VAC |

**Inputs**

| | |
|---|---|
| S11/S12 | Input channel 1 (+) |
| S11/S22 | Input channel 2 (+) |
| S13/S14 | Input channel 1 (+) |
| S21/S22 | Input channel 2 (–) |

**Outputs**

| | |
|---|---|
| 13/14 | First safety enabling output (STOP 0) |
| 23/24 | Second safety enabling output (STOP 0) |
| 33/34 | Third safety enabling output (STOP 0) |
| 37/38 | Third safety enabling output (STOP 1), |
| 41/42 | Auxiliary NC contact |

**Start**

| | |
|---|---|
| X1/X2 | Feedback loop, manual start (reset button) |
| S12/X2 | Feedback loop, manual start (reset button) with type SRB 301ST |
| X1/X2 | Feedback loop, automatic start with type SRB 301LC |
| X1/X3 | Feedback loop, automatic start with type SRB 301AN, SRB 211ST |
| S12/X3 | Feedback loop, automatic start with type SRB 301ST |

**Signalling outputs**

| | |
|---|---|
| Y1 | Auxiliary NC contact |

## Notes

# Two-hand relay modules
# Protect SRB series

# 3.1 SRB 201ZH




**Dimensions** 22.5 x 100 x 121 mm

**Dimensions**

- Two-hand module to DIN EN 574 (1997) type III C
- Plug-in terminals
- 2 safety enabling outputs
- 1 feedback output with NC function (floating contact)
- Electronic fuse
- Installed width: 22.5 mm
- Green LED displays for relays K1 and K2

| **Type designation** | Operating voltage | **24 VDC** |
|---|---|---|
| | Enabling paths<br>2 NO/1 NC | **SRB 201ZH** |
| **Test symbol** (in preparation) | FRG USA CAN | |

**Circuit example**




**NB**

- 2-channel control with two contacts A and B
- The NC contact of the buttons A and B must have opened before the NO contact closes. No overlapping contacts since otherwise the fuses F1 and F2 would trigger.
- Power level: 2-channel control, suitable for contact amplification and contact multiplication through contactors or relays with positively driven contacts.
- (H2) = feedback loop
- The control circuit detects wire breaks and earth leakage in the monitoring circuit.

| | SRB 201ZH |
|---|---|
| Operating voltage | 24 VDC –15%/+10%, residual ripple max. 10% |
| Fuse of operating voltage | internal electronic fuse F1, F2, tripping current > 0.2 A,<br>internal electronic fuse F3, tripping current > 0.6 A |
| Power consumption | max. 1.2 W |
| Switching capacity of the enabling contacts | 230 VAC, 6 A ohmic (inductive with suitable suppressor circuit) |
| Fuse of the enabling contacts | 6 A slow-blowing |
| Switching capacity of the auxiliary contacts | 24 VDC, 2 A |
| Fuse of the auxiliary contacts | 2 A slow-blowing |
| Utilisation categories | AC 15/DC 13: EN 60 947-5-1 |
| Pickup delay | ≤ 50 ms |
| Dropout delay | ≤ 30 ms |
| Contact material/contacts | AgSnO, self-cleaning, positively driven |
| Contact resistance | max. 100 mOhm in new state |
| Air clearance and creepage distance | DIN VDE 0110-1 (04.97), 4 kV/2 |
| Cable connections | Plug-in self-lifting screw terminals<br>min. 0.2 mm², max. 2.5 mm², strand or multicore with wire end ferrule |
| Dimensions | h/b/d 100 mm/22.5 mm/121 mm |
| Weight | 200 g |
| Ambient operating temperature | –25 °C ... 45 °C (derating curve upon request) |
| Mechanical life | $10^7$ switching cycles |
| Terminal markings | DIN EN 50 005/DIN 50 013 |



## Start/sensor configuration

**Two-hand circuit to DIN EN 574 and EN 60 204-1**

- Malfunctions of every button contact as well as earth and cross shorts are detected.
- Feedback loop: the safety-related function of external positively driven contactors is monitored by a series circuit of the NC contacts with the terminals X 1 and X2. In release state this circuit must be closed.
- Safety category III C to DIN EN 574 (02.97)




**Circuit example control level/ two hand circuit to DIN EN 574 and EN 60 204-1**

- Malfunctions of every button contact as well as earth and cross shorts are detected.
- Feedback loop: the safety-related function of external positively driven contactors is monitored by a series circuit of the NC contacts with the terminals X 1 and X2. In release state this circuit must be closed.
- Safety category III C to DIN EN 574 (02.97)



## Actuator configuration

**Single-channel control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.




**Dual-channel control**

- Suitable for contact amplification or contact multiplication by means of relay or contactor with positively driven contacts.

* Feedback loop
If the feedback loop is not required it is to be replaced by a bridge.



## Terminal designation

**Voltages**

| | |
|---|---|
| A1 | +24 VDC |
| A2 | 0 VDC |

**Inputs**

| | |
|---|---|
| A1.1/S11 | Input 1st actuator (NC contact) |
| A2.1/S12 | Input 1st actuator (NO contact) |
| A1.1/S22 | Input 2nd actuator (NO contact) |
| A2.1/S21 | Input 2nd actuator (NC contact) |

**Outputs**

| | |
|---|---|
| 13/14 | First safety enabling output (STOP 0) |
| 23/24 | Second safety enabling output (STOP 0) |
| 31/32 | Auxiliary NC output |

## Notes

# Symbol key

Sideways moving guard 

Rotating guard 

Removable guard 

EMERGENCY STOP function 

Guard closed 

Guard open 

Control category 1 to EN 954-1 

Control category 2 to EN 954-1 

Control category 3 to EN 954-1 

Control category 4 to EN 954-1 

Category 0 to IEC 60 204-1 

Category 1 to IEC 60 204-1 

Totally insulated 

NC contact with positive operation 

Human protection function 

Positive operation path/angle 

Latching point 

Cable break monitoring 

Cable pull monitoring 

Confirmed 

Unconfirmed 

Auxiliary unlocking with male triangular wrench 

Wrench size 

Explosion protected 

Inductive proximity switch 

Magnetic safety sensor,
contact-free safety sensor 

Switch off 

Switch on 

On/off switch 

Unlock latching 

Reset button 

Start button 

Test button 

Guard may not be opened
after unlocking 

Feedback loop increases safety
but not control category 

Refer to . If no connection,
 must be considered 

Only in the case of AES ...5
without start-up testing:
when the EMERGENCY STOP button is unlocked,
the enabling output is given automatically 

The bar must be locked at least
5 seconds after locking the guard 

Button for enabling output on/off 

Additional standstill signal 

Lever spring point 

Restart button 

SAQ approval, Sweden 

SA approval, Sweden 

UL approval, USA 

CSA approval, Canada 

TÜV prototype tested 

Approval Denmark 

BG prototype tested 

SUVA approval, Switzerland 

Approval Australia:
Division of Inspection Services 

## German agencies

**Headquarters**
K.A. Schmersal GmbH
Industrielle Sicherheitsschaltsysteme
Postfach 24 02 63, 42232 Wuppertal
Möddinghofe 30
**42279 Wuppertal**
Telephone: +49-(0) 2 02-64 74-0
Facsimile: +49-(0) 2 02-64 74-1 00
E-Mail: info@schmersal.de
Internet: www.schmersal.de

**01** **Hamburg**
K.A. Schmersal GmbH
Geschäftsstelle Hamburg
Zunftstraße 8
**21244 Buchholz i.d.N.**
Telephone: +49-(0) 41 81-9 22 0-0
Facsimile: +49-(0) 41 81-9 22 0-20
E-Mail: gshamburg@schmersal.de

**02** **Berlin**
KSA Komponenten der Steuerungs- und Automatisierungstechnik GmbH
Buchholzer Str. 62-65
**13156 Berlin**
Telephone: +49-(0) 30-47 48 24 00
Facsimile: +49-(0) 30-47 48 24 05
E-Mail: info@ksa-gmbh.de
Internet: www.ksa-gmbh.de

**03** **Hanover**
ELTOP GmbH
Robert-Bosch-Straße 8
**30989 Gehrden**
Telephone: +49-(0) 51 08-92 73 20
Facsimile: +49-(0) 51 08-92 73 21
E-Mail: eltop@eltop.de
Internet: www.eltop.de

**04** **Münster**
K.A. Schmersal GmbH
Geschäftsstelle Münster
Am Vechte Ufer 22
**48629 Metelen**
Telephone: +49-(0) 25 56-9 38 30
Facsimile: +49-(0) 25 56-93 83 73
E-Mail: gsmuenster @schmersal.de

**05** **Köln**
Stollenwerk
Technisches Büro GmbH
Scheuermühlenstraße 40
**51147 Köln**
Telephone: +49-(0) 22 03-9 66 20-0
Facsimile: +49-(0) 22 03-9 66 20-30
E-Mail: info@stollenwerk.de

**14** **Ruhr area**
K W S Elektronik Schumacher
Saarstr. 19a
**53919 Weilerswist**
Telephone: +49-(0) 22 54-33 80
Facsimile: +49-(0) 22 54-18 58
E-Mail: k-w-s-@t-online.de

**12** **Siegen**
Siegfried Klein
Elektro-Industrie-Vertretungen
Schloßblick 38
**57074 Siegen**
Telephone: +49-(0) 2 71-67 78
Facsimile: +49-(0) 2 71-67 70
E-Mail: info@sk-elektrotechnik.de

**16** **Frankfurt**
K.A. Schmersal GmbH
Geschäftsstelle Frankfurt
Kilianstädter Straße 38
**61137 Schöneck**
Telephone: +49-(0) 61 87-9 09 56-0
Facsimile: +49-(0) 61 87-9 09 56-6
E-Mail: gsfrankfurt@schmersal.de

## International agencies

**Argentina – Argentinien**
Roberto Pasqualini Representante
Av. Rivadavia 1321 – Piso 8°. Ofic. 32
**1033 Buenos Aires**
Telephone: +54-11-43 83-61 05
Facsimile: +54-11-43 83-61 05
E-Mail: whbo@attglobal.net

**Australia – Australien**
NHP Electrical Engineering
Products Pty. Ltd.
43 - 67 River Street
PO Box 199
Richmond 3121
**Melbourne, Victoria**
Telephone: +61-(0) 3-94 29 29 99
Facsimile: +61-(0) 3-94 29 10 75
E-Mail: products@nhp.com.au
Internet: www.nhp.com.au

**Austria – Österreich**
AVS-Schmersal Vertriebs Ges. m.b.H.
Biróstraße 17
**1232 Wien**
Telephone: +43-(0) 1-6 10 28
Facsimile: +43-(0) 1-6 10 28-1 30
E-Mail: infoservice @avs-schmersal.co.at
Internet: www.avs-schmersal.co.at

**Belgium – Belgien**
Schmersal Belgium NV/SA
Nieuwlandlaan 16B
Industriezone B413
**3200 Aarschot**
Telephone: +32-(0) 16-57 16 18
Facsimile: +32-(0) 16-57 16 20
E-Mail: info@schmersal.be

**Brazil – Brasilien**
ACE Schmersal
Eletroeletrônica Industrial Ltda.
Rodovia Boituva – Porto Feliz, Km 12
Vila Esplanada – CEP 18550-000
**Boituva – SP**
Telephone: +55-(0) 15-2 63-98 66
Facsimile: +55-(0) 15-2 63-98 90
E-Mail: export @aceschmersal.com.br
Internet: www.aceschmersal.com.br

**Chile – Chile**
NDU Ingeneria
Santa Elisa 498
7160269 La Cisterna
**Santiago de Chile**
Telephone: +56-2-5 26-66 46
Facsimile: +56-2-5 26-50 46
E-Mail: matelec@ndu.cl

**Colombia – Kolumbien**
Cimpex Ltda.
Apartado Aereo 2429
**Medellin**
Telephone: +57-4-2 51-59 72
Telephone: +57-4-2 51-59 87
Facsimile: +57-4-2 51-46 08
E-Mail: cimpex@supernet.com.co

**Costa Rica – Costa Rica**
Euro-Tec, S.A.
Apartado Postal 477
1250 Escazú
**San José**
Telephone: +5 06-3 84-78 69
Telephone: +5 06-2 31-41 01
Facsimile: +5 06-2 96-15 42
E-Mail: eurotec@sol.racsa.co.cr

**PR China – VR China**
Schmersal Industrial Switchgear
(Shanghai) Co. Ltd.
Central Plaza 1001
Huang Pi Bei Road 227
**200003 Shanghai**
Telephone: +86-21-63 75 82 87
Facsimile: +86-21-63 75 82 97
E-Mail: schmersl @public3.sta.net.cn
Internet: www.schmersal.com.cn

**Czech Republic – Tschechische Republik**
Mercom Componenta spol. s.r.o.
Ruská 67
**100 00 Praha 10**
Telephone: +4 20-(0) 2-67 31 46 40
Telephone: +4 20-(0) 2-67 31 46 41
Facsimile: +4 20-(0) 2-71 73 32 11
E-Mail: mercom@bohem-net.cz

**Denmark – Dänemark**
Schmersal Danmark A/S
Lindegårdsvej 17A
**2920 Charlottenlund**
Telephone: +45-70 20 90 27
Facsimile: +45-70 20 90 37
E-Mail: info@schmersal.dk
Internet: www.schmersal.dk

**Finland – Finnland**
Advancetec Oy
Malminkaari 10B
PO Box 149
**00701 Helsinki**
Telephone: +3 58-(0) 9-3 50 52 60
Facsimile: +3 58-(0) 9-35 05 26 60
E-Mail: advancetec@advancetec.fi
Internet: www.advancetec.fi

**France – Frankreich**
Automatisme et Contrôle
8, rue Raoul Follereau
BP 18
**38180 Seyssins**
Telephone: +33-4 76 84 23 20
Facsimile: +33-4 76 48 34 22
E-Mail: info@automatisme-et-controle.fr
Internet: www.automatisme-et-controle.fr

**Greece – Griechenland**
Kalamarakis Sapounas S.A.
Ionias & Neromilou
PO Box 46566
13671 Chamomilos Acharnes
**Athens**
Telephone: +30-(0) 1-2 40 60 00-6
Facsimile: +30-(0) 1-2 40 60 07
E-Mail: kalamarakis.sapounas @ksa.gr

**Honduras – Honduras**
Lusitana Int´l
Distribuciones – Represantaciones
Apdo. Postal # 783
**San Pedro Sula**
Telephone: +5 04-5 57-66 35
Facsimile: +5 04-5 57-66 35

**08** **Saarland**
Herbert Neundörfer
Werksvertretungen
Saargemünder Str. 68a
**66130 Güdingen**
Telephone: +49-(0)6 81-87 54 54
Facsimile: +49-(0)6 81-87 54 53
E-Mail: info
@herbert-neundoerfer.de

**19** **Leipzig**
K.A. Schmersal GmbH
Geschäftsstelle Leipzig
Nonnenstraße 11c
**04229 Leipzig**
Telephone: +49-(0) 3 41-4 87 34 50
Facsimile: +49-(0) 3 41-4 87 34 51
E-Mail: gsleipzig@schmersal.de

**09** **North Bavaria**
K.A. Schmersal GmbH
Geschäftsstelle Nürnberg
Beethovenstraße 14
**91074 Herzogenaurach**
Telephone: +49-(0) 91 32-73 70 00
Facsimile: +49-(0) 91 32-73 48 44
E-Mail: gsnuernberg@schmersal.de

**15** **Central Bavaria**
Ing. Adolf Müller GmbH
Industrievertretungen
Elly-Staegmeyr-Str. 15
**80999 München**
Telephone: +49-(0) 89-8 12 60 44
+49-(0) 89-8 12 60 45
Facsimile: +49-(0) 89-8 12 69 25
E-Mail: info@ingam.de

**10** **South Bavaria**
K.A. Schmersal GmbH
Geschäftsstelle München
Postfach 10 01 22
85592 Baldham
Neue Poststraße 13
**85598 Baldham**
Telephone: +49-(0) 81 06-85 62
Facsimile: +49-(0) 81 06-3 30 13
E-Mail: gsmuenchen
@schmersal.de

**11** **Stuttgart**
Gerhard Schützinger
Labor-Schütz GmbH
Industrievertretungen
Postfach 81 05 69, 70522 Stuttgart
Eichwiesenring 6
**70567 Stuttgart**
Telephone: +49-(0) 7 11-7 15 46-0
Facsimile: +49-(0) 7 11-7 15 46-18
E-Mail: hv@schuetzinger.de
Internet: www.schuetzinger.de


**Hungary – Ungarn**
NTK
Ipari-Elektronikai és
Kereskedelmi KFT.
Kodaly Z.u. 1
**9023 Györ**
Telephone: +36-(0) 96-52 32 68
Facsimile: +36-(0) 96-43 00 11
E-Mail: ntkkft@mail.datanct.hu

**Italy – Italien**
Schmersal Italia s.r.l.
Via Papa Giovanni XXIII, 75/A
**25086 Rezzato (BS)**
Telephone: + 39-0 30-2 49 92 11
Facsimile: + 39-0 30-2 49 92 31
E-Mail: info@schmersal.it
Internet: www.schmersal.it

**Japan – Japan**
Schmersal Japan Branch Office
3-39-8 Shoan
Suginami-ku
**Tokyo 167-0054**
Telephone: +81-(0) 3-32 47-05 19
Facsimile: +81-(0) 3-32 47-05 22
E-Mail: safety@elanjp.com

**Korea – Korea**
MEC Manhani Electric Co. Ltd.
576-8, Bisan-2dong
Dongan-Ku
Anyang-City
**Kyungi-Do 431-821**
Telephone: +82-(0) 31-4 63-33 00
Facsimile: +82-(0) 31-4 63-33 98
Facsimile: +82-(0) 31-4 63-33 99
E-Mail: yskim@hanmee.co.kr

**Mexico – Mexiko**
Spyro, S/A de cv
Andalucia No. 77 - Col. Alamos
**03400 Mexico, D.F.**
Telephone: +52-5-5 30-35 47
Telephone: +52-5-5 38-28 26
Facsimile: +52-5-5 30-35 47
E-Mail: spyro@infosel.net.mx

**Netherlands – Niederlande**
Hatenboer Elektro BV
Postbus 200
2170 AE Sassenheim
Wasbeekerlaan 59
**2171 AE Sassenheim**
Telephone: +31-(0) 2 52-21 90 12
Facsimile: +31-(0) 2 52-23 29 38
E-Mail: info@hatenboer.com
Internet: www.hatenboer.com

**New Zealand – Neuseeland**
NHP Electrical Engineering
Products (N.Z.) Ltd.
7 Lockhart Place
PO Box 6 20 09
Mt Wellington
**Auckland**
Telephone: +64-(0) 9-2 76 19 67
Facsimile: +64-(0) 9-2 76 19 92

**Norway – Norwegen**
Schmersal Nordiske
Hoffsveien 92
**0377 Oslo**
Telephone: +47-22 06 00 70
Facsimile: +47-22 06 00 80
E-Mail: info@schmersal.no
Internet: www.schmersal.se

**Paraguay – Paraguay**
Brasguay
Ruta Internacional, 07
**Mingua Guazu**
Telephone: +5 95-6 44-2 00 18
Facsimile: +5 95-6 44-2 05 77
Facsimile: +5 95-6 44-2 04 18
E-Mail: kuntz@foznet.com.br

**Poland – Polen**
Schmersal - Polska s.c.
ul. Kremowa 65A
**02-969 Warszawa**
Telephone: +48-(0) 22-8 16 85 78
Telephone: +48-(0) 22-8 16 85 79
Facsimile: +48-(0) 22-8 16 85 34
E-Mail: office@schmersal.pl

**Portugal – Portugal**
K. A. Schmersal GmbH
Sucursal em Portugal
Av. das Descobertas, 15-2° D
Quinta do Infantado
**2670 Loures**
Telephone: +3 51-21-9 83 92 83
Facsimile: +3 51-21-9 83 19 37
E-Mail: info@schmersal.pt
Internet: www.schmersal.pt

**Singapore – Singapur**
Tong Sim Marine & Electric Co.
46 Kaki Bukit Crescent
Kaki Bukit Techpark 1
**Singapore 416269**
Telephone: +65-7 43 31 77
Facsimile: +65-7 45 37 00
E-Mail: tongsim
@mbox4.singnet.com.sg

**Spain – Spanien**
Forn Valls S.A.
c/Milanesado, 2 tda
**08017 Barcelona**
Telephone: +34-9 32-03 41 33
Telephone: +34-9 32-04 05 44
Facsimile: +34-9 32-05 54 67
E-Mail: fvsa@retemail.es
Internet: www.fornvalls.com

**South Africa – Südafrika**
A+A Dynamic Distributors (Pty) Ltd.
42 Webber Street
Sølby
PO Box 38247
**2016 Booysens**
Telephone: +27-11-4 93 50 22
Facsimile: +27-11-4 93 07 60
E-Mail: nwkayser@iafrica.com

**Sweden – Schweden**
Schmersal Nordiska AB
Klockarus Våg 1
**43533 Mölnlycke**
Telephone: +46-(0) 31-3 38 35 00
Facsimile: +46-(0) 31-3 38 35 35
E-Mail: info@schmersal.se
Internet: www.schmersal.se

**Switzerland – Schweiz**
Schmersal Schweiz AG
Freilagerstrasse 25
**8047 Zürich**
Telephone: +41-(0) 43-3 11 22 33
Facsimile: +41-(0) 43-3 11 22 44
E-Mail: info@schmersal.ch

**Taiwan – Taiwan**
Leader Camel Enterprise Co., Ltd.
No. 453-7, Pei Tun Rd.
**Taichung**
Telephone: +886-4-2 41 32 92
Facsimile: +886-4-2 41 29 23
E-Mail: camel88@ms46.hinet.net
Internet: www.leadercamel.com.tw

**UK – Großbritannien**
Schmersal UK Ltd.
Unit 1, Beauchamp Business Centre
Enigma Park
**Malvern**
**Worcs WR14 1GL**
Telephone: +44-(0) 16 84-57 19 80
Facsimile: +44-(0) 16 84-56 02 73
E-Mail: support@schmersal.co.uk
Internet: www.schmersal.co.uk

**USA – USA**
Schmersal Inc.
100 Grasslands Road, Suite 110
Elmsford
**New York 10532**
Telephone: +1-(0) 9 14-347-47 75
Facsimile: +1-(0) 9 14-347-15 67
E-Mail: info@schmersalusa.com
Internet: www.schmersalusa.com

**Venezuela – Venezuela**
Petro System S.A.
Calle M, Residencias Las Rosas
P.B. Local 3
Santa Rosa de Lima, Baruta
**Caracas**
Telephone: +58-2 12-9 92-1916
E-Mail: petro@habitad.com
Internet: www.habitad.com/
petrosystem

## Other catalogues and brochures on the subject of machine safety

**Catalogues**

- General catalogue Industrial switching systems
- General catalogue on CD ROM
- Programme overview
- Catalogue Part A Lift switchgear
- Catalogue Part B Proximity switches and synchro-generators

**Brochures**

- Explosion protected switches
- Foot switches for medical technology
- Foot switches GFI/GFSI
- Multiple luminaires ML35 / ML50
- Assembly kits
- Proximity switches series IFL
- Optoelectronic safety devices
- Safety system packages
- Safety contact mat
- Safety light barriers SLC 400
- Safety laser scanners SLB 200 / SLB 400
- Safety laser scanners LSS 300
- The guard knob system
- Door knob system TG 1PW LED
- Safety switch strips SE40 / SE70
- Switch and applications manual
- S Guide gor safety modules
- Poster S Guide for safety modules
- Steute programme overview
- Company brochure – enterprise safety


Safety Relay Modules
Protect SRB series
Version 2.0 – August 2002
Housing Dimensions and Wiring Diagrams
System requirements
• Minimum Pentium 90 PC with 16 MB RAM
• Windows® 95 or higher
• Windows® NT V3.51 or higher
• Acrobat Reader 4.0
To install Acrobat Reader execute the file ACRD4ENU in the directory \ACROREAD on the CD-ROM.
SCHMERSAL

K. A. Schmersal GmbH
Industrielle Sicherheitsschaltsysteme
Möddinghofe 30
D-42279 Wuppertal
Tel.: +49-(0)2 02 / 64 74-0
Fax: +49-(0)2 02 / 64 74-100
Internet: http://www.schmersal.de
E-Mail: info@schmersal.de

08.02