

2.54mm/0.1" Pitch Terminal Block - 6-pin

PRODUCT ID: 2135

There are multiple versions of this item. Please select one from the options below:

IN STOCK

1


ADD TO CART

1-9

10-99

100+

ADD TO WISHLIST

[DESCRIPTION](#)[TECHNICAL DETAILS](#)

DESCRIPTION

After a long day out harvesting in the terminal block fields, we've returned with a veritable bounty of these very nice and compact 2.54mm/0.1" terminal blocks in a variety of sizes.

Our harvest of terminal blocks is great news since nothing makes a project harder to maintain than a lot of loose wiring. That's why we like to use terminal blocks whenever making PCB-to-wire connections. These are 2.54mm spaced blocks so they fit easily into perf or protoboards. They don't fit well into solderless breadboards since the legs are not very long, and **they don't snap together or fit side-by-side on a 0.1" grid** - but that's okay since we've got a bunch of sizes to choose from.

These terminal blocks are also big enough for a range of wire gauges and easy to adjust with a screwdriver. They're not too chunky - so won't take up too much space on your protoboard - and found them pretty ideal for projects where you need a specific number of pins.

This is one single 6-pin terminal block. [Check out our other sizes here!](#)



TECHNICAL DETAILS

[Datasheet](#)

Dimensions (w/o pins): 16mm x 9mm x 6mm / 0.6" x 0.4" x 0.2"

Pin Length: 3mm / 0.1"

Weight: 1.5g











LEARN



[Pulse Room](#)


Control room lighting & sound with the beat of your heart.

MAY WE ALSO SUGGEST...






Configurable Spring



2.54mm/0.1" Pitch Terminal



2.54mm/0.1" Pitch Terminal

DISTRIBUTORS [EXPAND TO SEE DISTRIBUTORS](#)

[CONTACT](#)

[SUPPORT](#)

[DISTRIBUTORS](#)

[EDUCATORS](#)

[JOBS](#)

[FAQ](#)

[SHIPPING & RETURNS](#)

[TERMS OF SERVICE](#)

[PRIVACY & LEGAL](#)

[ABOUT US](#)

"In order to change an existing paradigm you do not struggle to try and change the problematic model. You create a new model and make the old one obsolete" -
R. Buckminster Fuller

ENGINEERED IN NYC Adafruit®



4.9 ★★★★★
Google
Customer Reviews