



INSTRUCTIONS:

- 1) CUT THE WIRES ACCORDINGLY AS SHOWN ABOVE.
- 2) RUN IT THROUGH INSULATOR AND SOLDER THE CONTACT WIRES TO THE PLUG ASSEMBLY. CONNECT THE INSULATOR TO THE PLUG ASSEMBLY.
- 3) NOW SLIDE THE CONNECTED PLUG ASSEMBLY, INSULATOR INTO THE TINI QG HOUSING. MAKE SURE THAT THE PLUG ASSEMBLY IS BUTTED UP AGAINST THE FRONT OF THE TINI QG HOUSING.
- 4) SOLDER THE GROUND TERMINAL WIRE TO THE TINI QG HOUSING'S LOWER THRU HOLE AS SHOWN.
- 5) SLIDE THE BOTTOM PLASTIC HOUSING UP TOWARDS THE MALE HOUSING
- 6) DROP AND SLIDE THE TOP RIGHT ANGLE HOUSING INTO THE GROVE SUCH AS IT LATCHES WITH THE BOTTOM PLASTIC AND MALE HOUSING.
- 7) SLIDE THE CABLE CLAMP THROUGH THE CABLE INTO THE TOP/BOT HOUSINGS AS SHOWN.
- 8) SCREW THE PLUG HANDLE AND POP IN THE BOOT TO ASSEMBLE FULL PRODUCT.

**PRELIMINARY
CUSTOMER DRAWING**

<p>UNLESS OTHERWISE SPECIFIED</p> <p>1. ALL DIMENSIONS IN INCHES [mm]</p> <p>- TWO PLACE DECIMALS ±0.02 [0.5]</p> <p>- THREE PLACE DECIMALS ±0.005 [0.13]</p>					<p>THIS DRAWING DESCRIBES A DESIGN CONSIDERED PROPRIETARY IN NATURE, DEVELOPED AND MANUFACTURED BY SWITCHCRAFT INC. AND IS RELEASED ON A CONFIDENTIAL BASIS FOR IDENTIFICATION PURPOSES ONLY.</p>				
					SIZE *	WIDTH *	MULT *	LBS/M *	TEMPER *
<p>REV</p> <p>ECO NUMBER</p> <p>DATE</p> <p>BY</p> <p>APVD</p> <p>REVISIONS</p>					<p>FINISH *</p> <p>SPEC No. *</p>		<p>MATERIAL *</p> <p>SPEC No. *</p>		
					<p>DATE DRAWN</p> <p>01/03/17</p>		<p>BY</p> <p>AM</p>	<p>CHKD</p> <p>*</p>	<p>APVD</p> <p>*</p>
<p>DO NOT SCALE DRAWING</p>					<p>NAME</p> <p>TINI QG, MALE RA, RoHS</p>		<p>PART No.</p> <p>TARA_MX SERIES_CD</p>		
					<p>Switchcraft®</p>		<p>SHEET 1 OF 1</p>		
					<p>REV</p> <p>0A</p>				

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Switchcraft:](#)

[TARA4MX](#) [TARA3MX](#) [TARA5MX](#) [TARA6MX](#)