


OPTI-CAP® BROADBAND DATASHEET - BNL VERSION

FEATURES


- ✓ Same form and fit as previous Milli-Cap.
- ✓ Resonance-free DC blocking frequency extended up to 50 GHz.
- ✓ Available in 0201, 0402 and 0602 footprints.
- ✓ Very low series inductance.
- ✓ Low frequency stability over temperature.
- ✓ SMT by solder or epoxy bonding.
- ✓ X7R part with voltage stability.
- ✓ Applications:
 - o Broadband Microwave/Millimeter Wave
 - Test Equipment, Photonics, SONET, TOSA/ROSA, High Speed
 Data
 - Transimpedance Amplifiers
- ✓ Low insertion loss.
- ✓ Coplanar Waveguide
- ✓ Eliminates wire-bonding





Old Part Number	New Part Number	Capacitor MLC	Capacitor Milli-Cap	Tol.	DF (Max)	Case Size	тсс	Voltage Rating	IR MΩ (Min)	Freq. Range
P21BN300MA04733 P21BN300MA4733	P21BNL300MA04733	100 nF	30 pF	±20%	3.5%	0201	X5R	10 V	10 ²	
P21BN300MA04282 P21BN300MA4282	P21BNL300MA04282	22 nF	30 pF	±20%	3.5%	0201	X5R	10 V	10 ²	
P21BN300MA03976 P21BN300MA3976	P21BNL300MA03976	10 nF	30 pF	±20%	3.5%	0201	X5R	10 V	10 ²	
P21BN300MA04678 P21BN300MA4678	P21BNL300MA04678	1.5 nF	30 pF	±20%	3.5%	0201	X7R	25 V	10 ²	16 KHz – 50 GHz
P42BN820MA04679 P42BN820MA4679	P42BNL820MA04679	22 nF	82 pF	±20%	3.5%	0402	X7R	50 V	10 ²	
P42BN820MA03152 P42BN820MA3152	P42BNL820MA03152	220 nF	82 pF	±20%	3.5%	0402	X5R	10 V	10 ²	
P62BN820MA02636 P62BN820MA2636	P62BNL820MA02636	100 nF	82 pF	±20%	3.5%	0602	X7R	25 V	10 ²	





ATTACHMENT METHOD


Using Conductive Epoxy

- Place a single drop of conductive epoxy onto each microstrip. Keep the epoxy back from the edge based on the specific footprint.
- 2. Centering the termination gap in the micro strip, press with even pressure on to the micro strip ensuring the end terminations make good contact with the epoxy.
- 3. Cure based according to the epoxy manufacturer's preferred schedule (typically 125 to 250°C).
- 4. After curing, inspect joint for epoxy shorts across the termination and micro strip gaps to verify cause of short across the capacitor.
- 5. It is safe to use Isopropanol and Methanol to pre-clean, but not after mounting with conductive epoxy as they would act as a solvent.


Using Solder

- Place a single drop of solder on to each micro strip.
 Keep the solder back from the edge based on the specific footprint.
- 2. Centering the termination gap in the micro strip, press with even pressure on to the micro strip ensuring the end terminations make good contact with the epoxy.
- 3. Reflow according to solder manufacturer's preferred profile, ensuring reflow temperature does not exceed 250°C.
- 4. After reflow step is completed, inspect joints for voids or excess flux and solder balls that can degrade performance or cause shorts across the gaps.
- 5. It is safe to use Isopropanol and Methanol with soldered Milli-caps.





DIMENSIONAL SPECIFICATIONS



	Part Dimensions					Mounting Guidelines				
Case Size	Length, B	Width	Thickness	Gap, A (typ)	End Block, C (typ)	Epoxy Thickness, Et	Epoxy Diameter	Gap	Distance from Trace Edge	
P21 (0201)	0.020" ± 0.004"	0.012" ± 0.002"	0.010" ± 0.002"	0.005"	0.008"	0.003" – 0.005"	0.005" – 0.008"	0.008" – 0.010"	0.003" to 0.004"	
P42 (0402)	0.038" ± 0.004"	0.020" ± 0.002"	0.020" ± 0.002"	0.008"	0.015"	0.003" – 0.005"	0.010" – 0.015"	0.015" – 0.020"	0.003" to 0.004"	
P62 (0602)	0.058" ± 0.004:	0.020 ± 0.002"	0.020 ± 0.002"	0.008"	0.025"	0.003" – 0.005"	0.010" – 0.015"	0.015" – 0.020"	0.003" to 0.004"	

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Knowles:

<u>P21BNL300MA04678</u> <u>P21BNL300MA04282T</u> <u>P21BNL300MA04733</u> <u>P21BNL300MA04733T</u> <u>P42BNL820MA04679</u> P42BNL820MA03152T P62BNL820MA02636 P62BNL820MA02636T P42BNL820MA04679T P21BNL300MA03976